


## MODEL 900B SERIES HYDRAULIC TAIL SEMITRAILER OPERATOR'S MANUAL



1900 North Street Marysville, KS 66508 (785)562-5381



### LANDOLL CORPORATION

#### TRAILER FIVE YEAR LIMITED WARRANTY POLICY

Landoll Corporation warrants each new Trailer structure manufactured by Landoll Corporation to be free from defects in materials and workmanship. This limited warranty is subject to specific exclusions and does not apply to any trailer which has been: 1) subjected to or operated with loads which, at any time, have exceeded the trailer's rated capacity or design limits: 2) repaired or altered outside our factory in any way so as, in our judgment, to affect its stability or reliability: 3) subject to misuse, negligence, accident, or has been operated in a manner expressly prohibited in the instructions; or not operated in accordance with practices approved by Landoll Corporation. Trailer structure shall be considered the framework of the trailer (mainframe and/or rear frame weldment, gooseneck weldment and undercarriage weldment) which is fabricated by Landoll Corporation.

The sole obligation of Landoll Corporation under this warranty shall be limited to repairing or replacing, at its option, in accordance with the schedule below, a defective new Trailer structure which shall be identified to Landoll Corporation by way of a Landoll Corporation e-mail Warranty Claim Form within five (5) years from the date of registration of Trailer. Warranty, expressed or implied, will be denied on any Trailer not properly registered with the Landoll Corporation Warranty Department within ten (10) days of the first retail sale. Landoll Corporation Warranty Staff will identify components listed on a Warranty Claim required to be returned for further analysis. All parts returned to Landoll Corporation must be shipped with a Return Materials Authorization (RMA) provided by the Landoll Corporation Warranty Staff. Defective components must returned by the purchaser to Landoll Corporation with transportation and freight charges prepaid within fifteen (15) days after receipt of the RMA. The examination conducted by Landoll Corporation of returned parts shall disclose to its satisfaction the extent the component may be detective.

All labor and parts warranty MUST be authorized by Landoll Corporation Warranty Staff. Failure to do so will result in no warranty payment of any kind. Labor will be reimbursed in accordance with published shop rates pre-approved by the Landoll Corporation Warranty Staff. Time authorized for specific work will be limited, where appropriate, to the hours listed in the Landoll Corporation authorized Flat Rate Schedule.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES OF MATERIAL, WORKMANSHIP, DESIGN, APPLICA-TION OR OTHERWISE WITH RESPECT TO ANY EQUIPMENT, WHETHER EXPRESS OR IMIPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF LANDOLL COPRPORATION.

New Trailer Structure Schedule: Landoll Corporation shall bear that portion of the cost of repairing or replacing the new structure of the Trailer found to be defective within a sixty (60) month warranty period prorated on the following basis:

One (1) Year - 100% Three (3) Years - 70% Five (5) Years - 50%

Two (2) Years - 80% Four (4) Years - 60%

L

All Bottom Dump and Industrial and Utility Tag Trailers are exempt from the 5 year structural warranty and carry a 12 month structural warranty, due to the rugged and abusive off road use in which these off road units typically operate, and are subject to the Component Schedule below .

Component Schedule: Components manufactured by Landoll Corporation (other than the Structure) and Components supplied by other manufacturers shall be warranted under the following schedule:

Axles, Suspensions, Landing Gear, Wheels, Rims, Hubs, Rollers and Cam Followers,

Hydraulic Valve Body and other Landoll Corporation Components.

Coverage: 1 year 100%, Over 1 year 0%

Air Lines, Springs, Air Bags, Leveling Valves, Bearings, Brake Valves, Paint, Oil Seals, Engines,

Brake Drums, Shock Absorbers, Electrical, Cylinders, Wear Plates, Hydraulic Hoses & Connections

- Coverage: 1 6 months 100% Over 6 months 0%
- III. Tires and Tubes Coverage: Warranty claims must be made directly to the tire dealers.
- IV. Wood Components Coverage: 0%

This warranty does not expand, enlarge upon or alter in any way, the warranties provided by the original manufacturers and suppliers of component parts and accessories. This warranty excludes such parts or accessories which are not defective, but may wear out and have to be replaced during the warranty period, including, but not limited to, light bulbs, paint, brake lining, brake drums, wood pieces and the like. (Tire Warranties are expressly excluded from Landoll Corporation warranty herein.) Purchaser is expected to pay all repairs or replacement costs, in connection with this Agreement, including sales and other taxes immediately upon completion of work performed.

LIMITATION OF LIABILITY: Landoll Corporation shall not be liable to purchaser for any incidental or consequential damages suffered by the purchaser, including, but not limited to, any commercially reasonable charges, expenses or commissions incurred in connection with effecting cover or any other reasonable expense incident to the delay or other breach of warranty by Landoll Corporation, any loss of or damage to any cargo loaded or shipped in or on the Trailer, loss of anticipated profits, transportation expenses due to repairs, non-operation or increased expense of operation costs of purchased or replaced equipment, claim of customers, cost of money, any loss of use of capital or revenue, equipment rental, roadside assistance, or for any special damage or loss of any nature arising at any time or from any cause whatsoever.

LIMITATION OF REMEDY: In the event of Landoll Corporation failure to repair the Trailer subject to the warranty contained herein, the purchaser's sole and exclusive remedy against Landoll Corporation shall be for the repair or replacement of any defective part or parts of the Trailer subject to work or repair within the time period and manner set forth herein. This exclusive remedy shall not be deemed to have failed of its essential purpose so long as Landoll Corporation is willing and able to repair or replace defective parts in the prescribed manner.

### MODEL 900B SERIES HYDRAULIC TAIL SEMITRAILER OPERATOR'S MANUAL

PURCHASED FROM:	<b>DATE</b> / /
ADDRESS:	
PHONE NO.:	SERIAL NO.:

### **REPORTING SAFETY DEFECTS**

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Landoll Manufacturing.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Landoll Manufacturing.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

In the event of a defect or problem with your LANDOLL equipment, please notify LANDOLL CORPORATION:

LANDOLL CORPORATION SALES AND SERVICE 1900 NORTH STREET MARYSVILLE, KANSAS 66508

OR PHONE: 1-800-HAULOLL (1-800-428-5655) FAX NO.: (785)562-3240 FOR REPLACEMENT PARTS: (785)562-4650 1-800-423-4320 FAX NO.: (785) 562-4654

### **Table of Contents**

SECTION	DESCRIPTION	PAGE NO.
1	INTRODUCTION	
2	STANDARD SPECIFICATIONS	
2 3 3-1 3-2 3-3 3-4 3-5 3-6 3-7 3-8 3-9 3-10 3-11 3-12 3-13 3-14 3-15 3-16 3-17 3-18 3-19 3-20 3-21 3-22 3-23	OPERATING INSTRUCTIONS GENERAL PRE-COUPLING OF SEMITRAILER AND TRACTOR COUPLING OF THE TRACTOR TO THE SEMITRAILER CONNECTING TRACTOR SERVICES TO THE SEMITRAI TRACTOR AND SEMITRAILER CHECK-OUT TOWING THE SEMITRAILER PARKING THE TRAILER UNCOUPLING TOWING VEHICLE FROM SEMITRAILER TAIL/AXLE CONTROL LEVER AIR SUSPENSION DUMP VALVE. LOADING PROCEDURE UNLOADING PROCEDURE WORK LIGHT SWITCH (OPTION) WINCH CONTROLS DOCK LEVELER OPERATION AIR ACTIVATED UPPER DECK RAMP (OPTION) HYDRAULIC POWER SUPPLY ENGINE OPERATION (OI AIR RIDE OPERATION BULKHEAD (OPTION) REAR IMPACT GUARD SYSTEM ANTI-LOCK BRAKE SYSTEM (ABS) COLD WEATHER OPERATION	
3-24		3-28
4 4-1 4-2 4-3 4-4 4-5 4-6 4-7 4-8 4-9 4-10 4-11 4-12 4-13	MAINTENANCE AND LUBRICATION MAINTENANCE SCHEDULE MAINTENANCE PROCEDURES GOOSENECK, FRAME, AND DECK HYDRAULIC SYSTEM ELECTRICAL SYSTEM SUSPENSION MAINTENANCE. ALIGNMENT BRAKE SYSTEM MAINTENANCE HUB AND DRUM MAINTENANCE WHEEL BEARING LUBRICATION AND ADJUSTMENT. TIRE MAINTENANCE. WINCHES CRANK LANDING GEAR (SEE FIGURE 4-21)	
5	TROUBLESHOOTING	5-1

### SAFETY PRECAUTIONS



THIS IS THE SAFETY ALERT SYMBOL. IT IS USED TO ALERT YOU TO POTENTIAL INJURY HAZARDS. OBEY ALL SAFETY MESSAGES THAT FOLLOW THIS SYMBOL TO AVOID POSSIBLE INJURY OR DEATH.

DANGER INDICATES AN IMMINENTLY HAZARDOUS SITUA-TION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.

WARNING INDICATES A POTENTIALLY HAZARDOUS SITUA-TION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



CAUTION INDICATES A POTENTIALLY HAZARDOUS SITUA-TION WHICH, IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY.

CAUTION USED WITHOUT THE SAFETY ALERT SYMBOL INDI-CATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, MAY RESULT IN PROPERTY DAMAGE.



### **INTRODUCTION**

This manual provides operating, servicing, and maintenance instructions, for Model 900B series hydraulic tail semitrailer, manufactured by Landoll Corporation, Marysville, Kansas 66508.

- **SECTION 1** gives basic instructions on the use of this manual.
- SECTION 2 gives specifications for the semitrailer, including measurements and component specifications. A Standard Bolt Torque Table is provided to give guidelines for bolt torques to be used when servicing this product.
- **SECTION 3** gives instructions for the proper operation of the equipment.
- **SECTION 4** gives general maintenance procedures, a maintenance schedule, and a lubrication schedule. Improper maintenance will void your warranty.

IF YOU HAVE ANY QUESTIONS CONTACT:

LANDOLL CORPORATION 1900 NORTH STREET MARYSVILLE, KANSAS 66508 or phone: (785) 562-5381 or (800) 428-5655 or FAX: (785) 562-4893

- **SECTION 5** is a troubleshooting guide to aid in diagnosing and solving problems with the semitrailer.
- **PARTS LIST** is a separate manual showing the various assemblies, subassemblies, and systems. Refer to that manual when ordering Landoll replacement parts. Order parts from your Landoll dealer.
- **WARRANTY** The Warranty Registration form is located with the product documents. Fill it out and mail it within 15 days of purchase. The Warranty is printed inside the front cover.

NOTE: IMPROPER ASSEMBLY, MODIFICATION, OR MAINTENANCE OF YOUR LANDOLL EQUIPMENT CAN VOID YOUR WARRANTY.

**COMMENTS** Address comments or questions regarding this publication to:

LANDOLL CORPORATION 1900 NORTH STREET MARYSVILLE, KANSAS 66508 ATTENTION: PUBLICATIONS - DEPT. 55

### **STANDARD SPECIFICATIONS**

#### CAPACITY\*:

MODEL 930B TANDEM AXLE:
MODEL 950B TRIPLE AXLE:
GOOSENECK NON-TILTING
KING PIN SETTING:
UNDERCARRIAGE TRAVEL:
HYDRAULIC TAIL**
HYDRAULIC TAIL LOAD ANGLE - 12' TAIL
HYDRAULIC HOOKUP:
QUICK COUPLERS
ELECTRICAL HOOKUP:
AIR HOOK UP:GLAD HANDS
SPECIFIC BOLT TORQUES
AIR RIDE SUSPENSION:
EQUALIZER BEAM PIVOT AND ADAPTER BOLTS
WHEEL FASTENERS - ALL MODELS:
OUTER SPINDLE NUTS
* CAPACITY RATINGS ARE FRAME CAPACITIES ONLY. ACTUAL LOAD CAPACITIES MAY BE RE- STRICTED BY FACTORS SUCH AS GROSS AXLE WEIGHT RATINGS (GAWR) OR STATE AND FED- ERAL REGULATIONS. MAXIMUM CAPACITY MUST BE DISTRIBUTED OVER ENTIRE LENGTH OF TRAILER.

\*\* HYDRAULIC TAIL LOAD ANGLE AND DECK HEIGHT BASED ON STANDARD 10R17.5 TIRES.

## LANDOLL CORPORATION GENERAL TORQUE SPECIFICATIONS (REV. 4/97)

THIS CHART PROVIDES TIGHTENING TORQUES FOR GENERAL PURPOSE APPLICATIONS WHEN SPECIAL TORQUES ARE NOT SPECIFIED ON PROCESS OR DRAWING. ASSEMBLY TORQUES APPLY TO PLATED NUTS AND CAPSCREWS ASSEMBLED WITHOUT SUPPLEMENTAL LUBRICATION (AS RECEIVED CONDITION). THEY DO NOT APPLY IF SPECIAL GRAPHITE MOLY-DISULFIDE OR OTHER EXTREME PRESSURE LUBRICANTS ARE USED. WHEN FASTENERS ARE DRY (SOLVENT CLEANED), ADD 33% TO AS RECEIVED CONDITION TORQUE. BOLT HEAD IDENTIFICATION MARKS INDICATE GRADE AND MAY VARY FROM MANUFACTURER TO MANUFACTURER. THICK NUTS MUST BE USED ON GRADE 8 CAPSCREWS. USE VALUE IN [ ] IF USING PREVAILING TORQUE NUTS. TORQUE IS SPECIFIED IN FOOT POUNDS

UNC Size			SAE Grade 5		SAE Grade 8		UNF Size	SAE Grade 2		SAE Grade 5		SAE Grade 8	
1/4-20	4	[5]	6	[7]	9	[11]	1/4-28	5	[6]	7	[9]	10	[12]
5/16-18	8	[10]	13	[16]	18	[22]	5/16-24	9	[11]	14	[17]	20	[25]
3/8-16	15	[19]	23	[29]	35	[43]	3/8-24	17	[21]	25	[31]	35	[44]
7/16-14	24	[30]	35	[43]	55	[62]	7/16-20	27	[34]	40	[50]	60	[75]
1/2-13	35	[43]	55	[62]	80	[100]	1/2-20	40	[50]	65	[81]	90	[112]
9/16-12	55	[62]	80	[100]	110	[137]	9/16-18	60	[75]	90	[112]	130	[162]
5/8-11	75	[94]	110	[137]	170	[212]	5/8-18	85	[106]	130	[162]	180	[225]
3/4-10	130	[162]	200	[250]	280	[350]	3/4-16	150	[188]	220	[275]	320	[400]
7/8-9	125	[156]	320	[400]	460	[575]	7/8-14	140	[175]	360	[450]	500	[625]
1-8	190	[237]	408	[506]	680	[850]	1-14	210	[263]	540	[675]	760	[950]
1-1/8-7	270	[337]	600	[750]	960	[1200]	1-1/8-12	300	[375]	660	[825]	1080	[1350]
1-1/4-7	380	[475]	840	[1050]	1426	[1782]	1-1/4-12	420	[525]	920	[1150]	1500	[1875]
1-3/8-6	490	[612]	110	[1375]	1780	[2225]	1-3/8-12	560	[700]	1260	[1575]	2010	[2512]
1/1-2-6	650	[812]	1460	[1825]	2360	[2950]	1/1-2-12	730	[912]	1640	[2050]	2660	[3325]

#### **METRIC**

COARSE THREAD METRIC CLASS 10.9 FASTENERS AND CLASS 10.0 NUTS AND THROUGH HARDENED FLAT WASHERS, PHOSPHATE COATED, ROCKWELL "C" 38-45. USE VALUE IN [ ] IF USING PREVAILING TORQUE NUTS.

Nominal		Standar	d Toro	que	Nominal	Standard Torque				
Thread Diameter mm		ewton- leters		oot- ounds	Thread Diameter mm	Newton- Meters		Foot- Pounds		
6	10	[14]	7	[10]	20	385	[450]	290	[335]	
7	16	[22]	12	[16]	24	670	[775]	500	[625]	
8	23	[32]	17	[24]	27	980	[1105]	730	[825]	
10	46	[60]	34	[47]	30	1330	[1470]	990	[1090]	
12	80	[101]	60	[75]	33	1790	[1950]	1340	[1450]	
14	125	[155]	90	[115]	36	2325	[2515]	1730	[1870]	
16	200	[240]	150	[180]	39	3010	[3210]	2240	[2380]	
18	275	[330]	205	[245]						



# LANDOLL CORPORATION HYDRAULIC FITTING TORQUE SPECIFICATIONS 37° JIC, ORS, & ORB (REV. 10/97)

THIS CHART PROVIDES TIGHTENING TORQUES FOR HYDRAULIC FITTING APPLICATIONS WHEN SPECIAL TORQUES ARE NOT SPECIFIED

ON PROCESS OR DRAWING. ASSEMBLY TORQUES APPLY TO PLATED CARBON STEEL AND STAINLESS STEEL FITTINGS ASSEMBLED WITHOUT SUPPLEMENTAL LUBRICATION (AS RECEIVED CONDITION). THEY DO NOT APPLY IF SPECIAL GRAPHITE MOLY-DISULFIDE OR OTHER EXTREME PRESSURE LUBRICANTS ARE USED.

BRASS FITTINGS AND ADAPTERS - 65% OF THE TORQUE VALUE FOR STEEL. STAINLESS STEEL, ALUMINUM AND MONEL - THREADS ARE TO BE LUBRICATED. TORQUE IS SPECIFIED IN FOOT POUNDS

PARKER BRAND FITTINGS								
Dash Size	37 Degree JIC	O-Ring (ORS)	O-Ring Boss (ORB)					
-4	11-13	15-17	13-15					
-5	14-16	—	21-23					
-6	20-22	34-36	25-29					
-8	43-47	58-62	40-44					
-10	55-65	100-110	57.5-62.5					
-12	80-90	134-146	75-85					
-16	115-125	202-218	109-121					
-20	160-180	248-272	213-237					
-24	185-215	303-327	238-262					
-32	250-290	—	310-340					

### LANDOLL CORPORATION HYDRAULIC FITTING TORQUE SPECIFICATIONS 370 JIC, ORS & ORB (REV. 10/97)

THIS CHART PROVIDES TIGHTENING TORQUES FOR HYDRAULIC FITTING APPLICATIONS WHEN SPECIAL TORQUES ARE NOT SPECIFIED ON PROCESS OR DRAWING. ASSEMBLY TORQUES APPLY TO PLATED CARBON STEEL AND STAINLESS STEEL FITTINGS ASSEMBLED WITHOUT SUPPLEMENTAL

LUBRICATION (AS RECEIVED CONDITION). THEY DO NOT APPLY IF SPECIAL GRAPHITE MOLY-DISULFIDE OR OTHER EXTREME PRESSURE UBRICANTS ARE USED.

BRASS FITTINGS AND ADAPTERS - 65% OF THE TORQUE VALUE FOR STEEL. TORQUE IS SPECIFIED IN FOOT POUNDS.

#### AEROQUIP BRAND FITTINGS **O-Ring** 37 Degree JIC Dash **O-Ring Boss** Size (ORS) (OŘB) -4 11-12 10-12 14-16 -5 15-16 18-20 -6 18-20 18-20 24-26 50-60 -8 38-42 32-35 -10 57-62 46-50 72-80 125-135 -12 79-87 65-70 -14 160-180 200-220 -16 108-113 92-100 210-280 -20 127-133 125-140 -24 158-167 150-165 270-360 245-258 -32

Table 2-2 Hydraulic Fitting Torgue Specifications

#### 3-1 GENERAL

This section supplies information for operation of the semitrailer. It describes and locates controls and gives operation procedures. Read all instructions, warnings, cautions, and danger notes before attempting to operate the semitrailer. Operators must have proper training before operating the semitrailer. (See Figure 3-1 for location of semitrailer parts.)



DO NOT OPERATE THE SEMITRAILER WITH ANY KNOWN FAULT THAT MIGHT ENDANGER THE OCCUPANTS, NEARBY WORKERS, OTHER TRAFFIC, THE LOAD, OR THE EQUIPMENT.

### 

DO NOT OPERATE THE SEMITRAILER UNTIL YOU HAVE READ THE OPERA-TOR'S MANUAL AND COMPLETELY UNDERSTOOD THE PROPER USE AND FUNCTION OF ALL CONTROLS. IM-PROPER USE CAN CAUSE PERSONAL INJURY, DAMAGE TO YOUR SEMI-TRAILER AND CARGO, AND CAUSE TIME-CONSUMING BREAKDOWNS.

#### 3-1.1 Landing Gear

The landing gear consists of two legs, one on each side of trailer, with a tube telescoping within another tube. Crank style is standard (See Figure 3-3 for crank handle location). Pin drop style is optional.

#### 3-1.2 Parking Brake

The parking brakes are automatically applied by spring pressure within the air actuators of the braking system when air pressure in the emergency line drops below 50 psi. This may be done within the truck using trailer parking/emergency valve or by disconnecting the emergency gladhands.

#### 3-1.3 Air Brake System

The air brake system of the semitrailer is operated from the towing vehicle after coupling to the semitrailer. The towing vehicle's air system must be coupled to the semitrailer and charged to 90 psi minimum before the brakes can adequately function.

#### 3-1.4 Anti-lock Brake System (ABS)

The Anti-Lock Brake System of the semitrailer is constantly powered by the auxiliary (blue) circuit of the seven way electrical connector, with backup power from the stop lamp (red) circuit, and ground through the white wire. It is necessary that the blue circuit is hot when the tractor key switch is on. The blue circuit on the trailer may not be used to power any additional auxiliary devices while the semitrailer is moving forward. If a fault exists in the ABS, normal braking will occur, but wheels may lock. Service the ABS as soon as possible.

### 

THE AUXILIARY (BLUE) CIRCUIT IS FOR POWERING THE SEMITRAILER ABS. THIS CIRCUIT MUST BE HOT WHEN THE TRACTOR KEY SWITCH IS ON. NO OTHER ELECTRICAL DEVICES MAY BE POWERED BY THIS CIRCUIT WHILE THE SEMITRAILER IS MOVING FORWARD.

### 

IF A FAULT EXISTS IN THE SEMI-TRAILER ABS, NORMAL BRAKING WILL OCCUR, BUT WHEELS MAY LOCK. SERVICE THE ABS AS SOON AS POSSIBLE.




Figure 3-1 Trailer Terminology

#### 3-1.5 Electrical

The only electrical operation of the operator is interconnection of the towing vehicle electrical cable plug with the semitrailer electrical receptacle.

It is necessary that the tractor blue wire be connected to the appropriate electrical source on the tractor.

#### 3-2 PRE-COUPLING OF SEMITRAILER AND TRACTOR

- **3-2.1** Slowly back the tractor/truck (towing vehicle) up to the front end of the semitrailer so the kingpin of the semitrailer is centered between the tractor fifth wheel jaws. Stop the towing vehicle just inches ahead of the semitrailer. Set tractor parking brake.
- **3-2.2** Check the semitrailer king pin plate. It should be in a horizontal position. Use landing gear (See Section 3-1.1) to raise or lower the kingpin plate sufficiently to set proper coupling height. Drain all air and moisture from the towing vehicle air brake system following towing vehicle manufacturer's instructions.
- 3-2.3 Connect the service and emergency air hoses of the towing vehicle to their respective gladhand on the front of the semitrailer; red emergency line to the gladhand with the "EMERGENCY" tag, and the blue service line to the gladhand with the "SERVICE" tag (See Figure 3-2). Chock the semitrailer wheels before activating the semitrailer air supply valve in the towing vehicle. Set the parking brakes.

### WARNING

FAILURE TO CHOCK SEMITRAILER WHEELS COULD ALLOW MOVEMENT OF THE SEMITRAILER RESULTING IN SERIOUS PERSONAL INJURY, DEATH, OR DAMAGE TO PROPERTY IN ITS PATH.

#### 3-1.6 Hydraulic

Most controls are located on the driver's side of the trailer. A hydraulic pump must be coupled to the trailer hydraulic system, or the optional hydraulic engine package started, before any hydraulic controls can function. The hydraulic system is designed to operate at 2500 psi maximum pressure and approximately 17 gpm flow capacity.

- **3-2.4** Check the air brake operations of the semitrailer as follows:
  - **a.** Apply brakes and inspect brake action on all wheels for prompt application.
  - **b.** Release brakes. All brakes should release immediately. Air pressure should discharge quickly from the relay emergency valve.
  - **c.** Disconnect the emergency air line from the semitrailer gladhand. Trailer brakes should promptly set.
  - **d.** Re-connect the emergency air line to the semitrailer and activate the semitrailer air supply valve. The semitrailer brakes should set.




Figure 3-2 Service Hookups

#### 3-3 COUPLING OF THE TRACTOR TO THE SEMITRAILER

## 

KEEP ALL PERSONNEL CLEAR OF FRONT, REAR, AND SIDES OF TOW-ING VEHICLE AND SEMITRAILER DUR-ING COUPLING, COMPONENT OPERA-TIONS, AND UNCOUPLING. FAILURE TO STAY CLEAR CAN RESULT IN SE-RIOUS PERSONAL INJURY OR DEATH.

- **3-3.1** Verify the semitrailer wheels are chocked and brakes function properly.
- **3-3.2** Make certain the coupler of the towing vehicle's fifth wheel is open by pulling the latch handle.
- **3-3.3** Slowly back the towing vehicle so its fifth wheel contacts the front of the king pin plate on the semitrailer and slips under it. Continue backing until the fifth wheel coupler locks onto the semitrailer kingpin.

### CAUTION

PUSHING THE SEMITRAILER BACK-WARDS CAN DAMAGE PARKING STANDS.

- **3-3.4** Verify the vehicle coupling is secure by attempting to pull the tractor forward a few inches. If the tractor disconnects from the semitrailer, locate source of coupling failure; repair before continuing; and repeat **Section 3-3.3 and 3-3.4.**
- **3-3.5** Check that the towing vehicle couples securely to the semitrailer before setting towing vehicle and semitrailer parking brakes.

#### IMPORTANT

KEEP BRAKES ENGAGED FOR REMAINDER OF HOOKUP, CHECKOUT PROCEDURES, AND PARKING.

#### 3-4 CONNECTING TRACTOR SERVICES TO THE SEMITRAILER

**3-4.1** Connect the towing vehicle 7-pole electrical plug to the electrical receptacle on the front of the semitrailer (See Figure -).

#### **IMPORTANT**

THE KEY ON THE PLUG AND THE KEYWAY IN THE SOCKET MUST BE PROPERLY ALIGNED BEFORE INSERTING THE PLUG INTO THE SEMITRAILER SOCKET.

### CAUTION

HYDRAULIC OPERATING PRESSURES GREATER THAN 2500 PSI CAN CAUSE DAMAGE TO THE TRAILER.

**3-4.2** If you have not already done so, connect the tractor hydraulic lines to the semitrailer unless your semitrailer is equipped with the self-contained hydraulic power engine package.

#### IMPORTANT

SOME OIL MAY NEED TO BE REMOVED FROM THE TRACTOR RESERVOIR TO ALLOW ROOM FOR 12 GALLONS OF ADDITIONAL OIL DIS-PLACED FROM THE TRAILER HYDRAULIC SYSTEM.

3-4.3 Air Lines: See Section 3-2.

#### 3-5 TRACTOR AND SEMITRAILER CHECK-OUT

### 

FAILURE TO PROPERLY SET AND CHECK PARKING BRAKE, AND CHOCK WHEELS WHEN PARKING AND DURING STORAGE, COULD AL-LOW MOVEMENT OF THE TRUCK/SEMITRAILER RIG RESULT-ING IN SERIOUS PERSONAL INJURY, DEATH, OR DAMAGE TO PROPERTY IN ITS PATH.

**3-5.1** With hydraulic power operating, raise landing gear:

### CAUTION

ALWAYS GRIP CRANK HANDLE SE-CURELY WITH BOTH HANDS. NEVER SHIFT LANDING GEAR UNDER LOAD, LEAVE THE GEARS IN NEUTRAL OR LEAVE THE CRANK UNSECURED.

- a. For crank landing gear, retract landing gear by turning hand crank on control panel counterclockwise. Use low gear until the load is off the landing gear. Then shift to high gear and continue cranking until fully retracted. Leave the landing gear in high gear.
- **b.** For pin drop landing gear, unit weight is off the landing gear. Raise landing gear. Secure each leg with a park stand retaining pin in the full "up" position before transporting.

### CAUTION

1. LANDING GEAR LEGS MUST BE FULLY RETRACTED AND SECURED WITH PINS BEFORE OPERATING OR MOVING SEMITRAILER.

2. IF SEMITRAILER IS LOADED WHEN OPERATING LANDING GEAR, LOAD MUST BE CENTERED ON THE TRAILER.

- **3-5.2** Determine that the traveling undercarriage is completely slid back to transport position. Hold **TAIL/AXLE CONTROL LEVER** (See Section 3-9) in the transport position until hydraulic system works against the fully extended hydraulic axle cylinder.
- **3-5.3** Check the operation of all lights and signals on the semitrailer for proper response to switch positions (stop, right turn, left turn, and clearance). Check operation of remote function if present. Shut off hydraulic power.
- **3-5.4** Check tire inflation, adjust as needed to the pressure listed on the semitrailer VIN plate, located on the front of the semitrailer.
- **3-5.5** Check tractor/semitrailer rig for air leaks. If air leakage is found, repair the defect before transporting.
- **3-5.6** Check the oil in each hub for proper level and freedom from contamination. If hubs are contaminated with water, dirt or some other foreign material, clean before transporting.
- **3-5.7** Check tractor air pressure. Pressure must not fall below 90 psi, even after activating brakes a couple of times. Set parking brake and carefully remove all wheel chocks. Set emergency brake and try pulling forward. The semitrailer wheels must not rotate. If semitrailer brakes do not apply, **DO NOT** transport until defect, or defects, are repaired.




Figure 3-3 Hydraulic Controls

#### 3-6 TOWING THE SEMITRAILER

Driving the towing vehicle with the semitrailer coupled behind requires constant attention to the overall length of the combination. The "hinged-inthe-middle" configuration of the tractor and semitrailer, load, and weight effect performance. Turning, passing, acceleration, braking, stopping, and backup require special considerations. When executing steep grades or turning tight curves, the semitrailer must not be allowed to push the towing vehicle, or jack knifing the semitrailer with the towing vehicle may result. Application of the semitrailer brakes to keep the semitrailer in tow will help prevent this pushing. Braking should begin before descending a hill or attempting a curve, to assure control.

### CAUTION

WHEN OPERATING SEMITRAILER, DO NOT BACK OVER CURB. THIS WILL CAUSE SEVERE DAMAGE TO UNDER-CARRIAGE AND UNDERCARRIAGE CYLINDER.

- **3-6.1** Make a moving test of the semitrailer brakes at low, and medium speeds before traveling at highway speed.
  - a. The Anti-Lock Brake System (ABS) warning lamp mounted at left rear side of the semitrailer should come on when power is supplied to the ABS by turning the tractor keyswitch on. The warning lamp should go off once the semitrailer exceeds 4 mph. If the warning lamp does not go off, a fault exists in the semitrailer ABS. Once the vehicle speed exceeds 4 mph, the light should remain off unless a fault occurs or the keyswitch is turned off, then on again.

### 

IF A FAULT EXISTS IN THE SEMI-TRAILER ABS, NORMAL BRAKING WILL OCCUR, BUT WHEELS MAY LOCK. SERVICE THE ABS AS SOON AS POSSIBLE.

- **3-6.2** Monitor the air pressure gauge on the dash of the towing vehicle. Pressure should not fall below 90 psi at any time.
- **3-6.3** The semitrailer wheels track to the inside of the towing vehicle during turns. Thus, turning corners requires a wide swing to prevent "curb hopping", and to allow the semitrailer wheels to clear any obstacle on the inside of the corner.
- **3-6.4** To stop, use a gradual and smooth application of brakes. If grabbing occurs, apply less pressure grabbing brakes are not efficient.

### WARNING

ALWAYS CHECK BEHIND AND UNDER THE TRUCK AND SEMITRAILER FOR PERSONS OR OBJECTS BEFORE MOVING. FAILURE TO CHECK CAN LEAD TO SERIOUS PERSONAL IN-JURY OR DEATH TO OTHERS, OR DAMAGE TO PROPERTY.

**3-6.5** Backing should be done with care. Tail overhang, semitrailer length, and allowable space must be taken into consideration when backing the semitrailer.

### 3-7 PARKING THE TRAILER

- **3-7.1** Position truck/semitrailer rig on a level, solid surface.
- 3-7.2 Set the PARKING BRAKE, not the semitrailer hand brake, and check for proper brake holding.
- **3-7.3** Chock wheels of semitrailer.
- **3-7.4** Check for any air leaks in lines, relay valve, brake pods, or any other air system component.

### 

WHEN LEAVING THE SEMITRAILER UNATTENDED, POSITION ALL HY-DRAULIC CONTROLS TO THE NEU-TRAL OR "OFF" POSITION AND SHUT OFF THE HYDRAULIC ENGINE POWER SUPPLY, OR DISCONNECT THE TRAC-TOR HYDRAULIC HOOK-UP.

### 3-8 UNCOUPLING TOWING VEHICLE FROM SEMITRAILER

- **3-8.1** Park the semitrailer according to instructions in **Section 3-7**.
- **3-8.2** Lower the landing gear:
  - a. For crank landing gear, turn crank handle clockwise to extend. Using high gear, lower the landing gear until the pads make contact with the ground. To reduce the load on the fifth wheel, shift to low gear and crank an additional four to eight turns. Leave the landing gear engaged in low gear.

### CAUTION

ALWAYS GRIP CRANK HANDLE SE-CURELY WITH BOTH HANDS. NEVER SHIFT LANDING GEAR UNDER LOAD. NEVER LEAVE THE GEARS IN NEU-TRAL OR THE CRANK UNSECURED.

**b.** Lower the optional pin drop landing gear to the ground until next hole in landing gear is available. Pin through both inner and outer legs of landing gear.

### 

WITH PIN DROP LANDING GEAR, BE SURE TO SECURE EACH LEG WITH PIN BEFORE LEAVING SEMITRAILER UNATTENDED.

- **3-8.3** Disconnect the emergency and service air lines and attach them to the tractor gladhand holders. If present, install dummy gladhands on trailer couplings.
- **3-8.4** Disconnect the 7-pole electrical cable and hydraulic lines from the semitrailer and store with the tractor.
- **3-8.5** Pull the tractor fifth wheel plate latch release lever.
- **3-8.6** Attempt to pull the tractor forward. If the tractor uncouples, verify all service lines are disconnected and semitrailer wheels are chocked. If tractor does not disconnect, repeat **Section 3-8.5 and 3-8.6**.
- **3-8.7** Pull the tractor away from the semi-trailer.

### DANGER

ALWAYS CHECK BEHIND AND UNDER THE TRUCK AND SEMITRAILER FOR PERSONS OR OBJECTS BEFORE MOVING. FAILURE TO CHECK CAN LEAD TO SERIOUS PERSONAL IN-JURY OR DEATH TO OTHERS, OR DAMAGE TO PROPERTY.

#### 3-9 TAIL/AXLE CONTROL LEVER

The TAIL/AXLE CONTROL LEVER (See Figure 3-3) is located on the control panel. The lever is used both for loading/unloading and dock leveler operation. See Section 3-15.2 for use of TAIL/AXLE CONTROL LEVER for dock leveler operation. The TAIL/AXLE CONTROL LEVER is the beside the winch control lever and has three positions:

#### 3-10 AIR SUSPENSION DUMP VALVE

- **3-10.1** The 900B Series semitrailer comes equipped with a "dump valve" on the air ride suspension as standard equipment (See Figure 3-3). The valve has two primary purposes.
  - a. When the trailer is in the load position (tail down), you can dump the air (turn knob to ON) to achieve the lowest load angle.
    - It is NOT necessary to dump the valve each and every time that you ground load; however, when you need to minimize the load angle to load on the tail or over the hinge, then you can dump the air. The only time to operate the dump valve during the ground loading process is while the axles are in the foremost forward position.

#### IMPORTANT

### DO NOT OPERATE THE AXLES WHILE THE AIR IS DUMPED (KNOB TURNED ON).

2. To load, bring your axles forward until your travel cylinder stops, dumped the air (turn knob to ON).

DOWN/ LOAD CENTER UP/ROAD In this position, the undercarriage slides forward for loading.

This is the neutral position.

- In this position, the undercarriage slides to the rear. The undercarriage must be in the rear-most position for transport.
- **3.** Before returning the trailer axles to transport position, return the dump valve knob to the OFF position. This will inflate the air suspension and give proper clearance for the tires and traveling undercarriage.
- **b.** While loading from a dock (tail at dock height), the dump valve will exhaust all air from the suspension. This places the suspension and trailer in the most stable position for loading heavy equipment from a dock onto the trailer deck.
  - 1. It is common to use the dump valve each and every time while loading/unloading from a dock. It adds stability and safety to the operation.
  - 2. To load from a dock, bring the undercarriage forward to engage the dock arm return the undercarriage rearward and raise the tail a few inches above dock height.
  - **3.** Dump the air (turn knob to ON position). The air will exhaust from the suspension and lower the tail to dock height. If you need to adjust the axles to better match the dock height, it is ok to move the axles forward or rearward those few inches to accomplish the required height.

#### 3-11 LOADING PROCEDURE

### 

1. DO NOT GO NEAR UNDERCAR-RIAGE WHEN CAM ROLLERS ARE PARTIALLY IN POCKETS. CHECK THAT CAM ROLLERS ARE COM-PLETELY IN, OR COMPLETELY OUT OF POCKETS. IF A HYDRAULIC HOSE IS DISCONNECTED FROM THE SYS-TEM, THE UNDERCARRIAGE COULD SLIDE ABRUPTLY INTO THE POCK-ETS, DROPPING TAIL.

2. KEEP ALL PERSONS CLEAR WHILE OPERATING HYDRAULIC TRAVELING TAIL TO AVOID SERIOUS INJURY OR DEATH BY BEING PINCHED IN TRAILER BED.

- **3-11.1** Practice all standard industrial safety standards. Do not load any payload that will overload any component of the trailer or cause an unsafe condition.
- **3-11.2** Park the tractor/semitrailer in a straight line on level even surface. Set the tractor brakes and release the semitrailer brakes (See Figure 3-4).
- **3-11.3** Start operation of hydraulic power system. If the hydraulic engine package is installed, start and warm up engine following engine operating instructions in **Section 3-17. (Read engine operator's manual.)**

### CAUTION

DO NOT HOOK WINCH CABLE TO THE TAIL, WHEN PULLING THE UNDER-CARRIAGE FORWARD TO LOWER AP-PROACH PLATE TO THE GROUND.

### 

AIR RIDE SUSPENSION MUST BE IN TRANSPORT (OFF) POSITION WHILE MOVING UNDERCARRIAGE FOR-WARD.

- **3-11.4** Move undercarriage forward (into pockets) using the **TAIL/AXLE CONTROL LEVER** until approach plate touches the ground (See Section 3-9).
- **3-11.5** If winch cable is connected to tail bed, disconnect cable from tail bed or reel out cable as needed to keep it from becoming too tight when lowered (See Section 3-14).
- **3-11.6** Switch the air ride suspension to lower (on) position for lowest load angle after pulling undercarriage forward to stabilize trailer for loading.

### 

IN LOADING OR UNLOADING POSI-TION, THE APPROACH PLATE SHOULD BE RESTING ON THE GROUND AND THE UNDERCARRIAGE FULLY FORWARD.

### 

ALWAYS USE LOW LOAD ANGLE TO LOAD AND UNLOAD POWERED PRODUCTS. **3-11.7** Winch or drive the load onto the semitrailer. Insure that the load is steering straight up onto the semitrailer and does not maneuver off the side of the semitrailer. Continue until load center of gravity is just ahead of the axles, if possible. The load should never place more weight on the kingpin than on the rear axles during loading and unloading.

### CAUTION


MODEL 930 SEMITRAILER MAXIMUM CONCENTRATED LOAD IN A 10 FT. AREA IS 50,000 LBS. MODEL 950 SEMITRAILER MAXIMUM CONCEN-TRATED LOAD IN A 10 FT. AREA IS 70,000 LBS.

### 

1. THE SEMITRAILER MUST BE COU-PLED TO A TRACTOR AND THE LAND-ING GEAR RAISED OFF THE GROUND BEFORE OPERATING.

2. DO NOT EXCEED THE GROSS AXLE WEIGHT RATINGS FOR ANY AXLE ON YOUR VEHICLE. THE COMBINED WEIGHT OF THE SEMITRAILER AND CARGO MUST NOT EXCEED THE GROSS VEHICLE WEIGHT RATING (GVWR) OF THE TRAILER.

- **3-11.8** Securely tie down the load and attach the winch cable to the front of the load, if it is not already attached. Reel in winch cable until it becomes tight. (Winch cable serves as a safety tiedown in case load tiedown fails but is not to replace tie downs.)
- **3-11.9** Before returning trailer to transport position, return air ride suspension switch to transport (off) position.
- **3-11.10** Using **TAIL/AXLE CONTROL LEVER**, move the undercarriage to the rear until it is in transport position. The tail deck will raise as the undercarriage moves into the transport lock position. Hold **TAIL/AXLE CON-TROL LEVER** in the transport position until hydraulic system works against the fully extended Hydraulic Axle Cylinder (Approximately 15-30 seconds).
- **3-11.11** Recheck that load is properly secured. If necessary, unsecure the load, move load slightly forward or rearward on the load bed to get correct weight distribution on kingpin and the trailer axles, and resecure the load with the tiedowns and winch cable.
- 3-11.12 Shut down hydraulic power system. If hydraulic engine package is installed, shut down the auxiliary hydraulic power engine following operating instructions in Section 3-17. Assure maintenance schedule is upto-date and semitrailer is ready to be pulled.





#### 3-12 UNLOADING PROCEDURE

- **3-12.1** Practice all standard industrial safety standards.
- 3-12.2 Park the tractor/semitrailer in a straight line on a level even surface (See Figure 3-4). Set the tractor brakes and release the semitrailer brakes.
- **3-12.3** Start operation of hydraulic power system. If the hydraulic engine package is installed, start and warm up the auxiliary hydraulic power engine following engine operating instructions in **Section 3-17**.

### 

WHEN LOAD IS ON TAIL, DO NOT LOWER WITH LOAD SECURED TO MAIN DECK. WHEN LOAD IS ON MAIN DECK, DO NOT LOWER TAIL WITH LOAD SECURED TO TAIL.

- **3-12.4** Move load as far forward as is practical on the trailer and secure with appropriate load tiedowns.
- **3-12.5** Using the **TAIL/AXLE CONTROL LE-VER (See Section 3-9)**, move undercarriage forward until approach plate touches the ground.
- **3-12.6** Switch the air ride suspension to lower (on) position to achieve the lowest load angle.

### 

#### ALWAYS USE LOW LOAD ANGLE TO LOAD AND UNLOAD POWERED PRODUCTS.

- 3-12.7 If load is non-powered, insure that the winch cable is firmly attached to the load and tension is on the cable. Lower tail deck according to Sections 3-12.5 through 3-12.7, adjusting tension on winch cable as required. With winch cable firmly attached to load and sufficient tension on the cable so load securing devices can be safely removed, remove other load securing devices. Use the winch to assist the load down to end of approach plate. With end of load resting on ground, block load from rolling or sliding, if necessary. Disconnect the winch and move the trailer from under the load, allowing the load to move off trailer to the ground.
- **3-12.8** If powered load is secured to lower deck only, lower tail deck according to **Section 3-12.7**. Make sure the tail deck is tilted to the low load angle. Check that powered equipment parking brakes are set and winch cable hooked to powered equipment with sufficient tension so load securing devices can be removed. Remove safety securing devices. Take tension off winch cable and remove winch cable. Power load off the trailer.

### 

WHEN REMOVING LOAD, INSURE THAT THE LOAD IS STEERING STRAIGHT SO IT DOES NOT MANEU-VER OFF THE SIDE OF THE SEMI-TRAILER. FAILURE TO DO SO COULD RESULT IN DAMAGE TO EQUIPMENT, INJURY, OR DEATH.

- **3-12.9** If powered load is secured to both tail and lower deck, attention is required before lowering tail deck. Adjust load securing devices to allow tail to tilt and sufficiently secure load from movement while tail is tilted to low load angle.
- **3-12.10** Before returning the semitrailer to transport position insure that there is sufficient distance between the load and the rear of the semitrailer so that the semitrailer does not hit the load when being folded back to transport position.

### CAUTION

BEFORE RETURNING THE SEMI-TRAILER TO TRANSPORT POSITION, INSURE THAT THERE IS SUFFICIENT DISTANCE BETWEEN THE LOAD AND THE REAR OF THE SEMITRAILER. FAILURE TO DO SO MAY RESULT IN DAMAGE TO THE SEMITRAILER AND/OR LOAD.

- **3-12.11** Using **TAIL/AXLE CONTROL LEVER**, move undercarriage rearward to transport position. Hold **TAIL/AXLE CONTROL LE-VER** in the transport position until hydraulic system works against the fully extended Hydraulic Axle Cylinder (Approximately 15-30 seconds).
- **3-12.12** Reel in winch cable and secure hook on upper deck.
- **3-12.13** Shut down hydraulic power system. If hydraulic engine package is installed, shut down the auxiliary hydraulic power engine following operating instructions in **Section 3-17.**

#### 3-13 WORK LIGHT SWITCH (OPTION)

The **WORK LIGHT SWITCH** is on the hydraulic control panel (See Figure 3-3). It illuminates the hydraulic control panel and controls the optional work lights mounted on the bulkhead. The work lights illuminate the upper deck.

#### **3-14 WINCH CONTROLS**

### A DANGER

1. THE WINCH IS NOT DESIGNED OR INTENDED TO BE USED FOR LIFTING OR MOVING PEOPLE. USING IT THIS WAY CAN CAUSE SERIOUS INJURY OR DEATH.

2. MAKE CERTAIN THE WINCH CABLE SPOOL CLUTCH IS SET TO ENGAGE AND CLUTCH IS FULLY ENGAGED BE-FORE LOAD TENSION IS APPLIED TO WINCH CABLE. NEVER ATTEMPT TO DISENGAGE THE WINCH CABLE SPOOL WHEN THE CABLE IS UNDER TENSION. LOSS OF LOAD CONTROL, PROPERTY DAMAGE, INJURY OR DEATH CAN RESULT.

3. FAILURE TO LEAVE AT LEAST FIVE WINCH CABLE WRAPS ON THE WINCH CABLE SPOOL COULD ALLOW THE CABLE TO COME OFF THE SPOOL, RESULTING IN SERIOUS PERSONAL INJURY OR DEATH.

### 

DO NOT HANDLE THE WINCH CABLE WHEN THE WINCH IS IN THE ENGAGE POSITION. HANDS OR CLOTHING COULD GET CAUGHT IN THE CABLE AND BE PULLED INTO THE SPOOL CAUSING SERIOUS PERSONAL IN-JURY.

**3-14.1** The **WINCH CONTROL LEVER** (See Figures 3-1 and 3-3) is located beside the TAIL/AXLE CONTROL LEVER on the control panel. It is a three position control:

IN


This position will cause the winch to reel cable onto the winch spool when the winch clutch handle is engaged.


**CENTER** This is the neutral position. This position will not operate the winch.

- OUT This position will cause the winch to reel cable off of the winch spool when the winch is engaged.
- 3-14.2 The WINCH CLUTCH HANDLE (See Figure 3-5 and 3-6) is located on the right or curb-side end of the winch assembly. The function of the WINCH CLUTCH HANDLE is to engage or disengage the winch, allowing it to respond to the WINCH HYDRAULIC LEVER. For trailers equipped with optional PNEUMATIC WINCH CONTROL (15,000 lb. and 20,000 lb. winches only), the control is a switch on the control panel (See Figure 3-3). If the semitrailer also has the optional WINCH SPOOL AND AIR TENSION, it also is controlled by the same switch on the control panel. For the 15,000 lb. and 20,000 lb. winch, this switch controls both the clutch and the winch air tensioner simultaneously. For the 12,000 lb. winch, this switch controls only the air tensioner.

### CAUTION

A MINIMUM OF 5 WRAPS OF CABLE MUST BE LEFT ON THE WINCH DRUM.







### a. The **12,000 lb. WINCH CLUTCH HANDLE** has two positions: (See Figure 3-5)

- **DISENGAGE** When the handle is placed in this position, the winch is disengaged. This allows the spool to "freewheel" and the winch is not affected by use of the Winch Hydraulic lever.
- **ENGAGE** When the handle is placed in this position, the winch is engaged and cable may be spooled on or off the winch spool. The winch can now be controlled through the use of the Winch Hydraulic lever.

b. The 20,000 Ib WINCH CLUTCH HANDLE has two positions. (See Figure 3-6).

- DISENGAGE When the handle is placed in this position, the winch is disengaged. This allows the spool to "free-wheel" and the winch is not affected by use of the Winch In/Out lever.
- **ENGAGE** When the handle is placed in this position, the winch is engaged and cable may be spooled on or off the winch spool. The winch can now be controlled through the use of the Winch In/Out lever.





- c. The 15,000 lb, 20,000 lb, and 30,000 lb. PNEUMATIC WINCH CONTROL has two positions.
- **RELEASE** In this position, the winch is disengaged and air tension (if present) is released from the cable. Allow up to 15 seconds for release of air tension. The cable can then "free-wheel". The cable may need to be slackened to allow winch to disengage.

#### **IMPORTANT**

WHEN REELING WINCH, MOMENTARILY RO-TATE REEL IN OPPOSITE DIRECTION TO RE-LIEVE TENSION ON WINCH GEARS. THIS WILL AID IN WINCH RELEASE.

**TENSION** In this position, the winch is engaged and cable can be "power" spooled in or out. The winch is now controlled by the Winch Hydraulic Lever. Winch air tensioner will also be engaged, if present.

- d. The 12,000 lb, 15,000 lb, or 20,000 lb WINCH AIR TENSION or pressure on the cable is controlled by an air pressure regulator located behind the main control panel. It is set at 60 psi but can be adjusted, if desired, for more or less tension.
  - 1. To adjust, turn the regulator adjusting knob. Clockwise rotation increases and counterclockwise rotation decreases tension.
  - 2. When reducing from a higher to a lower setting, first reduce to some pressure less than that desired, then bring up to the desired point.
- 3. Push lockring on adjusting knob downward to lock pressure setting. To release, push lockring upward. Free spool tension is applied by adjustable spring load on the cable. Free spool tension can be adjusted, if desired, for more or less free spool tension.
- e. The **30,000 lb WINCH AIR TENSION** or pressure on the cable is controlled at system air pressure for operation. An air pressure regulator located behind the main control panel is used to reduce air pressure and cable tension during free spool. It is set at 60 psi, but can be adjusted, if desired, for more or less free spool tension. For adjustment procedure, see **Section 3-14.2 d.1. through 3.**
- f. Once the winch is selected, winch operation is the same as described in **Section 3-14.1**.

#### IMPORTANT

REMOTE CONTROL OPERATION IS DE-SCRIBED IN SECTION 3-20.

### **3-15 DOCK LEVELER OPERATION**

### 

1. WHEN USING DOCK LEVELER, THE SEMITRAILER MUST BE KEPT LEVEL AT ALL TIMES. DO NOT LOWER THE PARKING STANDS. LOADS BEING PLACED ON THE SEMITRAILER MUST BE KEPT CENTERED ON THE SEMI-TRAILER. AN UNLEVEL SEMITRAILER MAY ALLOW A LOAD TO SLIDE, CAUS-ING INJURY OR DEATH TO ANYONE NEAR THE LOAD.

2. DO NOT OPERATE DOCK LEVEL-ERS WITH INSUFFICIENT SPACE ON BOTH SIDES OF THE SEMITRAILER. PERSONS OR EQUIPMENT CAN BE CRUSHED BETWEEN SEMITRAILER SIDE AND RIGID OBJECTS.

3. TRACTOR PARK BRAKES MUST BE SET WHEN USING DOCK LEVELERS.

3-15.1 Dock loading is achieved with the TAIL/AXLE CONTROL LEVER and DOCK LIFT ARM CONTROL BUTTON (Manual) /SWITCH (Remote) located on the control panel (See Figure 3-3).

#### **IMPORTANT**

THE TAIL/AXLE CONTROL LEVER IS USED FOR BOTH LOADING/UNLOADING AND DOCK LEVELER OPERATIONS. SEE SECTION 3-9 FOR USE OF THE TAIL CONTROL LEVER IN LOADING/UNLOADING APPLICATIONS.

- **3-15.2** The **TAIL/AXLE CONTROL LEVER** has three positions:
- **DOWN/** LOAD In this position, the undercarriage slides forward to allow engaging of dock level.

**CENTER** This is the neutral position.

UP/ROAD In this position, in conjunction with dock level arm engaged, slide undercarriage rearward lifting approach plate to dock height.




Figure 3-7 Dock Leveler Operation




Figure 3-8 Air Activated Upper Deck Ramp (Optional)

- **3-15.3** The DOCK LIFT ARM CONTROL BUT-TON/SWITCH has two positions:
- **ENGAGE** In this position, the dock level arm lifts the approach plate to dock height.
- **DISENGAGE** This is the neutral position for the dock level arm.
- **3-15.4** Park the semitrailer in front of dock according to instructions in **Section 3-7**.
- **3-15.5** Engage hydraulic power supply.
- 3-15.6 Use TAIL/AXLE CONTROL LEVER to pull undercarriage forward approximately 30" (See Figure 3-7).
- 3-15.7 Engage DOCK LIFT ARM CONTROL BUTTON/SWITCH and hold while using TAIL/AXLE CONTROL LEVER to return undercarriage rearward to obtain dock height.
- **3-15.8** Switch air ride suspension to lower (on) position, stabilizing trailer while loading or unloading at dock.

## 

WHEN USING THE DOCK LEVEL, MAKE SURE THE DOCK LEVEL ARM IS SUPPORTING THE HYDRAULIC TAIL BEFORE PULLING AWAY FROM THE DOCK. FAILURE TO DO SO MAY RE-SULT IN DAMAGE TO THE TRAILER OR SEVERE PERSONAL INJURY.

- **3-15.9** To return to transport position, switch air ride suspension to transport (off) position.
- **3-15.10** Using **TAIL/AXLE CONTROL LEVER**, pull undercarriage forward approximately 30". This returns tail deck height and disengages dock level arm.
- **3-15.11** Return undercarriage to transport position, using **TAIL/AXLE CONTROL LEVER**, until hydraulic system works against the fully extended hydraulic axle cylinder.
- **3-15.12** Shut off the hydraulic power.

#### 3-16 AIR ACTIVATED UPPER DECK RAMP (OPTION)

**3-16.1 To raise ramp,** push ramp activation button (in). Hold button until ramp raises past ramp support latches. Release button allowing ramp to settle upon ramp supports (See Figure 3-8).

### CAUTION

RAISED RAMP MAXIMUM CAPACITIES 5,000 LB WHEEL LOAD/ 10,000 LB TO-TAL.

**3-16.2 To lower ramp,** push ramp activation button (in). Hold until ramp raises off ramp supports. While holding ramp palm button, rotate ramp support handle to release position. Now release ramp palm button to allow ramp to settle down to normal deck position (See Figure 3-8).



#### 3-17 HYDRAULIC POWER SUPPLY ENGINE OPERATION (OPTION)

**3-17.1** The Hydraulic Power Supply Engine system is used to power the hydraulic functions, should the tractor not be equipped with hydraulic hookups.

#### **IMPORTANT**

1. CHECK THE FOLLOWING FLUID LEVELS BE-FORE STARTING THE ENGINE PACKAGE: EN-GINE OIL, FUEL SUPPLY, HYDRAULIC OIL.

2. IF THE ENGINE DOES NOT CRANK, CHECK THE FOLLOWING ON THE BATTERY: CHARGE, FLUID, TERMINALS, AND CABLES. TAKE COR-RECTIVE ACTIONS AS NEEDED.

### 

IF THE HYDRAULIC FLUID LEVEL IS LOW DURING OPERATION, THE SEMI-TRAILER MAY NOT OPERATE COR-RECTLY, RESULTING IN DAMAGE TO THE SEMITRAILER.

- **3-17.2** The **ENGINE IGNITION SWITCH** is located below the hydraulic controls, and ahead of them on the driver's side of the semitrailer. Use the key to start and stop the Hydraulic Power Supply Engine. (See Figure 3-9). This switch has three positions:
- **OFF** In this position, the power package engine does not run. The key can only be inserted or removed from this position.

**RUN** In this position, the engine runs without activating the starter.

- **START** In this position, the starter cranks the power package engine, to start it. After the engine is started, release the key to the RUN position.
- **3-17.3** The **HYDRAULIC POWER SUPPLY ENGINE CHOKE (See Figure 3-9)** is located to the right of the Engine Ignition Switch on the driver's side of the semitrailer. The purpose of the Choke is to aid the starting procedure.




Figure 3-9 Hydraulic Engine Package Control Panel

IN This is normal operating position.

- **OUT** Set the choke in this position as an aid to start the engine. Once the engine is started, push in the choke fully.
- 3-17.4 The HYDRAULIC POWER SUPPLY ENGINE THROTTLE is located to the right of the choke on the driver's side of the semitrailer. The Engine Throttle controls the speed at which the engine operates (See Figure 3-9). It is a variable position control:
- **FULL OUT** In this position, the engine throttle is fully open, letting it run at full speed.
- **FULL IN** In this position, the engine throttle is closed, letting the engine run at a slow idle.

### 

DO NOT CRANK ENGINE FOR MORE THAN 10 SECONDS. IF ENGINE DOES NOT START, CONSULT THE OWNER'S MANUAL SUPPLIED WITH THE EN-GINE.

#### 3-18 AIR RIDE OPERATION

- **3-18.1** Trailer air pressure must be maintained above 90 PSI before operating. PROTEC-TION VALVES are used to maintain 65 PSI air brake pressure during suspension or remote system air loss.
- **3-18.2** The Model 900 Series tandem and triple axle semitrailer is equipped with a ride control valve located on the rear axle.

### CAUTION

INSURE SUSPENSION AIR BAGS ARE INFLATED ON ALL AXLES WHEN MOV-ING UNDERCARRIAGE FROM LOAD TO TRANSPORT POSITION. FAILURE TO DO SO CAN CAUSE EXCESSIVE TIRE WEAR.

- **3-17.5** To start, pull the choke completely out and set the throttle to the MEDIUM IDLE position.
- **3-17.6** Turn the ignition key to the START position. The engine should crank and then start.
- **3-17.7** When the engine starts, release the key. Gradually push the choke lever in until the engine runs smoothly.

#### IMPORTANT

BLACK SMOKE FROM THE EXHAUST AND A ROUGH RUNNING ENGINE USUALLY INDICATE OVER-CHOKING.

- **3-17.8** To adjust the speed, turn the throttle control in or out, as needed, until the engine runs smoothly at a speed capable of withstanding use of the hydraulic controls. The hydraulic controls should now be functional.
- **3-17.9** Before shutting it off, allow the engine to cool down by running at a slow idle for thirty seconds.
- **3-17.10** Once the engine is cool, turn or push the throttle and choke control completely in and turn the key to the OFF position.

### CAUTION

IF SUSPENSION AIR LOSS SHOULD OCCUR, COMPLETELY DEFLATE SUS-PENSION AND TEMPORARILY OPER-ATE ON THE AIR SPRINGS INTERNAL RUBBER BUMPERS. CAREFULLY PROCEED TO THE NEAREST SEMI-TRAILER SERVICE FACILITY. TO DE-FLATE THE AIR SUSPENSION, DIS-CONNECT THE LOWER CONNECTION ON THE LINKAGE OF THE AUTOMATIC AIR VALVES. ROTATE THE VALVE CONTROL ARMS DOWN ABOUT 45° TO EXHAUST THE AIR. TO RESTORE TO NORMAL OPERATION, SIMPLY RE-VERSE THE PROCEDURE.

#### 3-19 BULKHEAD (OPTION)

3-19.1 Optional bulkheads may come with or without chain racks or bulkhead extensions. To remove a bulkhead, disconnect the electrical harness (if work lights are present), remove the cotter pins and link pins holding the bulkhead into the pockets on the semitrailer front and bolts and nuts attaching the bulkhead extensions and supports to the deck, and lift the bulkhead off (See Figure 3-10).

### 

TO AVOID SERIOUS INJURY, ALL RE-MOVABLE ATTACHMENTS MUST BE FIRMLY ATTACHED WITH FASTENERS PROVIDED AT ALL TIMES.




Figure 3-10 Bulkhead

#### 3-20 REMOTE CONTROL (OPTION)

- **3-20.1** The wired remote control plugs into an electrical receptacle usually located on the hydraulic control panel. Optional receptacle locations are on the rear street side or both rear street and rear curb sides. The wired remote is available as a single, dual, or triple function.
- **3-20.2** A wireless radio remote control is also available as a dual, triple, or quadruple function.
- **3-20.3** The single function wired remote operates the WINCH HYDRAULIC LEVER (See Section 3-14.1).
- **3-20.4** The dual function wired remote operates the winch in/out and winch tension: or the tail and dock level.
  - a. The selector switch at the top of the remote box selects the function to be operated (WINCH HYDRAULIC and WINCH TEN-SIONER, or TAIL CONTROL and DOCK LEVEL ARM ).
  - b. The two buttons will function like the control levers for the WINCH HYDRAULIC (See Section 3-14.1), WINCH TENSIONER (See Section 3-14.2), TAIL CONTROL (See Section 3-9,) or DOCK LEVEL ARM (See Section 3-15.3).

- **3-20.5** The triple function wired remote operates the winch in/out, tail, and either the dock level or winch tension.
  - a. There are three switches which function like the control levers for the WINCH HYDRAU-LIC (See Section 3-14.1), TAIL CONTROL (See Section 3-9), DOCK LEVEL ARM (See Section 3-15.3), or WINCH TENSIONER (See Section 3-14.2).
- **3-20.6** A wireless radio remote control is a triple function (See Figure 3-11).
- **3-20.7** The remote operates any of the hydraulic functions that are desired. The remote components are connected to the hydraulic valve section that the remote is desired to operate. The electrical switches operate the functions of the hydraulic spool valve instead of operating the control levers on the valve.

#### IMPORTANT

ON WINCHES WITH THE AIR TENSION OPTION, THE WINCH TENSION IS ENGAGED AUTO-MATICALLY WHEN THE SWITCH IS TURNED TO WINCH IN/OUT. THE WINCH TENSION SWITCH ON EITHER THE REMOTE OR THE CONTROL PANEL MUST BE USED TO DISEN-GAGE THE WINCH.




Figure 3-11 Radio Remote Control




Figure 3-12 Rear Impact Guard and Anti-lock Brake System

## 3-21 REAR IMPACT GUARD SYSTEM

Vehicle standard FMVSS No. 224, Rear Impact Protection, requires all 900 Series trailers manufactured after January 26, 1998 shall be equipped with a rear impact guard certified by the manufacturer as meeting FMVSS No. 223, Rear Impact Guards. The guard, or bumper, **(See Figure 3-12)**, meets the following requirements:

- minimum of 4 inches vertical height
- extend laterally to within 4 inches of the sides of the trailer
- ground clearance of no more than 22 inches
- placed no more than 12 inches from the rear of the trailer.
- capable to deflect 5 inches.

The standard also specifies minimum force and energy absorption requirements for the guard. A DOT decal certifies that the guard meets FMVSS No. 223 and 224 standards. The decal is placed **and must remain at all times** on the forward facing surface of the guard, 12 inches inboard of the curb side and of the guard. **See Figure 3-12** for location of decals.

Replace any component that does not allow the above minimum requirements to be met. Any hardware that holds the rear impact guard and becomes damaged or becomes loose shall be removed and replaced. The 3/4" grade 8 screws that hold the bumper energy pack shall be loctited and torqued to 280 ft.-lbs.

# 

ALWAYS CHECK THE CONDITION OF THE REAR IMPACT GUARD SYSTEM. IF GUARD SYSTEM HAS BEEN DAM-AGED, IT MUST BE REPLACED. FAIL-URE TO MAINTAIN GUARD SYSTEM MAY RESULT IN INJURY OR DEATH TO OTHERS.

#### 3-22 ANTI-LOCK BRAKE SYSTEM (ABS)

Vehicle standard FMVSS No. 121, anti-lock brake system requires all trailers manufactured after March 1, 1998 with air brake systems to have ABS. Each trailer (including a trailer converter dolly) shall be equipped with an anti-lock brake system that controls the wheels of at least one axle of the trailer. Wheels on other axles of the trailer may be indirectly controlled by the anti-lock brake system.

NHTSA Docket 92-29; notice 11 published September 23, 1996 specifies the ABS warning light be mounted near the rear of the left side of the trailer (See Figure 3-12).

- Decal or lens marking with ABS to identify the lamp.
- The lamp must illuminate one time whenever power is supplied to the ABS. At any time the light remains on when power is supplied there is a malfunction to the system.

The ABS used on the semitrailer is a commercial unit. Single axle trailers use a two sensor, one modulator system. Tandem and triple axle semitrailers use a four sensor, two modulator system. Sensors are located at each hub of the front and rear axles, and each modulator controls one side of the trailer.

The ABS is constant powered by the auxiliary (blue) circuit, center pin on the semitrailer seven way electrical connector. This circuit must be hot whenever the tractor keyswitch is on. This circuit must also not be used to power any additional electrical devices while the semitrailer is moving forward. However, additional devices such as remote controls may be powered from the auxiliary circuit while the semitrailer is stationary. Back up power to the ABS is supplied through the stop lamp (red) circuit, No. 4 pin on the seven way connector, and ground is supplied by the white wire, No. 1 pin.

# 

THE AUXILIARY (BLUE) CIRCUIT IS FOR POWERING THE SEMITRAILER ABS. THIS CIRCUIT MUST BE HOT WHEN THE TRACTOR KEY SWITCH IS ON. NO OTHER ELECTRICAL DEVICES MAY BE POWERED BY THIS CIRCUIT WHILE THE SEMITRAILER IS MOVING FORWARD.

Malfunction in the ABS is signaled by illumination of the ABS warning lamp located at the streetside rear of the semitrailer. The warning lamp will come on and stay on while power is supplied to the ABS on a moving vehicle, if there is a fault. If a fault in the ABS exists, normal braking will still occur, but wheels may lock. The semitrailer is still operable, but the system should be serviced as soon as possible.

## 3-23 COLD WEATHER OPERATION

- **3-23.1** Cold weather causes lubricants to congeal, insulation and rubber parts to become hard, which may lead to problems found in bearings, electrical systems, and air systems. Moisture attracted by warm parts can condense, collect and freeze to immobilize equipment. The truck/semitrailer operator must always be alert for indicators of cold weather malfunctions.
- **3-23.2** During any extended stop period, neither the service nor parking brake should be used as they can freeze up. Use wheel chocks to secure the vehicle from moving.

# 

IF A FAULT EXISTS IN THE SEMI-TRAILER ABS, NORMAL BRAKING WILL OCCUR, BUT WHEELS MAY LOCK. SERVICE THE ABS AS SOON AS POSSIBLE.

The ABS is also equipped with a **Blink Code Diagnostic Tool** mounted at the curbside bumper arm of the undercarriage. This tool is used to identify faults that may occur in the ABS so that they may be repaired.

Refer to ABS maintenance manual supplied with semitrailer to answer basic questions for the anti-lock brake system, obtain outline procedures on how to adjust, test, remove, and install ABS components, as well as how to test for faults in the system by using **"Blink Code Diagnostics"**; and illustrates ABS components, wiring, and plumbing installation diagrams.

- **3-23.3** Check all structural fasteners, air system fittings, gaskets, seals and bearings for looseness that can develop due to contraction with cold. Do not over-tighten.
- **3-23.4** Check tire inflation. Tire inflation decreases when the temperature decreases.
- **3-23.5** Periodically check drain holes in the bottom of the relay valve (for trailers with air brakes) and storage compartments. They must be open at all times to avoid moisture entrapment.

## **3-24 HOT WEATHER OPERATION**

- **3-24.1** Hot weather operation can create certain problems which must be checked. Expansion of parts result in tightening of bearings, fasteners, and moving parts. Failure of gaskets or seals can occur.
- **3-24.2** The semitrailer should be parked in the shade if possible. Long exposure to the sun will shorten service life of rubber components (i.e., tires, light and hose grommets, hoses, etc.) and paint life.
- **3-24.3** Check tire pressure early in the day before beginning operations while the tire is cool. Replace all valve stem caps after checking.
- **3-24.4** If the area is extremely humid, protect electrical terminals with ignition insulation spray. Coat paint and bare metal surfaces with an appropriate protective sealer.
- **3-24.5** The use of a filter-lubricator in the towing vehicle's air delivery system is recommended.

This section contains instructions necessary for proper maintenance of the semitrailer. The 900B Series semitrailer is designed for years of service with minimal maintenance. However, proper maintenance is important for durability and safe operation and is an owner/user responsibility.

## 4-1 MAINTENANCE SCHEDULE

Trailer maintenance includes periodic inspection and lubrication. **Table 4-2**, Maintenance Schedule, lists the recommended maintenance and lubrication tasks by time interval and by accumulated mileage (use whichever occurs first). **Table 4-3**, Hydraulic Engine Maintenance Schedule, lists the recommended maintenance tasks for the hydraulic engine package.

# 

OPERATING THE TRACTOR OR TRAILER WITH DEFECTIVE, BROKEN OR MISSING PARTS MAY RESULT IN SERIOUS INJURY OR DEATH, DAM-AGE TO THE TRACTOR/TRAILER, ITS CARGO, OR PROPERTY IN ITS PATH.

#### 4-1.1 Inspection

a. Inspect the tractor, the trailer, and trailer parts periodically for damage or signs of pending failure. Damaged or broken parts must be repaired or replaced at once. Determine the cause of any binding or hydraulic leakage at once. Correct the problem before using the tractor or trailer. **b.** Use the troubleshooting section, Chapter 5 to check for "SYMPTOMS" and "PROBLEMS" of any trailer system not functioning correctly, or where wear, distortion, or breakage are found. Administer "REMEDY" according to the right-hand column of the troubleshooting section.

#### 4-1.2 Lubrication

**Figures 4-1 and 4-2 and Table 4-1** detail lubrication points and intervals, method of application, and lubricant required, and illustrate the location of each part to be lubricated. During inspections of the trailer, if lubricants are found to be fouled with dirt or sand, those parts should be cleaned with paint thinner, dried, and relubricated immediately. Dirt in a lubricant forms an abrasive compound that will wear parts rapidly.

# 

PAINT THINNER AND OTHER SOL-VENTS ARE FLAMMABLE AND TOXIC TO EYES, THE SKIN, AND RESPIRA-TORY TRACT. AVOID SKIN AND EYE CONTACT. GOOD GENERAL VENTILA-TION IS NORMALLY ADEQUATE. KEEP AWAY FROM OPEN FLAMES OR OTHER COMBUSTIBLE ITEMS.




Figure 4-1 Lubrication Points (1 of 2)




Figure 4-2 Lubrication Points (2 of 2)

LUBE	SEASON	BRAND AND PRODUCT (WEIGHT AND/OR TYPE)			
		AMOCO	EXXON	PHILLIPS	TEXACO
1	ALL YEAR	Rycon MV	HDX Plus 10W	Magnus Oil A KV 5W-20	Rando HD-AZ
2	SUMMER	Permagear EP 460 SAE 140	Spartan 460 SAE 140	Phil Gear Lube 460 SAE 140	Meropa 460 SAE 140
2	WINTER	Permagear EP 220 SAE 90	Spartan 220 SAE 90	Phil Gear Lube 220 SAE 90	Meropa 220 SAE 90
3	ALL YEAR	Lit-Multi-purpose Grease	Ronex Multi-purpose Grease	Phil Lube M.W. Grease	MarFax All Purpose
4	ALL YEAR	Industrial Oil 32	Estic 32	Condor 32 or Magnus 32	Regal Oil R&O 32
5	ALL YEAR	Gear Lube SAE 80W-90	Gear Oil GX SAE 80W-90	Superior MP Gear Oil SAE 80W-90	Multi-gear EP SAE 80W-90
	ABOVE 0 <sup>0</sup> F	Ultimate Gold 10W-30, 10W-40	SuperFlow 10W-30, 10W-40	Tropartic 10W-30, 10W-40	Havoline 10W-30, 10W-40
6	BELOW 32º F	Ultimate Gold 5W-20, 5W-30	SuperFlow 5W-20, 5W-30	Tropartic 5W-20, 5W-30	Havoline 5W-20, 5W-30

#### 4-2.1 Repair Parts

Repair parts are illustrated and listed in a separate parts manual. Replacement of parts due to wear is determined by examination and measurement in the Maintenance Procedures of this section.

#### 4-2.2 Tools and Equipment

Tools, equipment, and personnel normally found in a facility capable of making truck repairs will be adequate for maintenance of the semitrailer. No other special tools or equipment should be necessary.

#### 4-2.3 Torque Values

**Tables 2-1 and 2-2** list torque values for standard hardware and hydraulic fittings. They are intended as a guide for average applications involving typical stresses and mechanical surfaces. Values are based on the physical limitations of clean, plated, and lubricated hardware. In all cases, when an individual torque value is specified, it takes priority over values given in this table. Replace original fasteners with hardware of equal grade.

#### 4-2.4 Cleaning

- **a.** Wash semitrailer to remove all accumulated dirt and grime.
- **b.** Use any mineral spirits paint thinner (or its equivalent) to remove grease and oil from all parts of the trailer. Rinse degreasing solution off with cold water.
- **c.** Inspect semitrailer for cause of any reported troubles.

# 

PAINT THINNER AND OTHER SOL-VENTS ARE FLAMMABLE AND TOXIC TO EYES, SKIN, AND RESPIRATORY TRACT. AVOID SKIN AND EYE CON-TACT. GOOD GENERAL VENTILATION IS NORMALLY ADEQUATE. KEEP AWAY FROM OPEN FLAMES OR OTHER COMBUSTIBLE ITEMS.

- **d.** Scrape, sand, prime, and repaint areas where finish is missing or where there is evidence of corrosion.
- e. Replace any missing or illegible decals. Replace any missing or damaged reflective tape.
- f. Use Troubleshooting Guide to check for "SYMPTOMS" AND "PROBLEMS" of any semitrailer system not functioning correctly, or where wear, distortion, or breakage can be found. Administer "REMEDY" according to right-hand column of Troubleshooting guide.
- **g.** After disassembling any components, thoroughly clean dirt and old lubricant from all parts. Do not use a wire brush on any bearing parts or surfaces — use a stiff bristle brush. Do not use compressed air, or spin bearing parts when cleaning. These practices can throw solvents, dirt, or metal particles into your eyes. Dry clean parts with lint free, clean, soft, absorbent, cloth or paper. Wash and dry hands.
- **h.** Inspect seals, seal wiping surfaces, bearing caps, and bearing cones for wear, pitting, chipping, or other damage.

NORMAL OPERATING SERVICE INTERVALS <sup>a</sup>								
SERVICE INTERVAL :	TIMES	1st 5 Hrs	Weekly	Monthly	6 Months	Yearly	LUBE #	NOTES
ITEM							ГC	ž
	MILES	50	500	2,000	12,000	25,000		
LIGHTS		I	I					
WIRING & CONNECT	IONS	Ι		I				
FASTENERS		Ι, Τ		I				b
KING PIN AND PLAT	E	Ι		C,I,L			3	с
BRAKE AIR SYSTEM		Ι	I	I				
RELAY VALVES						I, C		
BRAKE ADJ & WEAR		Ι		Ι, Τ				d
SLACK ADJUSTERS		Ι	I		L		3	с
CAMSHAFT ASSYS		Ι	I			L	3	с
HUB OIL		Ι	I, L			R	5	с
WHEEL BEARINGS		Ι			Ι, Τ		5	с
TIRE INFLATION & W	/EAR	Ι	I					е
WHEEL LUG NUTS		Ι, Τ	I	Ι, Τ				f
SUSPENSION ALIGN	MENT	Ι		I				
AIR RIDE SUSPENSI	ON			I,T		I,T		
FRAME AND U/C RO	LLERS			L				с
HYDRAULIC OIL		Ι	I			R	1	с
HYDRAULIC FILTER		R			R			
HOSES (Inspect & Replace as needed)		Ι		I		I,R		
WINCH GEAR CASE		I		I			2	с
PLASTIC WEAR STRIPS		Ι		I	С		3	g
WINCH CABLE ASSEMBLIES		Ι		I,L			4	c, h
I – Inspect, R – Repl	I – Inspect, R – Replace, T– Tighten/ Adjust Torque, L – Lubricate, C – Clean							
NOTES:								

Table 4-2 900B Series Maintenance Schedule

ENGINE MAINTENANCE SCHEDULE				
OPERATION			H CYCLE D HOUR	
	8	25	100	200
FILL FUEL TANK	Х			
CHECK OIL LEVEL	Х			
CHECK AIR CLEANER FOR DIRTY, LOOSE, OR DAMAGED PARTS	Х*			
CHECK AIR INTAKE AND COOLING AREAS, CLEAN AS NECESSARY	Х*			
SERVICE PRECLEANER ELEMENT		Х*		
SERVICE AIR CLEANER ELEMENT			X*	
CHANGE OIL			Х	
CHECK SPARK PLUG CONDITION AND GAP			Х	
REMOVE COOLING SHROUDS AND CLEAN COOLING AREAS			x	
CHANGE OIL FILTER				Х
NOTE: *PERFORM THESE MAINTENANCE PROCEDURES MOR DUSTY, DIRTY CONDITIONS.	E FREQU	ENTLY U	INDER EX	TREMELY

# WARNING

BREATHING EXHAUST GASES CAN RESULT IN SEVERE PERSONAL INJURY OR DEATH. DO NOT USE AIR CLEANER, EXHAUST ELBOW, OR CONNECTING PARTS AS A SUPPORTING STEP. DAMAGE TO THESE AND CONNECTING PARTS CAN CAUSE AN EXHAUST LEAK.

#### 4-3.1 Repairing Structural Defects

If any structural defect is found, the fault must be corrected before further use of the vehicle. To continue usage could endanger the trailer, its load, personnel, traffic, and properties. If any cracks or breaks are found, contact the Landoll factory for repairs. Inspect the deck daily for broken or missing planks or missing attachments. Replace any defective parts promptly.

## 4-4 HYDRAULIC SYSTEM

#### 4-4.1 General

- a. Check the oil level of the tractor wet kit or hydraulic engine power hydraulic tank weekly, or after any leakage. See Table 4-1 for proper hydraulic oil. Check the hydraulic oil level with the undercarriage cylinder in the retracted position and the hydraulic pump disengaged.
- **b.** Overfilling can cause hydraulic fluid overflow during operation.
- **c.** Hydraulic system pressure relief valves should be set at 2500 psi.

#### 4-4.2 Hydraulic Engine Package

- **a.** Check the hydraulic oil level weekly, or after any leakage. **See Table 4-1** for proper hydraulic oil. Check oil level with the undercarriage cylinder in the retracted position and with the engine stopped.
- **b.** Check hoses weekly for cracks or leaks. If a valve or line leaks, it should be replaced immediately.
- **c.** Check the engine oil each time before using. Oil level should be maintained between the "L" and "F" marks on the oil dip stick. For further maintenance procedures and proper lubrication specifications, please refer to the engine owners manual that was supplied with the hydraulic engine package.
- **d.** Replace hydraulic filter with new filter at least every 6 months or more often under adverse conditions.
- **e.** Use the fuel recommended for the engine package installed on your semitrailer.

## 4-5 ELECTRICAL SYSTEM

- **4-5.1** Maintenance of the electrical system consists of inspection and minor servicing. Any wire, connection or electrical component showing signs of corrosion, wear, breakage or unraveling must be repaired or replaced. (See Figures 4-3 through 4-5 for electrical wiring diagrams and Table 4-4 for wiring parts list).
- **4-5.2** Frayed or unraveling wire must have the defective section removed and replaced with wire of the same color and gauge. Seal all connections and insulate.
- **4-5.3** Corroded terminals must have the corrosion removed, source of corrosion neutralized and the terminals resealed, protected, and insulated.

#### **4-6 SUSPENSION MAINTENANCE**

#### 4-6.1 Air Ride Suspension

- a. See Figure 4-6 for Tandem/Triple Axle Air Ride Suspension drawing
- **b.** Physically check all nuts, bolts, and air line fittings for proper torque (see torque chart below).

AIR SUSPENSION TORQUE CHART				
Size	1-1/8"-7	1/2"-13	*3/4"-16	3/4"-10
Torque in Ft. Lbs.	800	35	35	150

\* Air Spring Connections Only.

**c.** Check all other suspension components for any sign of damage, looseness, wear or cracks.

- **4-5.4** Fuse or circuit breaker burn-out or blow-out usually indicates an electrical short-circuit, although a fuse can occasion-ally fail from vibration. Insert a second fuse or reset the breaker. If this fuse immediately burns out or the breaker trips, locate the cause of the electrical short and repair.
- **4-5.5** A light that repeatedly burns-out usually indicates a loose connection, poor system ground, or a malfunctioning voltage regulator. Locate the source of the problem and repair. System grounds must be grounded to bare metal surfaces. Paint, grease, wax, and other coatings act as insulators. Replacement lamps must be equivalent to the factory installed lamp.
  - **d.** With trailer on level surface and air pressure in excess of 65 psi, all air springs should be of equal firmness. The height control valve on street side of rear axle controls all air springs on tandem and triple axle suspensions.
- 4-6.2 Air Ride Height Adjustment. (See Figure 4-7 for parts identification).
  - **a.** Before adjusting, the vehicle must be empty with the kingpin at operating height and have air supplied to the trailer.
  - **b.** Disconnect linkage at the control arm and raise control arm to the "up" position, raising the trailer until a block can be placed between axle tube and undercarriage frame (See Figure 4-7).
  - **c.** Position the wood block between the axle tube and frame according to table below. Block height is dependent upon suspension ride height and/or axle brake size.




Figure 4-3 900B Series Wiring Diagram

900B	SERIES WIRING PARTS LIST	900B	SERIES WIRING PARTS LIST
REF. DES.	FUNCTION	REF. DES.	FUNCTION
DS1	FRONT LEFT CLEARANCE, YELLOW	J4	BUMPER CONNECTOR
DS2	FRONT RIGHT CLEARANCE, YELLOW	J5	ABS LAMP CONNECTOR
DS3	FRONT LEFT MARKER, YELLOW	J6	BULKHEAD EXTENSION
DS3 DS4	FRONT RIGHT MARKER, YELLOW	J7	BULKHEAD WORK LIGHTS
DS4 DS5	LEFT SLOPE MARKER, YELLOW	J8	REMOTE, FRONT
DS5 DS6	RIGHT SLOPE MARKER, YELLOW	J9	REMOTE, STREET REAR
DS0 DS7	LEFT SIDE MARKER/TURN, YELLOW	J10	REMOTE, CURB REAR
		J11	ABS ECU VALVE CONNECTOR
DS8	RIGHT SIDE MARKER/TURN, YELLOW	L1	WINCH OUT
DS9	MID-LEFT SIDE MARKER, YELLOW	L2	WINCH IN
DS10	MID-RIGHT SIDE MARKER, YELLOW	L3	RAMP
DS11	LEFT REAR SIDE MARKER, RED	L4	LIFT ARM
DS12	RIGHT REAR SIDE MARKER, RED	L5	TAIL UP
DS13	LEFT STOP/TAIL, RED	L6	TAIL DOWN
DS14	RIGHT STOP/TAIL, RED	S1	WORK LIGHT
DS15	LEFT TURN/TAIL, RED	S2	IN-UP-LOAD-ENGAGE
DS16	RIGHT TURN/TAIL, RED	S3	OUT-DOWN-TRANSPORT-RELEASE
DS17	LEFT STOP/TAIL, RED	S4	SELECTOR SWITCH
DS18	RIGHT STOP/TAIL, RED	S5	IN-OUT
DS19	LICENSE PLATE LIGHT, RED	S6	UP/DOWN-ENGAGE/RELEASE
DS20	IDENTIFICATION RIGHT, RED	S7	LOAD/TRANSPORT-UP/DOWN
DS21	IDENTIFICATION LEFT, RED	S8	TENSION ENGAGE/RELEASE
DS22	IDENTIFICATION CENTER, RED	TB1	PRIMARY JUNCTION BOX
DS23	CONTROL PANEL LIGHT	TB2	ACCESSORY JUNCTION BOX
DS24	BULKHEAD WORK LIGHT, LEFT	TB3	ACCESSORY JUNCTION BOX
DS25	BULKHEAD WORK LIGHT, RIGHT	100	
DS26	ABS MALFUNCTION INDICATOR, YELLOW		
J1	FRONT MAIN CONNECTOR		
J2	E-CHAIN CONNECTOR		
J3	U/C CONNECTOR		

Table 4-4 900B Series Wiring Parts List





Figure 4-4 Remote Control Diagram








Figure 4-6 Tandem/Triple Axle Air Ride Suspension




Figure 4-7 Air Ride Height Adjustment

AIR SUSPENSION RIDE HEIGHT AND BLOCK			
Brake Size	Ride Height	Block Height	
12-1/4" Dia.	6"	3.5"	

- **d.** Lower the trailer by exhausting air from the air springs by moving the control arm to the "down" position (about 45°) until the axle tube is resting on the block.
- e. Check the ride height to make sure it is correct. Consult Landoll Service Center if correct height cannot be obtained.
- f. Loosen the 1/4" adjusting lock nut located on the adjusting block, allowing the control arm to move approximately 1 inch. Move the adjusting block until holes align, then insert locating pin (See Figure 4-7).
- **g.** Align the control arm linkage to the control arm lower bracket and re-tighten the 1/4" adjusting lock nut to 2-4 ft. lbs. The ride height valve should now be correctly adjusted.
- h. Remove the locating pin.

## 4-7 ALIGNMENT

#### 4-7.1 Wheel Alignment

## 

TO PREVENT A LIFE THREATENING ACCIDENT:

1. SUPPORT TRAILER AND UNDER-CARRIAGE SO TIRES ARE OFF THE GROUND.

2. SUPPORT THE TRAILER AND UN-DERCARRIAGE ON JACK STANDS WITH SUFFICIENT CAPACITY TO SUP-PORT THE TOTAL WEIGHT OF THE TRAILER AND ANY LOAD WHICH IT MAY BE CARRYING.


- i. The block can now be removed by using the height control valve as an improvised jack by disconnecting the control arm at the lower bracket and pushing the control arm to an "up" position.
- **j.** Remove the block and reconnect the linkage. This allows the Automatic Height Control Valve to resume normal operation.
- **k.** Check the air ride height. If necessary, go through the adjustment procedure again until the proper air ride height is achieved.
- I. Check the air ride height periodically and adjust as needed.

## CAUTION

INSURE SUSPENSION AIR SPRINGS ARE INFLATED ON ALL AXLES. FAIL-URE TO DO SO CAN CAUSE EXCES-SIVE TIRE WEAR.

When trailer tires show signs of scuffing, feather-edging or uneven wear, examine the trailer for damaged suspension (frame, shocks, linkage, etc.), axle, wheel bearings and wheels. Proper wheel alignment and wheel bearing adjustment is essential for proper tire wear. The simplest form of checking wheel alignment "toe" is by running the trailer over a "SCUFF GAUGE". A scuff gauge reading of 16 feet or less per mile is considered satisfactory. If a scuff gauge is not readily available, or edge wear on one side of a tire is occurring signifying positive or negative camber, alignment can be checked as follows:

- **a.** Remove wheel, hub and bearing assemblies.
- b. Place a 3-point axle gauge against the front side of the axle, and adjust each axle gauge point to the axle. (Double point end against the inner and outer wheel bearing surfaces of the spindle being checked and the other point on the inner bearing surface on the other spindle) (See Figure 4-8).






- c. Move the axle gauge and place against the back side of the axle. If either of the points of double point end fails to touch the axle surface, a bent spindle is evident. A point gap of .015" or more is considered excessive tire "toe" and the axle must be replaced (See Figure 4-8).
- d. Follow the same procedures as in Section 4-7.1 b. and c., except place the axle gauge above and below the axle. If gauge point gap is found, the axle has positive or negative camber. The trailer axle has no camber from the factory. If it is found to have positive or negative camber, axle replacement is necessary (See Figure 4-10 for examples of camber).

#### 4-7.2 Axle Alignment


Proper axle to king pin alignment is necessary to obtain straight tracking. If axle alignment is off, "dog-tracking" occurs. Check alignment manually or by using a semitrailer alignment machine. In either case, a thorough inspection of the complete suspension must be performed and all defects corrected before aligning.

#### a. Manual Alignment Procedure

- 1. Position semitrailer on a firm and level surface. Insure that the undercarriage is in the rear most position. Eliminate any suspension binding due to sharp turns or unusual maneuvers.
- 2. Detach tractor from the semitrailer and jack the trailer up sufficiently to permit measuring from the underside of the trailer.
- **3.** Suspend a plumb bob at axle height from the center of the king pin.
- 4. Measure (D) from the plumb bob to the center point on one end of the axle. Record this measurement (See Figure 4-9).
- 5. Measure (D1) to the other end of the axle in the same manner as in Step 4. Record this measurement (See Figure 4-9).
- 6. Set D about 1/8" shorter than D1 to insure proper trailer tracking on slope of road.
- **7.** Align the rear axle to the front axle. The rear axle should be parallel with the front axle, with the dimensions Y and Y1 being the same.
- **8.** Follow the same procedure as described above for a triple axle semitrailer.
- 9. The suspensions must be in good repair with no binding or other restrictions before aligning. All defective parts of the suspension or axles must be replaced immediately.









#### b. Air Ride Suspension Axles

The air ride suspension is aligned and adjusted at the factory and it should not be necessary to align the axles. If, however it does become necessary to align the axles, the procedure is as follows:

- To align air ride suspension axles, locate the front axle equalizer beam pivot bolt in front hanger at front end of lock nut. Loosen the suspension pivot bolt lock nut. Rotate the head of the pivot bolt. For axle alignment forward, rotate bolt head clockwise. For axle alignment rearward, rotate the bolt head counter-clockwise. Both sides of axle need to be adjusted to prevent axle rise or fall.
- 2. Align the front axle using the method outlined in Section 4-7.2 a.

- 3. After proper alignment has been obtained, tighten the suspension pivot bolt nut to the torque listed in the table in **Section 4-6.1 b**.
- 4. Align the rear axle to the front axle. Locate the rear axle equalizer beam pivot bolt in hanger at front end of driver's side rear axle equalizer beam. Loosen the suspension pivot bolt lock nut. Rotate the head of the pivot bolt. For axle alignment forward, rotate bolt head clockwise. For axle alignment rearward, rotate the bolt head counter-clockwise. The rear axle should be parallel with the front axle, with the dimensions Y and Y1 being the same.
- 5. Tighten the suspension pivot bolt nut to the torgue listed in the table in Section 4-6.1 b.

# **WARNING**

1. WHEN CRAWLING UNDER THE SEMITRAILER IS NECESSARY, CHOCK ALL WHEELS OF THE TRAILER AND TRACTOR. WHEN JACKING IS NECES-SARY, CHOCK ALL WHEELS AND SUPPORT THE SEMITRAILER UNDER-CARRIAGE WITH JACK STANDS SUF-FICIENT TO WITHSTAND THE WEIGHT OF THE SEMITRAILER AND LOAD. FAILURE TO TAKE ADEQUATE SAFETY MEASURES MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH.

2. USE GREAT CARE IF WHEELS OR BRAKE DRUMS MUST BE HANDLED. THEY MAY BE VERY HOT AND CAN CAUSE SERIOUS BURNS.

#### 4-8.1 General

A daily general inspection will reveal the most common problems found in the spring brake system. This inspection should include the following:

- **a.** Check air hoses for chafing, bends, kinks, or damaged fittings. Replace defective hoses.
- **b.** Check the brake system for loose, missing, deformed, or corroded fasteners. Replace and tighten defective hardware.
- **c.** Check brake linings for excessive wear or distortion.
- d. Drain air reservoir daily. A drain cock on the bottom of each air reservoir vents the tank to drain collected water and oil. If held open, air pressure in the tanks is relieved, causing the emergency or parking brakes to be applied (See Figure 4-11).

#### 4-8.2 Spring Air Brake Chambers

Check for faulty units. Check the condensation holes on the underside of the brake chambers to make sure they are open. The spring brake has two brake chambers, a service chamber and an emergency chamber or spring chamber. Service brake chambers should be disassembled and cleaned at 50,000 miles or yearly. The diaphragm and any marginal parts should be replaced. When replacing the service diaphragm, replace the corresponding parts for the other chamber on the same axle (to aid in even brake application and release). Examine yoke pin for wear and replace as necessary. The spring chamber should not be serviced. Replace entire unit (both service and spring chamber) if spring chamber becomes faulty.

# 

THE SPRING BRAKE CHAMBER EM-PLOYS A SPRING WITH HIGH FORCES. SERVICE SHOULD NOT BE ATTEMPTED. SERIOUS INJURY OR DEATH MAY RESULT.




Figure 4-11 Drain Cock Locations

#### a. Caging the Power Spring

- **1.** Chock the trailer wheels.
- 2. Remove dust cap from spring brake chamber.
- 3. Remove the release bolt from it's holding brackets and insert it into the spring brake chamber. DO NOT USE AN IMPACT WRENCH TO CAGE THE SPRING BRAKE.
- **4.** Turn the bolt until the spring brake is caged. This should be 2-1/4 to 2-1/2 inches of release bolt extension.
- 5. The brakes should now be totally released. Do not operate loaded trailer with brake manually released.
- 6. To reset the spring brake, turn the release bolt until the spring is released. Remove the release bolt and store it in its brackets.
- 7. Snap the dust cap back in place on the chamber.

#### b. Removal

- **1.** Chock all tractor and trailer wheels and drain the air system.
- **2.** Mark the brake chamber for proper air line port alignment for reassembly.
- 3. CAGE THE POWER SPRING following the steps outlined in Section 4-8.2a.
- Disconnect the slack adjuster from the connecting rod by removing the clevis pin (See Figure 4-14).
- **5.** Mark all air service lines for proper reinstallation and disconnect from the brake chamber.
- **6.** Remove the brake chamber from the axle brackets.

#### c. Installation

- 1. CAGE THE POWER SPRING following the steps outlined in Section 4-8.2a.
- 2. Position the inlet ports by loosening the service chamber clamp bands and rotating center housing such that ports are located according to alignment marks made during disassembly, then retighten the clamp bands.

- **3.** Position the breather hole in the downward facing position by loosening the clamp bands on the spring brake chamber and rotating the chamber housing until the breather hole faces downward. Retighten the clamp bands.
- 4. Remount the brake chamber on the axle brackets and reconnect the air service hoses and the slack adjuster connecting rod (See Figure 4-14).

### IMPORTANT

#### BE SURE THE SERVICE LINE IS ON THE SERV-ICE CHAMBER PORT AND THE EMERGENCY LINE IS ON THE SPRING BRAKE PORT.


- 5. Check for leakage by charging the air system to a minimum of 90 psi and applying soap suds to the brake chamber and connections. If a growing bubble is detected or bubbles are blown away, locate the source of the leak and repair.
  - 6. Insure that the clamp band is properly seated and tight **before** uncaging the power spring.

#### 4-8.3 Emergency Relay Valve Maintenance

Every 3600 operating hours, 100,000 miles, or yearly, the Emergency Relay Valve should be disassembled, cleaned, and lubricated by a trained technician.

# WARNING

REPAIR OR REPLACEMENT OF THE RELAY/EMERGENCY VALVE IS A COM-PLEX OPERATION AND SHOULD BE PERFORMED BY TRAINED SERVICE PERSONNEL. CONTACT A LANDOLL AUTHORIZED SERVICE CENTER OR THE LANDOLL FACTORY FOR SERVIC-ING.





#### 4-8.4 Brake Assembly Maintenance

The brake assemblies should be inspected and adjusted every 2,000 miles or monthly. Examine the brake linings visually to locate the lining showing the greatest amount of wear. The wheel and drum should be removed and the linings replaced if the thinnest portion of the lining is 3/8 in. (9.5 mm) or less. Do not allow the linings to wear thin enough that the lining rivet contacts the drum (See Figure 4-12). Lubricate brake assembly per Figures 4-1 and 4-2, Lubrication Points and Table 4-2, Maintenance Schedule.

# 

DO NOT ALLOW GREASE TO CON-TACT BRAKE LININGS AS THIS COULD RESULT IN REDUCED BRAK-ING PERFORMANCE.

#### a. Brake Adjustment

This semitrailer is equipped with automatic slack adjusters which compensate for brake lining wear and keep brakes adjusted. Brakes should not be adjusted manually except when relining brakes.

- b. Disassembly for 12-1/4" X 7-1/2" Brakes (See Figure 4-13)
  - 1. Block and secure trailer on adequate capacity jack stands. Check that the wheel and drum rotate freely.
  - 2. Release brakes and back off slack adjuster.
  - 3. Remove wheel equipment (See Figure 4-13).
  - 4. Lift top shoe upward to disengage the shoe webs from the anchor pin. Remove anchor pin.
  - 5. Repeat previous step for the bottom shoe.

- 6. Remove brake keeper springs.
- Unwrap bottom shoe by pivoting the shoe on the camshaft head and twisting the shoe 90<sup>o</sup> under the spindle. Remove shoe assemblies from spider.
- 8. Remove slack adjuster lock ring, disconnect slack clevis, and then remove slack adjuster.
- **9.** Remove camshaft lock ring, spacer washer(s), and camshaft.
- **10.** Completely inspect all brake components, servicing as necessary.
- c. Reassembly for 12-1/4" X 7-1/2" Brakes (See Figure 4-13)
  - 1. Install new camshaft bushing and seals into the spider.

#### IMPORTANT

WHEN INSTALLING CAMSHAFT SEALS, THE SEAL ON THE SLACK ADJUSTER SIDE IS IN-STALLED FACING INTO SPIDER. THIS AL-LOWS GREASE TO PURGE OUTSIDE THE BRAKE ASSEMBLY WHEN GREASING THE CAMSHAFT BUSHING.

2. Install cam roller assemblies onto the brake shoes.

#### **IMPORTANT**

THE HEAD OF ROLLER PIN SHOULD FACE THE CAMSHAFT "D" WASHER ONCE SHOES ARE INSTALLED ON SPIDER.

- **3.** Install "D" shaped camshaft washer onto the camshaft.
- 4. Install the camshaft into the spider. Install spacer washer and lock ring retainer on camshaft before sliding the camshaft through the camshaft support bracket.




Figure 4-13 Axle and Brake Assembly

- **5.** Install the slack adjuster, washer and lock ring retainer.
- 6. Lubricate cam roller notches with lubricant prior to installing cam roller assemblies onto the brake shoes. Bend roller retainer lop down so that retainer will be at same level as the shoe table and will not interfere with the brake drum during the life of the lining blocks.
- 7. Install "w" shaped retractor spring retainer pin into the 1/2" diameter shoe web holes near the camshaft roller end of the shoe.
- 8. Install retractor spring between shoes. Place top shoe onto spider as in service. Pivot bottom shoe on the camshaft head and twist the shoe 90o under the spindle, properly placing shoe on the spider as in service.

#### **IMPORTANT**

# ALWAYS USE ALL NEW SPRINGS WHEN SERVICING BRAKES.

- **9.** Install two keeper springs on the anchor end of the shoes.
- **10.** Lubricate anchor pin bores and shoe anchor pins with lubricant.
- **11.** Repeat previous step for bottom shoe.
- **12.** Lift top shoe upwards to clear anchor pin hole. Install anchor pin.
- **13.** Connect slack adjuster to brake chamber pushrod.
- 14. Lubricate cam bushings and slack adjuster.
- **15.** Reinstall wheel equipment per manufacturers instructions.
- **16.** Adjust automatic slack adjuster as outlined in **Section 4-8.5 c.**
- d. Disassembly for 16-1/2" x 7" Brakes (See Figure 4-13)
  - 1. Release brake and back off slack adjuster.
  - 2. Remove slack adjuster lock ring and slack adjuster.
  - 3. Remove brake drum.
  - **4.** Disengage the roller retainers from the rollers.

- 5. Press down on the bottom brake shoe and remove the lower cam roller. Lift the top shoe and take out the top cam roller.
- **6.** Lift out the shoe retractor spring, which is now free of tension.
- Swing the lower shoe back approximately 180° to relieve the tension on the shoe keeper springs. Remove the springs and slip the shoes off the anchor pins.
- 8. Remove camshaft lock ring, spacer washer(s), and camshaft.
- **9.** After removing the shoes, completely inspect all brake components, servicing as necessary.
- e. Reassembly for 16-1/2" x 7" Brakes (See Figure 4-13)
  - 1. Install new anchor pin bushings, camshaft bushing, and camshaft seals into the spider.

## IMPORTANT

WHEN INSTALLING CAMSHAFT SEALS, THE SEAL ON THE SLACK ADJUSTER SIDE IS IN-STALLED FACING INTO SPIDER. THIS AL-LOWS GREASE TO PURGE OUTSIDE THE BRAKE ASSEMBLY WHEN GREASING THE CAMSHAFT BUSHING.

- **2.** Install cam roller, retainer clip, and retractor spring retainers onto the brake shoes.
- **3.** Install 1/8" thick camshaft washer onto the camshaft.
- 4. Install the cam shaft into the spider. Install spacer washer and lock ring retainer on camshaft before sliding the camshaft through the camshaft support bracket. Install the slack adjuster, washer, and lock ring retainer.
- 5. Install the brake keeper springs onto the shoes. Install shoes onto the spider by placing shoes in place on the anchor pins, then "wrap" the two shoes into place about the spider.
- **6.** Install the shoe retractor spring onto the shoes.
- 7. Connect slack adjuster to brake chamber pushrod.
- **8.** Adjust brake as outlined in brake adjustment procedures.




Figure 4-14 Slack Adjuster

#### 4-8.5 Automatic Slack Adjuster

The semitrailer automatic slack adjusters provide the means for routine brake adjustment to compensate for lining wear. Inspect slack adjusters every 2,000 miles to assure correct operation.

# 

THE INSTALLATION GUIDE MUST BE USED WHEN INSTALLING OR REIN-STALLING AUTOMATIC SLACK AD-JUSTER. FAILURE TO DO SO MAY RE-SULT IN IMPROPERLY ADJUSTED BRAKES WHICH MAY CAUSE BRAKE DAMAGE OR LEAD TO BRAKE FAIL-URE.

- a. Operational Check (See Figure 4-14)
  - **1.** Block wheels to prevent vehicle from rolling.
  - **2.** Check that the push rod is fully retracted, apply air to release spring brake.

- Turn adjustment hex counterclockwise to create an excessive clearance condition. (A ratcheting sound will occur.)
- 4. Make a full service brake application. On release, allow sufficient time for brake to fully retract. During the brake release, observe rotation of the adjustment hex (attach a wrench on the hex to make this movement easier to see). This rotation indicates that an excessive clearance condition has been determined by the slack adjuster, and it is making an adjustment to compensate. On each subsequent brake release the amount of adjustment and push rod travel will be reduced until the desired clearance is achieved
- **5.** The push rod stroke should be 1 1/2" to 2" with a 90 PSI service brake application.
- 6. Measure the movement of the push rod from the completely released position to the applied position by marking the push rod where it exits the air chamber before and after application.
- **7.** If the brakes have been running tight, the control arm location should be checked.

# 

IF THE ADJUSTER APPEARS NOT TO BE OPERATING, CHECK THE OTHER BRAKE COMPONENTS FOR PROPER FUNCTION AND ELIMINATE ANY BIND-ING. RECHECK THE AUTOMATIC SLACK ADJUSTER. IF THE ADJUSTER IS NOT FUNCTIONING, THE UNIT MUST BE REPLACED BECAUSE FAILURE OF PROPER ADJUSTMENT FUNCTION WILL RESULT IN LOSS OF BRAKES.

- b. Replacing Slack Adjuster (See Figure 4-14)
  - Chock wheels to prevent vehicle from rolling. Release spring and service brake. Air chamber push rod must be fully released.
  - To maintain a fully released parking brake, a 90 - 100 psi reservoir pressure must be maintained. If air pressure is not available the spring brake must be manually caged.
  - 3. Remove the existing slack adjuster and clevis DO NOT REMOVE EXISTING JAM NUT.
  - Install the new clevis (with 1/2" pin) onto the push rod up to the jam nut -DO NOT TIGHTEN JAM NUT.
  - **5.** Fit the installation guide over the cam splines so the 1/2" pin slots face the air chamber.
  - **6.** Swing the guide into the clevis until the appropriate slot totally engages 1/2" pin.
  - 7. Observe the guide pointer arrow: If the guide pointer is above the clevis

pointer, adjust clevis **CCW** for alignment. If the guide pointer is below the clevis pointer, adjust clevis **CW** for alignment.

- **8.** Reposition clevis until the guide pointer aligns with the clevis pointer.
- **9.** Verify by engaging 1/4" pin through the clevis and guide.
- **10.** Tighten jam nut to 50 ft.-lbs. torque min.
- **11.** Remove the guide from cam shaft.
- **12.** If the push rod threads extend through the clevis more than 1/16", remove clevis and cut rod to length.
- **13.** If the push rod is not fully engaged in clevis body, install a new push rod cut to length.
- 14. Install the slack adjuster on the cam shaft.
- **15.** Rotate the manual adjuster shaft **CW** until the slack adjuster arm holes align with the clevis. Install 1/2" and 1/4" pins and cotter pins.
- c. Adjusting Slack Adjuster
  - **1.** Rotate the manual adjuster clockwise until brake shoes contact drum.
  - 2. Back off manual adjuster 1/2 turn. (counterclockwise)
  - **3.** Manually uncage the spring brake.
  - **4.** Build up vehicle air pressure.
  - 5. Fully apply and release the brakes several times to check for adequate clearance to all adjacent components.
  - 6. Measure the distance from air chamber to 1/2" pin. Apply brakes with 80 90 psi air pressure and remeasure distance to 1/2" pins.
  - 7. The stroke (difference of these two measurements) must be less than 2 inches.




Figure 4-15 Outboard Mount Hub and Drum

## 4-9 HUB AND DRUM MAINTENANCE

- **4-9.1** Clean and inspect the brake drums whenever relining the brakes. To be suitable for further service, the brake drum should pass the following checks.
  - a. The brake surface should be free of scoring, excessive heat checks and cracks.
  - **b.** The brake surface diameter should be within the maximum diameter cast or stamped on the drum.
  - **c.** The mounting holes and pilot must be round and true.
  - **d.** The mounting surface must be clean and flat.

# WARNING

FAILURE TO REPLACE FAULTY BRAKE DRUMS WILL RESULT IN AN UNRELIABLE BRAKING SYSTEM, AND MAY LEAD TO AN ACCIDENT.

- **4-9.2** It may be necessary to turn or resurface the braking surface to remove small heat checks or other surface defects resulting from normal use.
  - **a.** The maximum diameter cast into the back plate portion of the brake drum is the maximum diameter or discard diameter to which the brake drum may be turned or worn and still be usable. If any portion of the brake surface exceeds the maximum diameter it must be discarded. The maximum is .120 over the nominal new diameter unless stated otherwise on the casting. The maximum diameter cast into the brake drum supersedes all published information.
  - **b.** When resurfacing a drum, allow at least 0.040 inches under the maximum diameter for additional wear.

# 

TURNING A BRAKE DRUM BEYOND 0.040 INCHES UNDER THE MAXIMUM DIAMETER WILL RESULT IN A WEAKER BRAKE DRUM AND MAY RE-SULT IN AN ACCIDENT.

- **4-9.3** Replacement of the brake drum is required if any of the following conditions exist:
  - **a.** The brake drum is cracked.
  - **b.** The brake surface is heat checked, grooved or worn beyond the rebore limit or the maximum diameter.
  - c. The back plate is cracked.
  - **d.** The bolt holes are elongated.
  - e. The brake drum has been severely overheated.
  - f. The brake drum is out-of-round.

# 

REPLACE BRAKE DRUMS IN PAIRS TO ACHIEVE THE SAME BRAKING POWER ON BOTH WHEELS AND MAIN-TAIN AN EVEN BRAKING LOAD ON THE AXLE. FAILURE TO DO THIS MAY SIGNIFICANTLY REDUCE THE PER-FORMANCE, SERVICE LIFE, AND/OR SAFETY OF YOUR VEHICLE.

**4-9.4** For aluminum wheels, often a separator plate is used (See Figure 4-19). The separator plate is approximately .040" thick. It is placed between the drum and the wheel, or between two wheels in dual applications. The separator plate is recommended in severe applications where corrosion and/or wear have been identified. Aluminum wheels benefit from use of the separator plate. Care must be exercised in centering the separator plate prior to torquing, and stud length must be checked as each plate is approximately .040" thick.

- 4-9.5 Replace the hub and drum as follows (See Figure 4-15):
  - a. Remove the brake drum (See Figure 4-15). It may be necessary to release the slack adjuster.
  - **b.** Remove hub cap and catch lubricant in a pan.
  - **c.** Remove outer spindle nut, spindle locking washer, inner spindle nut, and bearing. Remove hub from axle.
  - **d.** Using an appropriate driver, remove inner bearing cone, and seal.
  - **e.** Using an appropriate driver, remove bearing cups from hub.
  - **f.** Check that the hub cavity is clean. If the hub is to be reused, clean it thoroughly.
  - g. Insert bearing cups into the hub.
  - **h.** Clean the mounting surfaces with a good grade commercial cleaner and soft rag. Dry all component parts with a clean, absorbent cloth or paper. Lubricant will not adhere to surfaces wet with solvent.
  - i. Install inner bearing, cone, and seal.

#### IMPORTANT

# DO NOT MIX NEW CUPS WITH OLD CONES OR NEW CONES WITH OLD CUPS.

- j. Place the hub or wheel over the axle spindle being careful to align the hub bore with the axle. Do not damage the seal. Support the hub assembly until the outer bearing cone and spindle nut are installed, to avoid damaging the seal.
- **k.** Install the outer bearing cone and inner spindle nut, tightening the nut until it is snug against the outer bearing cone. Remove the hub support allowing the hub to rest on the bearings.
- I. Install and adjust bearings (See Section 4-10).
- **m.** Install the hub cap with the proper gasket. Tighten the cap screws of the hub cap to 15 to 20 ft-lbs. of torque.
- **n.** Remove the filler plug and fill the hub cavity to the recommended level with a gear type oil.
- **o.** Place the drum over the hub and brake shoes being careful not to damage the threads on the studs. Make sure the drum seats flat against the hub flange and mates properly with the hub pilot. There should be no interference between the brake drum pilot chamfer and the corner radius on the hub. If interference exists, the hub will not be able to function properly.

## 4-10 WHEEL BEARING LUBRICATION AND ADJUSTMENT

With semitrailer sitting level, the oil level must be checked daily and maintained between the "ADD" and "FULL" lines on the hub cap window. Check for cracked windows, missing filler plugs, and oil leaks. Add hub oil through the "POP-IN" filler plug located in the center of the hub windows. Re-install the "POP-IN" plugs after filling each hub. Adjust wheel bearings and change oil every 50,000 miles or with each brake lining replacement, which ever occurs first.

#### 4-10.1 Adjustment


- **a.** With a drain pan under the hub cap, remove the hub cap assembly allowing oil to drain.
- **b.** Lift the wheel off of the ground.
- **c.** Adjust slack adjuster to eliminate brake drag during tire/wheel rotation.
- **d.** Remove outer lock nut and inner nut and lock washer.
- e. Tighten the inner adjustment nut to a minimum of 75 ft.-lbs., while rotating wheel to insure proper seating of the bearings and cups in the wheel hub.
- f. Loosen the inner adjustment nut so that the wheel will turn freely.
- **g.** Retighten the inner adjustment nut to 50 ft.-lbs. while rotating the wheel, to properly position the bearings for the final adjustment.

- **h.** Loosen the inner adjustment nut 1/3 turn.
- i. Install the spindle nut lock washer so that the dowel on the inner nut will align with a hole in the lock washer and the washer tang fits in the spindle keyway.
- **j.** Install the outer lock nut and tighten to 250-300 ft.-lbs. End-play of .001" to .010" must be present in the adjusted wheel bearing assembly.

# 

FAILURE TO TORQUE THE OUTER LOCK NUT PROPERLY COULD CAUSE THE WHEEL TO COME OFF DURING VEHICLE OPERATION RESULTING IN PROPERTY DAMAGE OR LOSS OF LIFE.

- **k.** Install the hub cap with a new gasket and fill with oil to the full mark (See Table 4-1).
- I. Adjust brakes according to Section 4-8.4 a.
- **m.** Check hub oil level after the wheel has set level in one position for a few minutes to allow the oil to work into the bearings.



## 4-11 TIRE MAINTENANCE

- 4-11.1 Tire Inflation. Tire inflation will cause tire to ground contact characteristics as shown in Figure 4-16. Tire inflation should be checked daily while the tire is cold, and during road stops. Checking the tire pressures while tires are hot will give a faulty increased pressure reading. Adjusting tire air pressure to the specified amount while tires are hot will produce improper tire to road contact and thus abnormal wear. Do not exceed cold inflation pressure listed on the semitrailer VIN plate located on the front of the trailer. Exceeding cold inflation pressure will result in damaged tire bodies, rims, and wheels. Replace all valve stem caps when pressure checking/adjusting has been completed. Remove any foreign objects from between duals.
- **4-11.2 Tire Matching**. Both tires on the same spindle must be the same size in order to properly distribute the load and braking forces between them. The tire must be mounted on a rim and properly inflated before measuring. If there is an allowable difference in size the smaller tire should be mounted to the inside position of the duals.
  - **a.** Tape Measuring Method: Measure around each tire on the tread surface. A maximum difference of 3/4" is allowed between the two mating tires of a dual (See Figure 4-17).
  - **b.** Straight Edge or String Method: (This method cannot be used if tire and wheel assemblies are not mounted on the axle.) Jack trailer up until the wheels are off of the ground. Hold a straight edge against the tires of both ends of an axle. A gap at one tire indicates a smaller tire. A maximum of 1/8" gap is allowed (See Figure 4-18).




Figure 4-17 Measuring Tape Method

Figure 4-18 Straight Edge Method




Figure 4-19 Mounting Tires and Wheels

#### 4-11.3 Mounting Tire and Wheel (Hub Type)

- a. Make sure that all mounting surfaces are clean and free of rust, dirt or paint. A wire brush may be used to clean these surfaces (See Figure 4-19).
  - **b.** Position the inner disc wheel over the studs, being careful not to damage the stud threads. Make sure that the disc wheel is flat against the mounting surface and that there is clearance between the disc wheel taper and brake drum.




Figure 4-20 Stud Tightening Sequence

- **c.** Position the outer disc wheel being careful not to damage the threads. Be sure the valve stems for both the inner and outer tire are accessible.
- d. Install the flange nut and tighten to 50 foot-pounds using the sequence in Figure 4-20. Then tighten to full torque of 450 to 500 foot-pounds.
- **e.** Torque will drop after the first 50 to 100 miles of operation. Check the nuts for proper torque after this interval and retighten them.

# 

USE A TORQUE WRENCH TO ASSURE PROPER TORQUE. INSUFFICIENT TORQUE CAN CAUSE STUD BREAK-AGE AND DAMAGE WHEEL PILOTS. OVERTORQUE CAN OVERSTRESS THE STUDS AND STRIP THE THREADS.

## 4-12 WINCHES

Inspect the winch cable before and after every usage. If frayed wires, nicks, kinks, worn spots, breaks or any other sign of deterioration or damage is found, immediate replacement is mandatory before further usage. If the semitrailer is going to be out in the weather for any length of time, it is advisable to oil the winch cable to prevent untimely rusting and deterioration of the cable. **See Table 4-1** for lubrication specifications.

Inspect the winch mechanism thoroughly each week to insure safe, efficient operation.

# WARNING

DO NOT HANDLE THE WINCH CABLE WHEN THE WINCH IS IN THE ENGAGE POSITION. HANDS OR CLOTHING COULD GET CAUGHT IN THE CABLE AND BE PULLED INTO THE SPOOL CAUSING SERIOUS PERSONAL IN-JURY.

## 4-13 CRANK LANDING GEAR (SEE FIGURE 4-21)

- **4-13.1** The landing gear receives adequate lubrication during manufacturing. Relubrication is possible through grease fittings and is recommended at three month intervals.
- **4-13.2** The elevating screw is lubricated by the lower grease fitting located on the upper housing. Prior to lubrication, extend the landing gear as far as possible. During lubrication, slowly retract the landing gear. The upper grease fitting lubricates the gearing, shafts, and bushings. It is recommended to use a high quality commercial grade lithium EP-2 grease.

#### **IMPORTANT**

SHIFT CRANKSHAFT INWARD INTO HIGH GEAR BEFORE LUBRICATING THE UPPER GREASE FITTING. **4-13.3** When inspecting the landing gear, any parts which are subjected to wear or damage, must be checked and replaced if worn or damaged. The inspection and maintenance intervals must be decreased if the trailer is operated under arduous transport conditions.

#### 4-13.4 Repair Instructions

- **a.** In order to repair landing gear, the legs should be taken off the trailer by removing the mounting attachment bolts and cross shaft.
- **b.** For two speed leg assembly, remove cover by removing cover screws.

#### **IMPORTANT**

THE COVER IS SEALED TO THE UPPER HOUS-ING WITH A SILICONE SEALANT. WHEN RE-PLACING THE COVER A SUITABLE SILICONE SEALANT MUST BE USED. DOW CORNING #700 OR EQUAL IS RECOMMENDED.

- **c.** Remove grease before disassembly. Drive spiral pins from output spur gear and input gear.
- **d.** Then drive out output shaft by placing a punch through hole in output spur gear and driving the shaft out. Now both items can be removed.




Figure 4-21 Crank Landing Gear Assembly

e. Remove cap plug. Shift input gear shaft to the high gear position. Then drive out roll pin with a 3/8" diameter punch, by using the .50 dia hole at the side of the shaft in the outer housing.

#### **IMPORTANT**

#### FOR TWO SPEED LEG ASSEMBLIES WITHOUT THE SIDE ACCESS HOLE, USE A CURVED 3/8" DIA PUNCH.

- f. Remove output cluster shaft.
- **g.** Shift input gear shaft to the low gear position. Position mark on end of input gear shaft in a vertical position. Remove locknuts from shift housing. Pull out the input gear shaft and shift housing as one unit.
- h. Remove bevel gear and output cluster gear by lifting upwards on both parts at the same time. Remove groove pin and thrust washer. Lift outer housing off from inner leg assembly.
- i. Remove thrust bearing and collar.

#### IMPORTANT

THRUST BEARING MUST BE EXCHANGED COMPLETE WITH COLLAR. NEW THRUST BEARING MUST BE PACKED WITH GREASE BEFORE ASSEMBLY.

#### IMPORTANT

IF ELEVATING SCREW SHOWS SIGN OF WEAR, REPLACE LOWER LEG ASSEMBLY BE-FORE MOUNTING. MAKE SURE ELEVATING SCREW AND NUT ARE SUFFICIENTLY GREASED. IF GREASE IS REQUIRED, COAT THE ENTIRE SURFACE OF THE SCREW WITH A MIN. OF 4 OZ. OF GREASE.

- **j.** If bushings are worn, they must be removed and replaced. Install bushings with a step driver and punch.
- **k.** Assemble shift housing and ball detent to input gear. Apply a thin film of lithium grease to the inside of the bushing before assembly. Reassemble by compressing balls and spring into hole in input gear. Then slide shift housing onto the shaft, capturing the detent balls and spring.

## TROUBLESHOOTING

Troubleshooting should be performed by a trained and competent technician. Landoll Corporation is not responsible for equipment that is improperly maintained. Contact an authorized Landoll Service center or the Landoll factory for servicing.

## 5-1 ELECTRICAL

Most electrical system problems show up as a burned out light or fuse, or inoperative electrical component. Wiring, grounds, or components may be at fault. Locate the symptom in this section that best identifies your electrical problem. Check out each possible problem under that symptom. If the problem cannot be located, see an automotive electrical specialist.

SYMPTOM NO LIGHTS	PROBLEM: REMEDYFuse blown: replace fuse.Connection at plug-in: tighten connection.Broken or corroded wires: replace wire.Ground wire loose: clean and tighten ground.
LIGHTS FLICKERING	<b>Wires shorted or loose:</b> locate, insulate, replace, or tighten. <b>Grounding through fifth wheel:</b> locate broken ground wire (tractor or semitrailer).
LIGHTS DIM	Voltage difference between semitrailer & tractor: match bulbs with tractor voltage. Grounding through fifth wheel: locate broken ground wire (tractor or semitrailer).
LIGHTS BRIGHT & BURN OUT	Voltage difference between semitrailer & tractor: match bulbs with tractor voltage.
FUSE BLOW-OUT OR CIRCUIT BREAKER TRIPPING	<b>Vibration:</b> locate source of vibration and repair. <b>Short circuit:</b> replace fuse and try all accessories. If fuse blows right away, locate short and repair.
LAMP BULB BURN OUT	<ul> <li>Vibration: locate source of vibration and repair.</li> <li>Short circuit: replace fuse and try all accessories. If fuse blows right away, locate short and repair.</li> <li>Loose connection: check lamp sockets and ground connections.</li> <li>Intermittent short: locate short and repair.</li> <li>Improper voltage: check voltage regulator output.</li> </ul>

## 5-2 TIRES - WHEELS - SUSPENSION

Most tire, wheel, and suspension related problems are due to excessive loads, extreme conditions, and improper maintenance. Tire, wheel, and suspension problems can be easily detected and solved by checking the following guide.

#### SYMPTOM

#### **PROBLEM: REMEDY** VIBRATIONS WHILE DRIVING Improper tire inflation: inflate to proper pressure. Tires cupped or have flat spots: replace tires. Wheels bent or loose: replace or tighten. Tires incorrectly mounted: remount. Mud in wheels: clean wheels. Tire(s) out of balance: balance tires. Brakes dragging: locate cause and repair. Object(s) stuck between duals: remove object(s). **RAPID TIRE WEAR/DETERIORA-**TION: CENTER TREAD WEAR Over inflation: deflate to correct inflation. SHOULDER TREAD WEAR -Under inflation: increase inflation to correct PSI. Check axle BOTH SHOULDERS alignment. **Overload:** loads are above rated tire capacity. DO NOT load above rated tire capacity. SHOULDER TREAD WEAR - ONE Axle damage: straighten or replace axle. SHOULDER Axles not parallel: check axle alignment. OVERALL TREAD WEAR Overloading: check tire load rating. High speeds: adjust speed according to road and load conditions. Incorrect dual matching: properly match dual tires. Front and rear axle suspension air bags not inflated: Adjust front and rear axle ride height control valves to proper settings. TIRE FLAT SPOTS Quick stops: adjust braking practices. Grabbing brakes: adjust brakes properly. Worn or loose wheel bearings: adjust or replace as needed. Out of balance wheels and tire: balance wheels and tires. Check ABS system function. Front and rear axle suspension air bags not inflated: Adjust front and rear axle ride height control valves to proper settings. **UNEVEN WEAR** Suspension bushings worn: replace bushings. Worn or loose wheel bearings: adjust or replace as needed. Out of balance wheels and tires: balance wheels and tires.

## TIRES - WHEELS - SUSPENSION (CONTINUED)

SYMPTOMS	PROBLEM: REMEDY
RIM FAILURE*:	
CRACKING *IN ALL INSTANCES OF RIM FAIL	Over inflated tires: deflate tire to proper PSI. High speeds: adjust speed according to road and load condi- tions. High speed cornering: adjust cornering practices. Over loading: check rim load rating. LURE, REPLACE THE RIM IMMEDIATELY!
BENDING OR WARPING	<b>Curb-hopping or potholes:</b> adjust turning practices and adjust speed accordingly with road conditions. <b>Improper tightening sequence:</b> follow proper tightening sequence.
BROKEN STUDS*	<b>Over tightening:</b> use correct torque when mounting.
*REPLACE BROKEN STUDS BEF	ORE USING THE SEMITRAILER!
SEMITRAILER TRACKING PROB- LEMS:	
TRACKS TO ONE SIDE	Axle alignment: re-align axle.
TRACKS TO EITHER SIDE	Broken or bent springs or equalizers: replace defective parts. Axles not parallel: realign axles
AIR RIDE HEIGHT PROBLEMS:	
TOO HIGH	Axle to control valve linkage: readjust linkage. Height Control Valve internal leak: repair or replace valve.
TOO LOW	<ul> <li>Axle to control valve linkage: readjust linkage.</li> <li>Height Control Valve filter plugged: clean or replace valve.</li> <li>Pressure Protection Valve filter plugged: clean or replace valve.</li> <li>System air pressure low (65 PSI minimum required): troubleshoot air supply.</li> </ul>
UNEVEN FROM SIDE TO SIDE	Linkage adjustment: readjust linkage. Exhaust port plugged: clean or replace valve(s). Height control valve internal leak: repair or replace valve. Supply line to one height control valve pinched, restricted, or plugged: repair or replace line.

SYMPTOM NO BRAKES OR BRAKES ARE INTERMITTENT	PROBLEM: REMEDY Brake air system improperly connected: reconnect hand valves properly. Relay/Emergency valve plugged: clean valve. Defective tractor protection valve: repair or replace. Restricted tubing or hose line: locate and eliminate restric- tion. Broken line: locate break and repair. Tractor air system failure: troubleshoot tractor air system and repair. Check ABS system function.
SINGLE BRAKE DRAGGING OR LOCKED	<ul> <li>Broken internal brake component: locate and replace broken part.</li> <li>Flat spot on cam roller or cam shaft: replace and lubricate.</li> <li>Improper adjustment: adjust slack adjusters.</li> <li>Spider bushing or cam bracket bushing binding: lubricate or replace bushing.</li> <li>Improper lubrication: lubricate</li> <li>Worn brake shoe bushing: replace bushing.</li> <li>Brake drum distortion: replace drum.</li> <li>Broken brake chamber spring: replace spring.</li> <li>Brake chamber pushrod binding: re-align brake chamber bracket.</li> <li>Air brake line loose or broken: tighten or repair.</li> </ul>
UNEVEN BRAKES	See "SINGLE BRAKE DRAGGING OR LOCKED" Restriction in hose: locate restriction and remove. Worn brake linings: reline brakes. Grease on linings: reline brakes. Broken slack adjuster: replace slack adjuster. Leaking brake chamber diaphragm: replace diaphragm.
BRAKES APPLY TOO SLOWLY	<ul> <li>Brakes need adjusting or lubrication: adjust or lubricate as needed.</li> <li>Low air pressure in brake system (below 90 PSI): check tractor air system.</li> <li>Restricted tubing or hose: locate restriction and remove.</li> <li>Defective relay valve: clean or replace.</li> <li>Call Factory or see qualified Trailer/Brake Technician</li> </ul>
BRAKES RELEASE TOO SLOWLY	<ul> <li>Brakes need adjusting or lubrication: adjust or lubricate as needed.</li> <li>Brake rigging binding: align brakes or replace bent parts.</li> <li>Exhaust port of relay valve restricted or plugged: clean valve.</li> <li>Tractor pressure too low: Adjust to provide 90 psi min.</li> </ul>

SYMPTOM ALL BRAKES DO NOT RELEASE	<ul> <li>PROBLEM: REMEDY</li> <li>Air system improperly connected to tractor: tighten or adjust connections.</li> <li>Brake valve on tractor is applied: release brake.</li> <li>Relay emergency valve in emergency position: check line pressure and check valve.</li> <li>Restricted tubing or line: locate restriction and remove.</li> <li>Defective tractor protection valve: troubleshoot tractor air system.</li> <li>Parking brakes locked: troubleshoot air system.</li> <li>Moisture in air system: Check air system</li> <li>Tractor pressure too low: Adjust to provide 90 psi min.</li> </ul>
INSUFFICIENT BRAKES	<ul> <li>Brakes need adjusting: adjust brakes.</li> <li>Brakes need lubricating: lubricate brakes.</li> <li>Brakes need relining: reline brakes.</li> <li>Low air pressure: troubleshoot air system.</li> <li>Defective relay emergency valve: repair or replace.</li> <li>Brakes overheated: stop and allow brakes to cool, locate cause of overheating.</li> </ul>
BRAKES GRABBING EXCESSIVE LEAKAGE WITH BRAKES RELEASED	Grease on brake linings: reline brakes. Brake rigging binding: align brakes or replace bent parts. Defective brake valve on tractor: repair or replace valve. Defective relay emergency valve: repair or replace valve. Relay emergency valve leaking: repair or replace valve. Leaking tubing or hose: replace defective part.
EXCESSIVE LEAKAGE WITH BRAKES APPLIED	Relay emergency valve leaking: repair or replace valve. Leaking brake chamber diaphragm: replace diaphragm. Call Factory or see qualified Trailer/Brake Technician Leaking tubing or hose: replace defective part.
EXCESSIVE LEAKAGE WITH EMERGENCY SYSTEM ONLY APPLIED - NO LEAKAGE WITH NORMAL BRAKING	Defective relay emergency valve: repair or replace valve.
EXCESSIVE WATER PRESENT IN BRAKE SYSTEM	Reservoir not drained often enough: drain reservoir daily.
EXCESSIVE OIL PRESENT IN BRAKE SYSTEM	Compressor on tractor passing excessive oil: repair compressor.
BRAKE WILL NOT APPLY PROPERLY	Flat spot on cam roller or camshaft: replace and lubricate.

## BRAKES (CONTINUED)

# SYMPTOMPROBLEM: REMEDYBRAKES WILL NOT APPLYDefective relay emergency valve: repair or replace valve.WHEN EMERGENCY LINE IS<br/>DISCONNECTEDBrake chamber defective: replace brake chamber.<br/>Broken internal brake component: locate and replace broken<br/>part.ABS WARNING LIGHT<br/>STAYS ONRefer to Rockwell WABCO ABS maintenance manual sup-<br/>plied with semitrailer, for system function and use of blink<br/>code diagnostics.

## 5-4 BRAKE DRUMS

#### SYMPTOM PROBLEM: REMEDY EXCESSIVE LOSS OF BRAKES Overheated brake drums: check for defective or misadjusted OR FADING brake linings, distorted or over-machined drums. Also check for operating conditions or loads that create severe or excessive brake applications. BRAKES PULL TO EITHER SIDE Drums of different diameters: replace with drums of same diameter. Foreign matter in drums: clean drums out. ROUGH OR NOISY BRAKING AC-Defective drums: pull drums and inspect for any of the follow-TION ing; Heat spotted drums, grease spotting, blue drums, scored drums, excessive wear at rivet holes or edges, polished drums, out of round drums, unbalanced drums, worn/damaged brake components, foreign matter in drums. Correct situation or replace defective part(s). **VIBRATION IN RIDE** Defective drums or out-of-round: replace drums. Out-of-balance drums: balance drums.

## 5-5 HYDRAULIC SYSTEM

SYMPTOM

Most hydraulic system failures follow the same pattern: a gradual or sudden loss of pressure or flow with a resulting loss of cylinder or motor power. Any one of the system's components may be at fault. By following step-by-step procedures, the trouble can be located in a short time.

**PROBLEM: REMEDY** 

#### SYSTEM INOPERATIVE Not enough oil in system: fill, check for leaks. Wrong oil in system: change oil, see specifications. Filter dirty or clogged: drain oil and replace filter. Hvdraulic lines dirty or collapsed: clean or replace as necessarv. Air leaks in pump suction line: repair or replace as necessary. Worn or dirty pump: clean, repair or replace. Check for contaminated oil. Drain and flush. Badly worn components: examine for internal leakage. Replace faulty components. Check for cause of wear. Leakage: check all components, and relief valve for proper settings. Excessive load: check unit specifications for load limits. Slipping or broken pump drive: repair or replace couplings. Check for alignment. SYSTEM OPERATES ERRATIC-Air in the system: check suction side of system for leaks. Re-ALLY pair leaks. **Cold oil:** allow ample warm-up time. Use proper weight oil for operating temperature. Dirty or damaged components: clean or repair as needed. Restriction in filters or lines: clean and/or replace filter or lines. Not enough oil in system: fill and check for leaks. SYSTEM OPERATES SLOWLY Oil viscosity too high, or "cold oil". Allow oil to warm up before operating. Low pump drive speed: increase engine speed (check pump owners manual for specifications). Low oil level: check reservoir and add oil as necessary. Air in system: check suction side for leaks. Repair leaks. Badly worn pump, valves, cylinders, etc.: repair or replace faulty component(s) as necessary. Restrictions in lines or filter: clean and/or replace filter or lines Improper adjustments: check orifices, relief valves, etc. Adjust as necessary. Oil leaks: tighten fittings. Replace seals, gaskets and damaged lines.

## HYDRAULIC SYSTEM (CONTINUED)

SYMPTOM SYSTEM OPERATES TOO FAST	PROBLEM: REMEDY Engine running too fast: reduce engine speed.
OVER HEATING OF OIL IN SYSTEM	<ul> <li>Oil passing through relief valve for excessive time: return control valve to neutral when not in use.</li> <li>Incorrect, low, dirty oil: use recommended oil. Fill reservoir with clean oil. Replace filter.</li> <li>Engine running too fast: reduce engine speed.</li> <li>Excessive component internal leakage: repair or replace component as necessary.</li> <li>Restriction in filters or lines: clean and/or replace filter or lines.</li> <li>Insufficient heat radiation: clean dirt and mud from reservoir and components.</li> <li>Malfunctioning component: repair or replace.</li> </ul>
FOAMING OF OIL	<ul> <li>Incorrect, low, or dirty oil: replace, clean or add oil as needed.</li> <li>Water in oil: replace oil</li> <li>Air leaks: check suction line and component seals for suction leaks. Replace defective parts.</li> </ul>
NOISY PUMP	<ul> <li>Low, incorrect, foamy oil: replace, clean, or add oil as needed.</li> <li>Suction line plugged: clean out obstruction or replace line.</li> <li>Flush system, replace filter.</li> <li>Pump damaged: repair or replace.</li> </ul>
LEAKY PUMP	<b>Damaged or worn shaft seal:</b> Replace seal and/or shaft and check for misalignment. <b>Loose or broken parts:</b> Tighten or replace.
CYLINDERS MOVE WITH CONTROL VALVE IN NEUTRAL POSITION	<ul> <li>Leaking cylinder seals or fittings: Replace worn seals or fittings.</li> <li>Control valve not centering when released: Check linkage for binding and repair.</li> <li>Valve damaged: Repair or replace.</li> </ul>
CONTROL VALVE LEAKS	Seals damaged or worn: Replace.
CYLINDER LEAKS	Seals worn or damaged: Replace. Rod damaged: Replace. Barrel damaged: Replace.
CYLINDERS DO NOT FUNCTION, OR CREEP WITH PTO DISENGAGED	Leaking fittings or cylinder seals: Tighten loose fittings. Replace worn seals or fittings. Piloted check valve or O-ring leak: Replace defective compo- nent.