

MODEL L20, L24, L40 & L50 SERIES TAG TRAILER OPERATOR'S MANUAL



1900 NORTH STREET MARYSVILLE, KANSAS 66508 (785) 562-5381



MODEL L20, L24, L40 & L50 SERIES TAG TRAILER OPERATOR'S MANUAL

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Landoll Manufacturing.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Landoll Manufacturing.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

In the event of a defect or problem with your LANDOLL equipment, please notify LANDOLL CORPORATION:

LANDOLL CORPORATION SALES AND SERVICE 1900 NORTH STREET MARYSVILLE, KANSAS 66508

OR PHONE: 1-800-HAULOLL (1-800-428-5655) FAX NO.: (785)562-3240 FOR REPLACEMENT PARTS: (785)562-4650 1-800-423-4320 FAX NO.: (785) 562-4654

TABLE OF CONTENTS

SECTION	TITLE	PAGE
1	INTRODUCTION	
2	STANDARD SPECIFICATIONS	
3	OPERATING INSTRUCTIONS	
3-1	GENERAL	3-1
3-2		3-1
3-3 2 A		
3-4 3-5	TOWING VEHICLE AND TRAILER HOOK-UP AND CHECK-OUT	⊼3-ວ ຊ_ຊ
3-6	TOWING THE TRAILER	3-3
3-7	PARKING THE TRAILER	
3-8	UNCOUPLING TOWING VEHICLE FROM TRAILER	
3-9	LOADING THE TRAILER	3-5
3-10	UNLOADING THE TRAILER	3-6
3-11	COLD WEATHER OPERATION	3-6
3-12		3-6
4	MAINTENANCE AND LUBRICATION	
4-1	GENERAL	4-1
4-2	MAINTENANCE SCHEDULE	4-1
4-3	MAINTENANCE PROCEDURES	4-2
4-4	FRAME AND DECKS	4-2
4-5		4-3
4-6		4.0
4 7		4-3
4-7	MITH ELECTRIC RRAKES OR HVDRAILLIC RRAKES)	10
1_8	WITH ELECTRIC DRAKES OR HTDRAULIC DRAKES)	4-9
4-0	WITH AIR BRAKES)	4-9
4-9	HUB AND DRUM MAINTENANCE (FOR TRAILER	··· · -J
40	WITH ELECTRIC BRAKES)	4-10
4-10	WHEEL BEARING LUBRICATION AND ADJUSTMENT	
	(FOR AIR BRAKE TRAILER)	4-11
4-11	WHEEL BEARING LUBRICÁTION AND ADJUSTMENT	
	(FOR ELECTRIC OR HYDRAULIC BRAKE TRAILER)	4-11
4-12	SUSPENSION MAINTENANCE (FOR AIR BRAKE TRAILER)	4-11
4-13	SUSPENSION MAINTENANCE (FOR ELECTRIC	
	OR HYDRAULIC BRAKE TRAILER)	4-11
4-14		4-12
4-15		4-14
4-16		4-16
4-17	WITELS (FUR ELECTRIC BRAKE TRAILERS)	4-16
5	TROUBLESHOOTING	

SAFETY PRECAUTIONS



THIS IS THE SAFETY ALERT SYMBOL. IT IS USED TO ALERT YOU TO POTENTIAL INJURY HAZARDS. OBEY ALL SAFETY MESSAGES THAT FOLLOW THIS SYMBOL TO AVOID POSSIBLE INJURY OR DEATH.

DANGER INDICATES AN IMMINENTLY HAZARDOUS SITUA-TION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY.



WARNING INDICATES A POTENTIALLY HAZARDOUS SITUA-TION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



CAUTION INDICATES A POTENTIALLY HAZARDOUS SITUA-TION WHICH, IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY.

CAUTION

CAUTION USED WITHOUT THE SAFETY ALERT SYMBOL INDI-CATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED. MAY RESULT IN PROPERTY DAMAGE.

A Careful Operator IS THE BEST INSURANCE AGAINST AN ACCIDENT -National Lafely Council-

INTRODUCTION

This manual provides operating, servicing, and maintenance instructions, for Models L20, L24, L40, and L50 Tag Trailers, manufactured by Landoll Corporation, Marysville, Kansas 66508.

- **SECTION 1** gives basic instructions on the use of this manual.
- SECTION 2 gives specifications for the trailer, including measurements and component specifications. A Standard Bolt Torque Table is provided to give guidelines for bolt torques to be used when servicing this product.
- **SECTION 3** gives instructions for the proper operation of the equipment.
- **SECTION 4** gives general maintenance procedures, a maintenance schedule, and a lubrication schedule. Improper maintenance will void your warranty.

IF YOU HAVE ANY QUESTIONS CONTACT:

LANDOLL CORPORATION 1900 NORTH STREET MARYSVILLE, KANSAS 66508 or phone: (785) 562-5381 or (800) 428-5655 or FAX: (785) 562-3240

- **SECTION 5** is a troubleshooting guide to aid in diagnosing and solving problems with the trailer.
- PARTS LIST is a separate manual showing the various assemblies, subassemblies, and systems. Refer to that manual when ordering Landoll replacement parts. Order parts from your Landoll dealer.
- **WARRANTY** The Warranty Registration form is located with the product documents. Fill it out and mail it within 15 days of purchase. The Warranty is printed inside the front cover.

NOTE: IMPROPER ASSEMBLY, MODIFICATION, OR MAINTENANCE OF YOUR LANDOLL MACHINE CAN VOID YOUR WARRANTY.

COMMENTS Address comments or questions regarding this publication to:

LANDOLL CORPORATION 1900 NORTH STREET MARYSVILLE, KANSAS 66508 ATTENTION: PUBLISHING -DEPT. 55

STANDARD SPECIFICATIONS

CAPACITY* (FRAME DESIGN):

OVE	L2024 L2424 L4024 L5029 RALL I	I, L2	2024 GT	4HC H:	D . 	 		 	 	 		 	-	 	 		 	 		 •	 			 			 	 				 	 	. 4	20, 24, 40, 50,	000 000 000 000) L) L) L	BS. BS. BS. BS.
	L2024 L5029	, L2)	2024	4HC),	L24 	42 	4 , 	L4	02	24 	•	•••	•••		 	•		 	 	•	•••	•••	2	4' 9'	DI DI	EC EC	K K	(19 (24	9'F 4'F	FL/ FL/	AT AT	D D	EC EC	CK CK	+ { + {	5' I 5' I	B/T) B/T)
OVE	RALL \	NID	ТΗ					• •				• •					• •			 	• •		•			•	• •			• •		• •					. 8	'-6"
WEIG	SHT																																					
	L2024 L2024 L2424 L4024 L5029	HD	 	 	 	 		 	 	 		 	 		· · ·	-	 	· · · · · · · ·	•	 •	 	- · · - · ·		 			 	· · ·				 	 	 	5, 5, 5, 7, 9,	90(95(99(90(98() L) L) L) L	BS. BS. BS. BS. BS.
нітс	н																								н	E٨	١V	Υ	DU	ΤΥ	' P	IN	ΤL	E	E١	ΈI	ΗП	ГСН

FASTENER SPECIFICATIONS AND TORQUES (FTLBS.) (FOR 9K-15K AXLES)											
DESCRIPTION	APPLICATION	PART NO.	MIN. TORQUE	MAX. TORQUE							
SPINDLE NUT INNER OUTER	9K-15K 9K-15K	SEE SPINDLE TO ADJUSTMENT P	ORQUE/BEARIN AGE 2-4.	NG							
GREASE ZERK	CAM BUSHING SPIDER		5 8	15 8							
CAM BRACKETS			3	4							
AIR CHAMBER	12K-15K AIR BRAKE		50	55							
5/8-11 HEX LOCK NUT	9K, 10K U-BOLT	006-038-00	110	130							
5/8-11 SOCKET HEAD CAP SCREW	DRUM MTG	007-161-00	160	180							
5/8-18 HEX CAP SCREW	DRUM MTG	007-165-00	160	180							
7/8-9 HEX LOCK NUT	SLIPPER EQUALIZER	006-111-00	SNUG FIT	PARTS MUST ROTATE							
3/4-10 HEX LOCK NUT	12K, 15K U-BOLT	006-113-00	130	170							
3/4-16 HEX LOCK NUT	12K, 15K U-BOLT	006-113-00	130	170							
1-8 HEX LOCK NUT	10K, 12-15K SPRING EYE RUBBER	006-112-00	275	325							
1-1/8 -7 HEX LOCK NUT	10K, 12-15K EQUALIZER RUBBER	006-072-00 BUSHED	350	400							
PLASTIC OIL CAP	OIL HUBS	021- 033,24,35,36	20	30							

2

LANDOLL CORPORATION GENERAL TORQUE SPECIFICATIONS (REV. 4/97)

THIS CHART PROVIDES TIGHTENING TORQUES FOR GENERAL PURPOSE APPLICATIONS WHEN SPECIAL TORQUES ARE NOT SPECIFIED ON PROCESS OR DRAWING.

ASSEMBLY TORQUES APPLY TO PLATED NUTS AND CAPSCREWS ASSEMBLED WITHOUT SUPPLEMENTAL LUBRICATION (AS RECEIVED CONDITION). THEY DO NOT APPLY IF SPECIAL GRAPHITE MOLY-DISULFIDE OR OTHER EXTREME PRESSURE LUBRICANTS ARE USED. WHEN FASTENERS ARE DRY (SOLVENT CLEANED), ADD 33% TO AS RECEIVED CONDITION TORQUE.

BOLT HEAD IDENTIFICATION MARKS INDICATE GRADE AND MAY VARY FROM MANUFACTURER TO MANUFACTURER.

THICK NUTS MUST BE USED ON GRADE 8 CAPSCREWS.

USE VALUE IN [] IF USING PREVAILING TORQUE NUTS.

UNC Size	SAE	Grade 2	SAE	Grade 5	SAE	Grade 8	UNF Size	SAE	Grade 2	SAE	Grade 5	SAE	Grade 8
1/4-20	4	[5]	6	[7]	9	[11]	1/4-28	5	[6]	7	[9]	10	[12]
5/16-18	8	[10]	13	[16]	18	[22]	5/16-24	9	[11]	14	[17]	20	[25]
3/8-16	15	[19]	23	[29]	35	[43]	3/8-24	17	[21]	25	[31]	35	[44]
7/16-14	24	[30]	35	[43]	55	[62]	7/16-20	27	[34]	40	[50]	60	[75]
1/2-13	35	[43]	55	[62]	80	[100]	1/2-20	40	[50]	65	[81]	90	[112]
9/16-12	55	[62]	80	[100]	110	[137]	9/16-18	60	[75]	90	[112]	130	[162]
5/8-11	75	[94]	110	[137]	170	[212]	5/8-18	85	[106]	130	[162]	180	[225]
3/4-10	130	[162]	200	[250]	280	[350]	3/4-16	150	[188]	220	[275]	320	[400]
7/8-9	125	[156]	320	[400]	460	[575]	7/8-14	140	[175]	360	[450]	500	[625]
1-8	190	[237]	408	[506]	680	[850]	1-14	210	[263]	540	[675]	760	[950]
1-1/8-7	270	[337]	600	[750]	960	[1200]	1-1/8-12	300	[375]	660	[825]	1080	[1350]
1-1/4-7	380	[475]	840	[1050]	1426	[1782]	1-1/4-12	420	[525]	920	[1150]	1500	[1875]
1-3/8-6	490	[612]	110	[1375]	1780	[2225]	1-3/8-12	560	[700]	1260	[1575]	2010	[2512]
1/1-2-6	650	[812]	1460	[1825]	2360	[2950]	1/1-2-12	730	[912]	1640	[2050]	2660	[3325]

METRIC

COARSE THREAD METRIC CLASS 10.9 FASTENERS AND CLASS 10.0 NUTS AND THROUGH HARDENED FLAT WASHERS, PHOSPHATE COATED, ROCKWELL "C" 38-45.

USE VALUE IN [] IF USING PREVAILING TORQUE NUTS.

Nominal		Standar	d Torq	lne	N <u>o</u> minal	Standard Torque						
Diameter mm	Ne M	wton- eters	F Po	oot- ounds	Diameter mm	Nev Me	Newton- Meters		oot- unds			
6	10	[14]	7	[10]	20	385	[450]	290	[335]			
7	16	[22]	12	[16]	24	670	[775]	500	[625]			
8	23	[32]	17	[24]	27	980	[1105]	730	[825]			
10	46	[60]	34	[47]	30	1330	[1470]	990	[1090]			
12	80	[101]	60	[75]	33	1790	[1950]	1340	[1450]			
14	125	[155]	90	[115]	36	2325	[2515]	1730	[1870]			
16	200	[240]	150	[180]	39	3010	[3210]	2240	[2380]			
18	275	[330]	205	[245]								



LANDOLL CORPORATION HYDRAULIC FITTING TORQUE SPECIFICATIONS 37° JIC, ORS, & ORB (REV. 10/97)

THIS CHART PROVIDES TIGHTENING TORQUES FOR HYDRAULIC FITTING APPLICATIONS WHEN SPECIAL TORQUES ARE NOT SPECIFIED ON PROCESS OR DRAWING.

ASSEMBLY TORQUES APPLY TO PLATED CARBON STEEL AND STAINLESS STEEL FITTINGS ASSEMBLED WITHOUT SUPPLEMENTAL LUBRI-CATION (AS RECEIVED CONDITION). THEY DO NOT APPLY IF SPECIAL GRAPHITE MOLY-DISULFIDE OR OTHER EXTREME PRESSURE LUBRI-CANTS ARE USED.

BRASS FITTINGS AND ADAPTERS - 65% OF THE TORQUE VALUE FOR STEEL. STAINLESS STEEL, ALUMINUM AND MONEL - THREADS ARE TO BE LUBRICATED.

TORQUE IS SPECIFIED IN FOOT POUNDS

	PARKER BRA	ND FITTINGS	
Dash Size	37 Degree JIC	O-Ring (ORS)	O-Ring Boss (ORB)
-4	11-13	15-17	13-15
-5	14-16		21-23
-6	20-22	34-36	25-29
-8	43-47	58-62	40-44
-10	55-65	100-110	57.5-62.5
-12	80-90	134-146	75-85
-16	115-125	202-218	109-121
-20	160-180	248-272	213-237
-24	185-215	303-327	238-262
-32	250-290	_	310-340

LANDOLL CORPORATION HYDRAULIC FITTING TORQUE SPECIFICATIONS 37° JIC, ORS & ORB (REV. 10/97)

THIS CHART PROVIDES TIGHTENING TORQUES FOR HYDRAULIC FITTING APPLICATIONS WHEN SPECIAL TORQUES ARE NOT SPECIFIED ON PROCESS OR DRAWING.

ASSEMBLY TORQUES APPLY TO PLATED CARBON STEEL AND STAINLESS STEEL FITTINGS ASSEMBLED WITHOUT SUPPLEMENTAL LUBRI-CATION (AS RECEIVED CONDITION). THEY DO NOT APPLY IF SPECIAL GRAPHITE MOLY-DISULFIDE OR OTHER EXTREME PRESSURE LUBRI-CANTS ARE USED.

BRASS FITTINGS AND ADAPTERS - 65% OF THE TORQUE VALUE FOR STEEL.

TORQUE IS SPECIFIED IN FOOT POUNDS.

AEROQUIP BRAND FITTINGS										
Dash Size37 Degree JICO-Ring (ORS)O-Ring Bo (ORB)										
-4	11-12	10-12	14-16							
-5	15-16		18-20							
-6	18-20	18-20	24-26							
-8	38-42	32-35	50-60							
-10	57-62	46-50	72-80							
-12	79-87	65-70	125-135							
-14	_		160-180							
-16	108-113	92-100	200-220							
-20	127-133	125-140	210-280							
-24	158-167	150-165	270-360							
-32	245-258		_							

Table 2-3 Hydraulic Fitting Torque Specifications

SPECIFIC BOLT TORQUES

FOUR SPRING SUSPENSION: (FOR 20,000# OR 22,500# AIR BRAKE AXLE SUSPENSIONS AXLE CLAMP U-BOLTS**) FTLBS. FTLBS. FTLBS. FTLBS.
WHEEL FASTENERS: (FOR 20,000# OR 22,500# AIR BRAKE AXLES) OUTER SPINDLE NUTS 250-400 INNER SPINDLE NUTS 450-500 OUTER SPINDLE NUTS 450-500	FTLBS. FTLBS. FTLBS.

**AXLE U-BOLTS MUST BE TIGHTENED EVENLY TO EQUAL TENSION IN INCREMENTS OF 50 FT.-LBS.

WH	WHEEL AND RIM TORQUE REQUIREMENTS											
DESCRIPTION	APPLICATION	PART NO.	TORQUE MIÑ. FTLBS.	TORQUE MAX FTLBS.								
5/8-18 90 ⁰ CONE NUT	FLAT DISC WHEEL	006-081-00	175	225								
5/8-18 90º CONE NUT	CLAMP RING 033-052-01	006-109-00	190	210 GREASED THREADS								
3/4-10 HEX NUT	DEMOUNTABLE RIM CLAMP	006-117-00	210	260								
3/4-16 SPHERICAL NUT	SINGLE WHEEL INNER DUAL	006-064-01,02 006-069-01, 02	450 450	500 500								
1-1/8 -16 SPHERICAL NUT	OUTER DUAL	006-070-01, 02	450	500								
5/8-18 FLANGE NUT	WHEELS	006-058-00	275	325								

Table 2-4 Wheel and Rim Torque Requirements

SPINDLE TORQUE/BEARING ADJUSTMENT (FOR 9K-15K AXLES)

1. Install the bearing and washer into the hub. Thread on the inner nut, rotate the hub and tighten the nut until the hub will not rotate. This requires a minimum of 100 ft.-lb. of torque.

2. Loosen the nut to remove preload torque.

3. Hand tighten the nut and back it off 1/4 to 3/8 turn.

4. Place the tang washer on the spindle and bend one tang inward over the nut. This will keep the inner nut from turning while torque is applied to the outer nut.

5. Install the outer nut and torque it to 225-250 ft.-lb. Insure that the inner nut does not turn. Bend two tangs from the tang washer over the outer nut flats to secure.

6. Install cap with the o-ring and plug installed. Rotate the hub and check the bearing adjustment. The allowable end play is .001"-.010".

FAILURE TO BACK OFF THE INNER ADJUSTING NUT COULD CAUSE BEARING AND AXLE SPINDLE OVERHEATING OR DAMAGE, WHICH COULD RESULT IN THE WHEEL LOCKING UP OR COMING OFF DURING VEHICLE OPERATION.

3-1 GENERAL

This section supplies information for operation of the trailer. It describes and locates controls, and gives general operation procedures. Read all instructions, warnings, cautions, and danger notes before attempting to operate the trailer. Operators must have proper training before operating the trailer.

A WARNING

DO NOT OPERATE THE TRAILER WITH ANY KNOWN FAULT THAT MIGHT EN-DANGER THE OCCUPANTS, NEARBY WORKERS, OTHER TRAFFIC, THE LOAD, OR THE EQUIPMENT.

DO NOT OPERATE THE SEMITRAILER UNTIL YOU HAVE READ THE OPERA-TOR'S MANUAL AND COMPLETELY UNDERSTAND THE PROPER USE AND FUNCTION OF ALL CONTROLS. IM-PROPER USE CAN CAUSE PERSONAL INJURY, DAMAGE TO YOUR SEMI-TRAILER AND CARGO, AND CAUSE TIME-CONSUMING BREAKDOWNS.

3-1.1 Parking Brake (For Trailer With Air Brakes)

The parking brakes are automatically applied by spring pressure with the air actuators of the braking system when air pressure in the emergency line drops below 50 psi. This may be done within the truck using the trailer parking/emergency valve or by disconnecting the emergency gladhands.

3-1.2 Air Brake System

The air brake system of the semitrailer is operated from the towing vehicle after coupling. The towing vehicle's air system must be coupled to the semitrailer and charged to 90 psi minimum before the brakes can adequately function.

3-1.3 Anti-Lock Brake System (ABS)

The Anti-Lock Brake System of the semitrailer is constant powered by the auxiliary (blue) circuit of the seven way electrical connector, with backup power from the stop lamp (red) circuit, and ground through the white wire. It is necessary that the blue circuit is hot when the tractor key switch is on. The blue circuit on the trailer may not be used to power any additional auxiliary devices while the semitrailer is moving forward. If a fault exists in the ABS, normal braking will occur, but the wheels may lock. Service the ABS as soon as possible.

CAUTION

THE AUXILIARY (BLUE) CIRCUIT IS FOR POWERING THE SEMITRAILER ABS. THIS CIRCUIT MUST BE HOT WHEN THE TRACTOR KEY SWITCH IS ON. NO OTHER ELECTRICAL DEVICES MAY BE POWERED BY THIS CIRCUIT WHILE THE SEMITRAILER IS MOVING FORWARD.

IF A FAULT EXISTS IN THE SEMI-TRAILER ABS, BRAKING WILL OC-CUR, BUT WHEELS MAY LOCK. SERV-ICE THE ABS AS SOON AS POSSIBLE.

3-2 PRE-COUPLING OF TRAILER AND TRUCK

- **3-2.1** Slowly back the truck (towing vehicle) up to the front end of the trailer so the hitch of the trailer is centered with the truck. Stop the towing vehicle just inches ahead of the trailer. Set truck parking brake.
- **3-2.2** The hitch on the trailer can be adjusted to different heights. Make sure the hitch height is at the correct height so the trailer deck is about parallel to the ground when loaded.
- **3-2.3** Check the trailer hitch height. The hitch should be the same height, to slightly higher, than the hitch of the towing vehicle. If the trailer hitch is bolted to the trailer at the correct height, but needs some adjustment to connect to the truck, manually raise or lower the front of trailer by cranking the landing gear (parking stands) up or down until the proper height has been obtained.



Figure 3-1 Service Hookups (Front View) - Air Brakes



Figure 3-2 Service Hookups(Front View)-Electric Brakes

- **3-2.4** For trailer with air brakes:
 - a. Connect the service and emergency air hoses of the towing vehicle to their respective gladhand on the front of the trailer. The towing vehicle's air hose couplings are attached and locked to the appropriate gladhands; red emergency line to the gladhand with the "EMERGENCY" tag, and the blue service line to the gladhand with the "SERVICE" tag (See Figure 3-1). Chock the trailer wheels before activating the trailer air supply valve in the towing vehicle. Set the trailer brakes.
 - **b.** Check the air brake operations of the trailer as follows:
 - 1. Apply brakes and inspect brake action on all wheels for prompt application.
 - 2. Release brakes. All brakes should release immediately. Air pressure should discharge quickly from the relay emergency valve.
 - **3.** Disconnect the emergency air line from the trailer gladhand. Trailer brakes should promptly set.
 - **4.** Re-connect the emergency air line to the trailer and activate the trailer air supply valve. The trailer brakes should set.
- **3-2.5** For trailer with electric brakes:
 - a. Connect electrical receptacle to the truck. (See Figures 3-2 and 3-3).
 - **b.** Apply brakes and inspect brake action on all wheels for prompt application.



Figure 3-3 Electrical Assembly (For Trailer w/ Electric Brakes)



Figure 3-4 Electrical Assembly (For Trailer w/ Air Brakes)

3-3 COUPLING OF THE TOWING VEHICLE TO THE TRAILER

▲ DANGER

KEEP ALL PERSONNEL CLEAR OF FRONT, REAR, AND SIDES OF TOW-ING VEHICLE AND TRAILER DURING COUPLING, COMPONENT OPERA-TIONS, AND UNCOUPLING. FAILURE TO STAY CLEAR CAN RESULT IN SE-RIOUS PERSONAL INJURY OR DEATH.

- **3-3.1** Verify the trailer wheels are chocked and brakes function properly.
- **3-3.2** Make sure the towing vehicle's coupler is open.

PUSHING THE TRAILER BACKWARDS CAN DAMAGE LANDING GEAR.

- **3-3.3** Slowly back the towing vehicle so the hitch contacts the trailer hitch. Make sure the hitch is centered and will properly connect up. Set the vehicle brakes.
- **3-3.4** Raise the landing gear (parking stands) and lock the hitch in place.

IMPORTANT

KEEP BRAKES ENGAGED FOR REMAINDER OF HOOKUP, CHECK-OUT PROCEDURES, AND FOR PARKING.

3-4 CONNECTING TOWING VEHICLE SERVICES TO THE TRAILER

3-4.1 Connect the electrical receptacle on the front of the trailer to the towing vehicle. (See Figures 3-1, 3-2, 3-3 and 3-4).

IMPORTANT

THE KEY ON THE PLUG AND THE KEYWAY IN THE SOCKET MUST BE PROPERLY ALIGNED BEFORE INSERTING THE PLUG INTO THE TRAILER SOCKET.

FOR ELECTRIC BRAKE TRAILERS, MAKE SURE BRAKE BREAKAWAY CABLE IS CONNECTED FOR PROTEC-TION WHILE TRAVELING. FAILURE OF CABLE CONNECTION WILL CONSTI-TUTE NO EMERGENCY BRAKING SYS-TEM IN THE EVENT THAT THE TRAILER IS SEPARATED FROM THE TOWING VEHICLE. THIS MAY RESULT IN SERIOUS PERSONAL INJURY, DEATH, OR DAMAGE TO PROPERTY.

3-5 TOWING VEHICLE AND TRAILER HOOK-UP AND CHECK-OUT

WARNING

FAILURE TO PROPERLY SET AND CHECK PARKING BRAKE, AND CHOCK WHEELS WHEN PARKING AND DURING STORAGE, COULD AL-LOW MOVEMENT OF THE TRUCK/TRAILER RIG RESULTING IN SERIOUS PERSONAL INJURY, DEATH, OR DAMAGE TO PROPERTY IN ITS PATH.

3-6 TOWING THE TRAILER

- **3-6.1** Driving the towing vehicle with the trailer coupled behind requires constant attention to the overall length of the combination. Turning, passing, acceleration, braking, stopping, and back-up require special attention to the "hinged-in-the-middle" configuration of the trailer. When executing steep grades or turning tight curves, the trailer must not be allowed to push the towing vehicle, or jackknifing the trailer with the towing vehicle may result. Application of the trailer brakes to keep the trailer in tow will help prevent this pushing. Braking should begin before descending a hill or attempting a curve, to assure control.
- **3-6.2** Make a moving test of the trailer brakes at low, and medium speeds *before* traveling at highway speed.
- **3-6.3** For trailer with air brakes, monitor the air pressure gauge on the dash of the towing vehicle. Pressure should not fall below the 85 to 95 psi range at any time.

- **3-5.1** Assure landing gear is raised up all the way.
- **3-5.2** Attach safety chains from the trailer to the towing vehicle.
- **3-5.3** For electric brake breakaway system, attach brake breakaway cable to towing vehicle. Allow slack in cable for turning. Make sure breakaway battery is charged and breakaway system is working properly.
- **3-5.4** Check your maintenance schedule and be sure everything is up-to-date.
- **3-5.5** Set parking brake and carefully remove all wheel chocks. If brakes are not properly set, the truck/trailer may roll when removing wheel chocks.
- **3-6.4** The trailer wheels track to the inside of the towing vehicle during turns. Thus, turning corners requires a wide swing to prevent "curb hopping", and to allow the trailer wheels to clear any obstacle on the inside of the corner.
- **3-6.5** To stop, use a gradual and smooth application of brakes. If grabbing occurs, apply less pressure. Grabbing brakes are not efficient.

ALWAYS CHECK BEHIND AND UNDER THE TRUCK AND TRAILER FOR PER-SONS OR OBJECTS BEFORE MOVING. FAILURE TO CHECK CAN LEAD TO SERIOUS PERSONAL INJURY OR DEATH TO OTHERS, OR DAMAGE TO PROPERTY.

- **3-6.6** Backing should be done with care. Tail overhang, trailer length, and allowable space must be taken into consideration.
- **3-6.7** The load on the trailer should be positioned so a minimum of 8% of the total weight and a maximum of 30% of the total weight is on the hitch.

3-7 PARKING THE TRAILER

- **3-7.1** Position truck/trailer combination on a level, solid surface.
- **3-7.2** For trailer with air brakes, set the *PARKING BRAKE*, not the trailer hand brake, and check for proper brake holding.

IMPORTANT

ELECTRIC BRAKE TRAILERS DO NOT HAVE A PARKING BRAKE.

- **3-7.3** Chock wheels of trailer for air and electric brake trailers.
- **3-7.4** For air brake trailers, check for any air leaks in lines, relay valve, brake air chamber, or any other air system component.

3-8 UNCOUPLING TOWING VEHICLE FROM TRAILER

- **3-8.1** Park the trailer according to instructions in **Section 3-7**.
- **3-8.2** Lower the landing gear to the ground using the manual crank on the trailer.
- **3-8.3** For air brake trailers, disconnect emergency and service air lines and attach them to the truck gladhand holders.
- **3-8.4** For electric brake trailers, disconnect the brake breakaway cable. Disconnect the electrical cable and store so end is not on the ground.
- **3-8.5** Disconnect safety chains from the towing vehicle.
- **3-8.6** Verify that all service lines are disconnected and trailer wheels are chocked.
- **3-8.7** Unlock hitch and raise trailer hitch by cranking landing gear down until the hitch is in a position to be disconnected.
- **3-8.8** Pull towing vehicle away from the trailer.

3-9 LOADING THE TRAILER

- **3-9.1** Practice all standard industrial safety standards. Do not load any payload that will overload any component of the trailer or cause an unsafe condition.
- **3-9.2** Park towing vehicle and trailer on relatively level ground.
- **3-9.3** Set towing vehicle's brakes.

DO NOT ATTEMPT TO LOAD OR UN-LOAD TRAILER WITHOUT THE RAMP ALL THE WAY UNDERNEATH THE TRAILER BUMPER. PERSONAL IN-JURY OR DEATH IS POSSIBLE IF BACK OF TRAILER IS NOT SUP-PORTED.

- **3-9.4** Keeping hands and feet away from areas that they can become pinched, flip loading ramps down so ramp is completely underneath trailer bumper to support rear of trailer while loading.
- **3-9.5** If base of ramp is not within 2" of the ground, properly shore under ramp to within 2" of front base of ramp so ramp is supported during loading. Do not shore up tight to the ramp because the ramp can not be flipped up once the trailer is loaded.
- **3-9.6** Load the pay load into the trailer so the load center of gravity is centered from side to side and so between 8% and 30% of the total weight of trailer plus payload is on the hitch.
- **3-9.7** Secure the load using approved standard tie-down methods.
- **3-9.8** Flip the loading ramps back up onto the trailer and secure to trailer.
- **3-9.9** Assure maintenance schedule is up-todate and trailer is ready to be pulled.

WARNING

DO NOT ATTEMPT TO LOAD OR UN-LOAD TRAILER WITHOUT THE RAMP ALL THE WAY UNDERNEATH THE TRAILER BUMPER. PERSONAL IN-JURY OR DEATH IS POSSIBLE IF BACK OF TRAILER IS NOT SUP-PORTED.

- **3-10.1** Practice all standard industrial safety standards.
- **3-10.2** Park towing vehicle and trailer on relatively level ground.
- **3-10.3** Set towing vehicle's brakes.
- **3-10.4** Keeping hands and feet away from areas that they can become pinched, flip loading ramps down so ramp is completely underneath trailer bumper to support rear of trailer while unloading.
- **3-10.5** If base of the ramp is not within 1" of the ground, properly shore under the ramp to within 1" of front base of ramp.
- **3-10.6** Making sure the payload will not roll in any direction, remove the payload tie-downs.
- **3-10.7** Unload the payload from the trailer.
- **3-10.8** Flip the loading ramps back up onto the trailer and secure to trailer.

3-11 COLD WEATHER OPERATION

- **3-11.1** Cold weather causes lubricants to congeal, insulation and rubber parts to become hard, which may lead to problems found in bearings, electrical systems, and air systems. Moisture attracted by warm parts can condense, collect and freeze to immobilize equipment. The truck/trailer operator must always be alert for indicators of cold weather malfunctions.
- **3-11.2** During any extended stop period, neither the service nor parking brake should be used as they can freeze up. Use wheel chocks to secure the vehicle from moving.
- **3-11.3** Check all structural fasteners, air system fittings, gaskets, seals and bearings for looseness that can develop due to contraction with cold. Do not over-tighten.
- **3-11.4** Check tire inflation. Tire inflation decreases when the temperature decreases.
- **3-11.5** Periodically check drain holes in the bottom of the relay valve (for trailers with air brakes) and storage compartments. They must be open at all times to avoid moisture entrapment.

3-12 HOT WEATHER OPERATION

- **3-12.1** Hot weather operation can cause expansion of parts, resulting in tightening of bearings, fasteners, and moving parts. Failure of gaskets or seals can occur.
- **3-12.2** The trailer should be parked in the shade if possible. Long exposure to the sun will shorten service life of rubber components (i.e., tires, light and hose grommets, hoses, etc.) and paint life.
- **3-12.3** Check tire pressure early in the day before beginning operations while the tire is cool. Put all valve stem caps back on after checking.
- **3-12.4** If the area is extremely humid, protect electrical terminals with ignition insulation spray. Coat paint and bare metal surfaces with an appropriate protective sealer.
- **3-12.5** For trailers with air brakes, the use of a filter-lubricator in the towing vehicle's air delivery system is recommended.

4-1 GENERAL

This section contains instructions necessary for proper maintenance of the trailer. The trailer is designed for years of service with minimal maintenance. However, proper maintenance is important for durability and safe operation and is an owner/user responsibility.

4-2 MAINTENANCE SCHEDULE

Trailer maintenance includes periodic inspection and lubrication. **Table 4-2, Maintenance Schedule**, lists the recommended maintenance and lubrication tasks by time interval and by accumulated mileage (use whichever occurs first). **4-2.1** Inspection

OPERATING THE TRUCK OR TRAILER WITH DEFECTIVE, BROKEN OR MISS-ING PARTS MAY RESULT IN SERIOUS INJURY OR DEATH; DAMAGE TO THE TRUCK/TRAILER, ITS CARGO, OR PROPERTY IN ITS PATH.

Inspect the towing vehicle, the trailer, and trailer parts periodically for damage or signs of pending failure. Damaged or broken parts must be repaired or replaced at once. Determine the cause of any binding or fluid leakage at once. Correct the problem before using the towing vehicle or trailer. **4-2.2 Lubrication. Table 4-1** details lubrication points and intervals, method of application, and lubricant required, and illustrates the location of each part to be lubricated. During inspections of the trailer, if lubricants are found to be fouled with dirt or sand, those parts should be cleaned with solvent, dried, and relubricated immediately. Dirt in a lubricant forms an abrasive compound that will wear parts rapidly.

PAINT THINNER AND OTHER SOL-VENTS ARE FLAMMABLE AND TOXIC TO THE EYES, THE SKIN, AND THE RESPIRATORY TRACT. AVOID SKIN AND EYE CONTACT. GOOD GENERAL VENTILATION IS NORMALLY ADE-QUATE. KEEP AWAY FROM OPEN FLAMES OR OTHER COMBUSTIBLE ITEMS.

4

4-3 MAINTENANCE PROCEDURES

- **4-3.1 Repair Parts**. Repair parts are illustrated and listed in the parts manual. Replacement of parts due to wear is determined by examination and measurement in the Maintenance Procedures of this section.
- **4-3.2 Tools and Equipment**. Tools, equipment, and personnel normally found in a facility capable of making truck repairs will be adequate for maintenance of the trailer. No other special tools or equipment should be necessary.
- **4-3.3 Standard Torque Values. Tables 2-2 and 2-3** lists torque values for standard hardware and is intended as a guide for average applications involving typical stresses and mechanical surfaces. Values are based on the physical limitations of clean, plated, and lubricated hardware. In all cases, when an individual torque value is specified, it takes priority over values given in this table. Replace original fasteners with hardware of equal grade.

4-3.4 Cleaning

a. Wash trailer to remove all accumulated dirt and grime.

- **b.** Use any mineral spirits paint thinner (or its equivalent) to remove grease and oil from all parts of the trailer. Rinse degreasing solution off with cold water.
- **c.** Inspect trailer for cause of any reported troubles.
- **d.** Scrape, sand, prime, and repaint areas where finish is missing or where there is evidence of corrosion.
- **e.** Replace any missing or illegible decals. Replace any missing or damaged reflective tape.
- f. Use the Troubleshooting Guide to check for "SYMPTOMS" and "PROBLEMS" of any trailer system not functioning correctly. Administer "REMEDY" according to the righthand column of the Troubleshooting guide.
- **g.** After disassembling any components, thoroughly clean dirt and old lubricant from all parts. Do not use a wire brush on any bearing parts or surfaces — use a stiff bristle brush. Do not use compressed air, or spin bearing parts when cleaning. These practices can throw solvents, dirt, or metal particles into your eyes. Dry clean parts with lint free, clean, soft, absorbent, cloth or paper. Wash and dry hands.
- **h.** Inspect seals, seal wiping surfaces, any bearing caps, and bearing cones for wear, pitting, chipping, or other damage.

4-4 FRAME AND DECKS

The trailer should be thoroughly checked daily for cracks or material fatigue. Cracks will normally show best under loaded conditions. If any cracks or breaks are found, immediately contact Landoll Corporation for recommended repair. Any defective parts must be replaced immediately.

4-5 ELECTRICAL SYSTEM

- **4-5.1** Maintenance of the electrical system consists of inspection and minor servicing. Any wire, connection or electrical component showing signs of corrosion, wear, breakage or unraveling must be repaired or replaced.
- **4-5.2** Frayed or unraveling wire must have the defective section removed and replaced with wire of the same color and gauge. Seal all connections and insulate.
- **4-5.3** Corroded terminals must have the corrosion removed, source of corrosion neutralized and the terminals resealed, protected and insulated.
- **4-5.4** Fuse or circuit breaker burn-out or "blow-out" usually indicates an electrical short-circuit, although a fuse can occasionally fail from vibration. Insert a second fuse or reset the breaker. If this fuse immediately burns out or the breaker trips, locate the cause of the electrical short and repair.
- **4-5.5** Lights with a repeated lamp burn-out usually indicates a loose connection, poor system ground, or a malfunctioning voltage regulator. Locate the source of the problem and repair. System grounds must be grounded to bare metal surfaces. Paint, grease, wax, and other coatings act as insulators. Replacement lamps must be equivalent to the factory installed lamp.

4-6 BRAKE SYSTEM MAINTENANCE (FOR TRAILER WITH AIR BRAKES)

USE GREAT CARE IF WHEELS OR BRAKE DRUMS MUST BE TOUCHED OR HANDLED, THEY MAY BE VERY HOT AND CAN CAUSE SERIOUS IN-JURY.



Figure 4-1 Drain Cock Locations

4-6.1 General

- **a.** Check air hoses for chafing, bends, kinks, or damaged fittings. Replace defective hoses.
- **b.** Check the brake system for loose, missing, deformed, or corroded fasteners. Replace and tighten defective hardware.
- **c.** Check brake linings for excessive wear or distortion.
- **d.** Drain air reservoir daily. A drain cock on the bottom of each air reservoir vents the tank to drain collected water and oil. If held open, air pressure in the tanks is relieved, causing the emergency or parking brakes to be applied (See Figure 4-1).

4-6.2 Air Brake Chamber Maintenance

Repair or replace faulty units. Check the condensation holes on the underside of the brake chambers to make sure they are open. The front and rear brake chambers each have two brake chambers - a service chamber and an emergency chamber or spring chamber. The spring chamber should not be serviced. Replace entire unit if spring chamber becomes faulty. Examine yoke pin for wear and replace as necessary.

WHEN CRAWLING UNDER THE TRAILER IS NECESSARY, CHOCK ALL WHEELS OF THE TRAILER AND TRUCK. WHEN JACKING IS NECES-SARY, CHOCK ALL WHEELS AND SUPPORT THE TRAILER FRAME WITH JACK STANDS SUFFICIENT TO WITH-STAND THE WEIGHT OF THE TRAILER AND LOAD. FAILURE TO TAKE ADE-QUATE SAFETY MEASURES CAN RE-SULT IN SERIOUS PERSONAL INJURY OR DEATH.

THE SPRING BRAKE CHAMBER EM-PLOYS A SPRING WITH HIGH FORCES. SERVICE SHOULD NOT BE AT-TEMPTED. SERIOUS INJURY OR DEATH MAY RESULT.

- a. Caging the Power Spring
 - **1.** Chock the trailer wheels.
 - 2. Remove dust cap from spring brake chamber.
 - 3. Remove the release bolt from it's holding brackets and insert it into the spring brake chamber. DO NOT USE AN IMPACT WRENCH TO CAGE THE SPRING BRAKE!
 - **4.** Turn the bolt until the spring brake is caged. This should be 2-1/4 to 2-1/2 inches of release bolt extension.
 - 5. The brakes should now be released. Do not operate loaded trailer with brake manually released.
 - 6. To reset the spring brake, turn the release bolt until the spring is released. Remove the release bolt and store it in its brackets.
 - 7. Snap the dust cap back in place on the chamber.

- b. Removal
 - **1.** Chock all truck and trailer wheels and drain the air system.
 - **2.** Mark the brake chamber for proper air line port alignment for reassembly.
 - 3. CAGE THE POWER SPRING following the steps outlined in Section 4-6.2 a.
 - Disconnect the slack adjuster from the connecting rod by removing the clevis pin (See Figure 4-4).
 - **5.** Mark all air service lines for proper re-installation and disconnect from the brake chamber.
 - **6.** Remove the brake chamber from the axle brackets.
- c. Installation
 - 1. CAGE THE POWER SPRING following the steps outlined in Section 4-6.2 a.
 - 2. Position the inlet ports by loosening the service chamber clamp bands and rotating the center housing so the ports align with marks made during disassembly. Then re-tighten the clamp bands.
 - 3. Position the breather hole in the downward facing position by loosening the clamp bands on the spring brake chamber and rotating the chamber housing until the breather hole faces downward. Re-tighten the clamp bands.
 - 4. Remount the brake chamber on the axle brackets and reconnect the air service hoses and the slack adjuster connecting rod (See Figure 4-4).

IMPORTANT

BE SURE THE SERVICE LINE IS ON THE SERV-ICE CHAMBER PORT AND THE EMERGENCY LINE IS ON THE SPRING BRAKE PORT.

- **d.** Check for leakage by charging the air system to a minimum of 90 psi and apply soap suds to the brake chamber and connections. If a growing bubble is detected or bubbles are blown away, locate the source of the leak and repair.
- e. Insure that the clamp band is properly seated and tight before uncaging the power spring.

4-6.3 Relay Emergency Valve

A WARNING

REPAIR OR REPLACEMENT OF THE RELAY EMERGENCY VALVE IS A COMPLEX OPERATION AND SHOULD BE PERFORMED BY TRAINED SERV-ICE PERSONNEL. IF THE RELAY OR EMERGENCY VALVE NEEDS REPAIR, CONTACT A LANDOLL AUTHORIZED SERVICE CENTER OR THE LANDOLL FACTORY FOR SERVICING.

Every 3600 operating hours, 100,000 miles (161,000 km), or yearly, depending upon operating conditions and experience, the Relay Emergency Valve should be disassembled, cleaned, and lubricated. Rubber parts and parts subject to wear should be replaced if worn or damaged.

4-6.4 Brake Assembly Maintenance.

The brake assemblies should be inspected and adjusted every 2,000 miles or monthly. Examine the brake linings visually to locate the lining showing the greatest amount of wear. The wheel and drum should be removed and the linings replaced if the thinnest portion of the lining is 3/8 in. (9.5 mm) or less. Do not allow the linings to wear thin enough that the lining rivet contacts the drum. (See Figure 4-2).

a. Brake Adjustment This trailer is equipped with automatic slack adjusters which compensate for brake lining wear and keep brakes adjusted. Brakes should not be adjusted manually except when relining brakes.

b. Disassembly for Brakes (See Figure 4-3)

- 1. Release brakes and back off slack adjuster.
- **2.** Remove slack adjuster lock ring and slack adjuster.
- 3. Remove drum assembly (See Figure 4-3.
- **4.** Disengage the roller retainers from the rollers.
- 5. Press down on the bottom brake shoe and remove the lower cam roller. Lift the top shoe and take out the top cam roller.
- **6.** Lift out the shoe retractor spring, which is now free of tension.
- 7. Swing the lower shoe back approximately 180° to relieve the tension on the shoe keeper springs. Remove the springs and slip the shoes off the anchor pins.
- 8. Remove camshaft lock ring, spacer washer(s) and camshaft.
- **9.** After removing the shoes, completely inspect all brake components, servicing as necessary.
- c. Reassembly for Brakes (See Figure 4-3)
 - **1.** Install new anchor pin bushings, camshaft bushing and camshaft seals into the spider.

IMPORTANT

WHEN INSTALLING CAMSHAFT SEALS, THE SEAL ON THE SLACK ADJUSTER SIDE IS IN-STALLED FACING INTO SPIDER. THIS AL-LOWS GREASE TO PURGE OUTSIDE THE BRAKE ASSEMBLY WHEN GREASING THE CAMSHAFT BUSHING. 2.



Figure 4-2 Brake Lining Wear



Figure 4-3 Axle and Brake Assembly



Figure 4-4 Slack Adjuster (Crewson Brunner)

Install cam roller, retainer clip and retractor spring retainers onto the brake shoes.

- **3.** Install 1/8" thick camshaft washer onto the camshaft.
- 4. Install the cam shaft into the spider. Install spacer washer and lock ring on camshaft before sliding the camshaft through the camshaft support bracket. Install the slack adjuster, washer and lock ring.
- 5. Install the brake keeper springs onto the shoes. Install shoes onto the spider by placing shoes in place on the anchor pins, then "wrap" the two shoes into place about the spider.
- **6.** Install the shoe retractor spring onto the shoes.
- 7. Connect slack adjuster to brake chamber pushrod.
- 8. Adjust automatic slack adjuster as outlined in Section 4-6.5.

4-6.5 Automatic Slack Adjusters.

The trailer's automatic slack adjusters provide the means for routine brake adjustment to compensate for lining wear. Inspect slack adjusters every 2,000 miles to assure correct operation.

a. Operational Check (See Figure 4-4)

- **1.** Block wheels to prevent vehicle from rolling.
- **2.** Check that the push rod is fully retracted, apply air to release spring brake.
- **3.** Turn adjustment hex counterclockwise to create an excessive clearance condition. (A ratcheting sound will occur.)
- 4. Make a full service brake application. On release, allow sufficient time for brake to fully retract. During the brake release, observe rotation of the adjustment hex (attach a wrench on the hex to make this movement easier to see). This rotation indicates that an excessive clearance condition has been determined by the slack adjuster, and it is making an adjustment to compensate. On each subsequent brake release the amount of adjustment and push rod travel will be reduced until the desired clearance is achieved.

- **5.** The push rod stroke should be 1 1/2" to 2" with an 80 to 90 PSI service brake application.
- 6. Measure the movement of the push rod from the completely released position to the applied position by marking the push rod where it exits the air chamber before and after application.
- 7. If the brakes have been running tight, the control arm location should be checked.

IF THE ADJUSTER APPEARS NOT TO BE OPERATING, CHECK THE FOUN-DATION BRAKE FOR PROPER FUNC-TION AND ELIMINATE ANY BINDING. RECHECK THE AUTOMATIC SLACK ADJUSTER. IF THE ADJUSTER IS NOT FUNCTIONING, THE UNIT MUST BE REPLACED BECAUSE FAILURE OF PROPER ADJUSTMENT FUNCTION WILL RESULT IN LOSS OF BRAKES.

- b. Replacing Slack Adjuster (See Figure 4-4)
 - 1. Chock wheels to prevent vehicle from rolling. Release spring and service brake. Air chamber push rod must be **fully released**.
 - 2. To maintain a fully released parking brake, a minimum of 80 psi reservoir pressure must be maintained. If air pressure is not available, the spring brake must be manually caged.
 - Remove the existing slack adjuster and clevis - DO NOT REMOVE EXISTING JAM NUT.
 - **4.** Install the new clevis (with 1/2" pin) onto the push rod up to the jam nut DO NOT TIGHTEN JAM NUT.

- **5.** Fit the installation guide over the s-cam splines so the 1/2" pin slots face the air chamber.
- 6. Swing the guide into the clevis until the appropriate slot totally engages 1/2" pin.
- 7. Observe the guide pointer arrow: If the guide pointer is <u>above</u> the clevis, rotate clevis counterclockwise for alignment.

If the guide pointer is <u>below</u> the clevis, rotate clevis clockwise for alignment.

- **8.** Reposition clevis until the guide pointer aligns with the clevis pointer.
- **9.** Verify by engaging 1/4" pin through the clevis and guide.
- **10.** Tighten jam nut to 50 ft.-lbs. torque min.
- **11.** Remove the guide from S-cam shaft.
- **12.** If the push rod threads extend through the clevis more than 1/16", remove clevis and cut rod to length.
- **13.** If the push rod is not fully engaged in clevis body, install a new push rod cut to length.
- **14.** Install the slack adjuster on the S-cam shaft.
- **15.** Rotate the manual adjuster shaft clockwise until the slack adjuster arm holes align with the clevis. Install 1/2" and 1/4" pins and cotter pins.

c. Adjusting Crewson Brunner Slack Adjuster

- 1. Rotate the manual adjuster clockwise until brake shoes contact drum.
- Back off manual adjuster 1/2 turn. (counterclockwise)
- **3.** Manually uncage the spring brake.
- 4. Build up vehicle air pressure.
- 5. Fully apply and release the brakes several times to check for adequate clearance to all adjacent components.
- 6. Measure the distance from air chamber to 1/2" pin. Apply brakes with 80-90 psi air pressure and remeasure distance to 1/2" pins.
- **7.** The stroke (difference of these two measurements) must be less than 2 inches.

4-7 BRAKE SYSTEM MAINTENANCE (FOR TRAILER WITH ELECTRIC BRAKES OR HYDRAULIC BRAKES)

Follow operation maintenance service manual from brake and axle manufacturer. If another manual is required, it may be obtained by requesting Landoll p/n 3-475-010001.

4-8 HUB AND DRUM MAINTENANCE (FOR TRAILER WITH AIR BRAKES)

- **4-8.1** Clean and inspect the brake drums whenever relining the brakes. To be suitable for further service, the brake drum should pass the following checks.
 - a. The brake surface should be free of scoring, excessive heat checks and cracks.
 - **b.** The brake surface diameter should be within the maximum diameter cast or stamped on the drum.
 - **c.** The mounting holes and pilot must be round and true.
 - **d.** The mounting surface must be clean and flat.

FAILURE TO REPLACE FAULTY BRAKE DRUMS WILL RESULT IN AN UNRELIABLE BRAKING SYSTEM, AND MAY LEAD TO AN ACCIDENT.

- **4-8.2** It may be necessary to turn or resurface the braking surface to remove small heat checks or other surface defects resulting from normal use.
 - **a.** The maximum diameter cast into the back plate portion of the brake drum is the maximum diameter or discard diameter to which the brake drum may be turned or worn and still be usable. If any portion of the brake surface exceeds the maximum diameter it must be discarded. The maximum is .120 over the nominal new diameter unless stated otherwise on the casting. The maximum diameter cast into the brake drum supersedes all published information.
 - **b.** When resurfacing a drum, allow at least 0.040 inches under the maximum diameter for additional wear.



Figure 4-5 Hub and Drum Assembly

TURNING A BRAKE DRUM BEYOND 0.040 INCHES UNDER THE MAXIMUM DIAMETER WILL RESULT IN A WEAKER BRAKE DRUM AND MAY RESULT IN AN ACCIDENT.

- **4-8.3** Replacement of the brake drum is required if any of the following conditions exist:**a.** The brake drum is cracked.
 - **b.** The brake surface is heat checked, grooved or worn beyond the rebore limit or the maximum diameter.
 - c. The back plate is cracked.
 - **d.** The bolt holes are elongated.
 - e. The brake drum has been severely overheated.
 - **f.** The brake drum is out-of-round.

- **4-8.4** Replace the hub and drum as follows (See Figure 4-5):
 - a. Remove the brake drum (See Figure 4-5). It may be necessary to release the slack adjuster.
 - **b.** Remove hub cap and catch lubricant in a pan.
 - **c.** Remove outer spindle nut, spindle locking washer, inner spindle nut, and bearing. Remove hub from axle.
 - **d.** Using an appropriate driver, remove inner bearing cone, and seal.
 - e. Using an appropriate driver, remove bearing cups from hub.
 - f. Check that the hub cavity is clean. If the hub is to be reused, clean it thoroughly.
 - g. Insert bearing cups into the hub.

REPLACE BRAKE DRUMS IN PAIRS TO ACHIEVE THE SAME BRAKING POWER ON BOTH WHEELS AND MAIN-TAIN AN EVEN BRAKING LOAD ON THE AXLE. FAILURE TO DO THIS MAY SIGNIFICANTLY REDUCE THE PER-FORMANCE, SERVICE LIFE, AND/OR SAFETY OF YOUR VEHICLE.

h. Clean the mounting surfaces with a good grade commercial cleaner and soft rag. Dry all component parts with a clean, absorbent cloth or paper. Lubricant will not adhere to surfaces wet with solvent.

- i. Place the drum over the hub and brake shoes being careful not to damage the threads on the studs (See Figure 4-5). Make sure the drum seats flat against the hub flange and mates properly with the hub pilot. There should be no interference between the brake drum pilot chamfer and the corner radius on the hub. If interference exists, the hub will not be able to function properly.
- j. Install inner bearing, cone, and seal.

IMPORTANT

DO NOT MIX NEW CUPS WITH OLD CONES OR NEW CONES WITH OLD CUPS.

k. If studs are marked "R" or "L", right hand (R) hubs should be installed on the curbside of the vehicle, left hand (L) hubs should be installed on the driver side.

WARNING

FAILURE TO USE THE CORRECT STUD ON THE CORRECT SIDE MAY CAUSE LOOSENING OF THE HUB STUDS DURING OPERATION, RE-SULTING IN LOSS OF A WHEEL.

- I. Place the hub or wheel over the axle spindle being careful to align the hub bore with the axle. Do not damage the seal. Support the hub assembly until the outer bearing cone and spindle nut are installed, to avoid damaging the seal.
- **m.** Install the outer bearing cone and inner spindle nut, tightening the nut until it is snug against the outer bearing cone. Remove the hub support allowing the hub to rest on the bearings.
- n. Install and adjust bearings (See Section 4-10, Wheel Bearing Lubrication and Adjustment).
- **o.** Install the hub cap with the proper gasket. Tighten the cap screws of the hub cap to 15 to 20 ft-lbs. of torque.
- **p.** Remove the filler plug and fill the hub cavity to the recommended level with a gear type oil.

4-9 HUB AND DRUM MAINTENANCE (FOR TRAILER WITH ELECTRIC BRAKES)

Follow operation, maintenance, service manual from hub and drum vendor that comes with each trailer. If another manual is required, it can be obtained by requesting Landoll P/N 3-475-010001.

4-10 WHEEL BEARING LUBRICATION AND ADJUSTMENT (FOR AIR BRAKE TRAILER)

With trailer sitting level, the oil level must be checked daily and maintained between the "ADD" and "FULL" lines on the hub cap window. Check for cracked windows, missing filler plugs and oil leaks. Add hub oil through the "POP-IN" filler plug located in the center of the hub windows. Re-install the "POP-IN" plugs after filling each hub.

4-10.1 Adjustment

- **a.** With a drain pan under the hub cap, remove the hub cap assembly allowing oil to drain.
- b. Lift the wheel off of the ground.
- c. Adjust slack adjuster to eliminate brake drag during tire/wheel rotation (See Page 4-7).
- d. Remove the outer spindle nut and locking washer (See Figure 4-3).

- e. Rotate the tire by hand and tighten the inner nut until there is a slight bind. Back off the inner spindle nut 1/4 turn (3/8 turn max.) to allow free rotation of wheel.
- f. Install lock ring. Lock ring must engage pin on inner adjusting nut. Nut must engage nearest pin hole.
- **g.** Install tab washer and outer spindle nut. Torque outer spindle nut to 250 (min.) - 300 (max.) ft-lb. Bend 3 tabs over outer nut flats to secure.
- **h.** Install hub cap with new gasket and fill with oil to the full mark. Use 90 weight gear oil.
- i. Check hub oil level after the wheel has set level in one position for a few minutes to allow the oil to work into the bearings.

4-11 WHEEL BEARING LUBRICATION AND ADJUSTMENT (FOR ELECTRIC OR HY-DRAULIC BRAKE TRAILER)

Use vendor manual for electric or hydraulic brake trailer p/n 3-475-010001.

4-12 SUSPENSION MAINTENANCE (FOR AIR BRAKE TRAILER)

4-12.1 Spring Suspension

- a. Make certain that all springs are properly located on the wear pads. Twisted springs or cocked hangers will cause uneven spring contact with wear pad and will result in excessive wear on the spring suspension. Check the shocks for excessive wear.
- **b.** After an initial break in period, approximately 3000 miles, all bolts and nuts should be checked to insure that recommended torque values are being maintained.
- **c.** To obtain proper torque, it is recommended to back off nuts, clean threads, oil threads with SAE 20 oil then tighten.
- **d.** Replacing the equalizer bushings and the torque arm bushings on the spring suspension is a complex operation and should be left to trained service personnel. If the bushings need to be replaced contact a Landoll authorized service center or the Landoll factory for servicing.

4-13 SUSPENSION MAINTENANCE (FOR ELECTRIC OR HYDRAULIC BRAKE TRAILER)

4-13.1 Use vendor manual for electric or hydraulic brake trailer p/n 3-475-010001.



Figure 4-6 Checking Axle for Bend

When trailer tires show signs of scuffing,

4-14 ALIGNMENT (FOR AIR BRAKE TRAILER)

4-14.1 Wheel Alignment



Figure 4-7 Examples of Camber

1.1.1

camber

- a. Remove wheel, hub and bearing assemblies.
- **b.** Place a 3-point axle gauge against the front side of the axle, and adjust each axle gauge point to the axle. (Double point end against the inner and outer wheel bearing surfaces of the spindle being checked and the other point on the inner bearing surface on the other spindle)(See Figure 4-6).
- c. Move the axle gauge and place against the back side of the axle. If either of the points of double point end fails to touch the axle surface, a bent spindle is evident. A point gap of .015" or more is considered excessive tire "toe" and the axle must be replaced (See Figure 4-6).
- d. Follow the same procedures as in Section 4-14.1 b and c, except place the axle gauge above and below the axle. If gauge point gap is found, the axle has positive or negative camber. The trailer axle has no camber from the factory, thus if it is found to have positive or negative camber, axle replacement is necessary (See Figure 4-7 for examples of camber).

4-14.2 Axle Alignment

Proper axle to king pin alignment is necessary to obtain straight tracking. If axle alignment is off, "dog-tracking" occurs. Check alignment manually or by using a trailer alignment machine. In either case, a thorough inspection of the complete suspension must be performed and all defects corrected before aligning.

a. Manual Älignment Procedure

1. Position trailer on a firm and level surface. Insure that the undercarriage is in the rear most position. Eliminate any suspension binding due to sharp turns or unusual maneuvers.

- **2.** Detach truck from the trailer and jack the trailer up sufficiently to permit measuring from the underside of the trailer.
- **3.** Suspend a plumb bob at axle height from the center of the hitch.
- Measure (D) from the plumb bob to the center point on one end of the axle. Record this measurement (See Figure 4-8).
- Measure (D1) to the other end of the axle in the same manner as in Step 4. Record this measurement (See Figure 4-8).
- It is usually necessary to set D about 1/8" shorter than D1 to insure proper trailer tracking on slope of road.
- **7.** Loosen the radius rod clamp bolts on the adjustable radius rods.
- 8. Turn the adjustable radius rod on the front axle until the proper alignment has been achieved.
- **9.** Tighten the radius rod clamp bolts to 45-55 ft-lb torque to lock in the alignment of the front axle.
- **10.** Align the rear axle to the front axle in the same manner, using the radius rod for adjusting. The rear axle should be parallel with the front axle, with the dimensions Y and Y1 being the same.
- **11.** Tighten the rear axle radius rod clamp bolts to 45 to 55 ft-lb.
- 12. In all cases, all suspensions must be in good repair with no binding or other restrictions before the alignment process can be undertaken properly. All defective parts of the suspension or axles must be replaced immediately.



Figure 4-8 Checking Axle Alignment



4-15 TIRES

- 4-15.1 Tire Inflation. Tire inflation will cause tire to ground contact characteristics as shown in Figure 4-9. Tire inflation should be checked daily while the tire is cold, and during road stops. Checking the tire pressures while tires are hot will give a faulty increased pressure reading. Adjusting tire air pressure to the specified amount while tires are hot will produce improper tire to road contact and thus abnormal wear. Do not exceed cold inflation pressure listed on the trailer VIN plate located on the front of the trailer. Exceeding cold inflation pressure will result in damaged tire bodies, rims, and wheels. Replace all valve stem caps when pressure checking/adjusting has been completed. remove any foreign objects from between duals.
- **4-15.2 Tire Matching**. Both tires on the same spindle must be the same size in order to properly distribute the load and braking forces between them. The tire must be mounted on a rim and properly inflated before measuring. If there is an allowable difference in size the smaller tire should be mounted to the inside position of the duals.
 - a. Tape Measuring Method.: Measure around each tire on the tread surface. A maximum difference of 3/4" is allowed between the two mating tires of a dual (See Figure 4-10).
 - **b.** Straight Edge or String Method: (This method can not be used if tire and wheel assemblies are not mounted on the axle.) Jack trailer up until the wheels are off of the ground. Hold a straight edge against the tires of both ends of an axle. A gap at one tire indicates a smaller tire. A maximum of 1/8" gap is allowed (See Figure 4-11).



Figure 4-10 Tape Measuring Method



Figure 4-11 Straight Edge Method



Figure 4-12 Mounting Tires and Wheels





4-16 WHEELS (FOR AIR BRAKE TRAILERS)

- 4-16.1 Mounting Tire and Wheel
 - a. Make sure that all mounting surfaces are clean and free of rust, dirt or paint. A wire brush may be used to clean these surfaces (See Figure 4-12).
 - **b.** Position the inner disc wheel over the studs, being careful not to damage the stud threads. Make sure that the disc wheel is flat against the mounting surface and that there is clearance between the disc wheel taper and brake drum.
 - **c.** Position the outer disc wheel being careful not to damage the threads. Be sure the valve stems for both the inner and outer tire are accessible.

- **d.** Install the flange nut and tighten to 50 footpounds using the sequence in **Figure 4-13**. Then tighten to full torque of 450 to 500 footpounds.
- **e.** Torque will drop after the first 50 to 100 miles of operation. Check the nuts for proper torque after this interval and retighten them.

USE A TORQUE WRENCH TO ASSURE PROPER TORQUE. INSUFFICIENT TORQUE CAN CAUSE STUD BREAK-AGE AND DAMAGE WHEEL PILOTS. OVERTORQUE CAN OVERSTRESS THE STUDS AND STRIP THE THREADS.

4-17 WHEELS (FOR ELECTRIC BRAKE TRAILERS)

Use vendor manual for electric or hydraulic brake trailer p/n 3-475-010001.



Fig. 4-14 Lubrication Points

LUBE	BRAND AND PRODUCT (WEIGHT AND/OR TYPE)									
	AMOCO	TEXACO								
1	Lit-multi-purpose Grease	Rondex Multi-purpose Grease	Phil Lube M.W. Grease	MarFax All Purpose						
2	Multi-purpose 90	Gear Oil GTX 85-140	Phil Lube All-purpose Gear SAE 90 #90501	Multi-gear EP 80W90						

NORMAL OPERATING SERVICE INTERVALS a								
SERVICE INTERVAL : ITEM	Before Every Use	1st 5 Hrs. or 50	Weekly or 500	Monthly or 2,000	6 Months or 12,000	Yearly or 25,000	LUBE #	NOTES
LIGHTS		I	I					
WIRING & CONNECTIONS		I		I				
FASTENERS		I, T		I				b
BRAKES	0	I		C, I, L			1	с
*BRAKE AIR SYSTEM		I	I	I				
*RELAY VALVES						I, C		
*BRAKE ADJ & WEAR		I		I, T				d
*SLACK ADJUSTERS		I	I			L	1	С
*CAMSHAFT ASSYS		I	I			L	1	С
HUB OIL		I	I, L			R	2	С
WHEEL BEARINGS		I			Ι, Τ		2	С
TIRE INFLATION & WEAR		I	I					е
WHEEL LUG NUTS		Ι, Τ	I	I, T				b
SUSPENSION				Т		I,T		
SUSPENSION ALIGNMENT		I		I				
**BRAKE MAGNETS					I			
**BRAKE CONTROLLER					I			
**BREAKAWAY STSTEM	0							
I – Inspect, O - Test Operation, R – Replace, T– Tighten/ Adjust Torque, L – Lubricate, C – Clean								
* For Trailers with Air Brakes								
** For Trailers with Electric Brakes								
A								
NOTES:								
a. Perform at the time shown. Shorten service intervals when operating in severe or dirty conditions.b. See Table 2-1 (Bolt Torque Chart) for correct torque.								

c. See Table 4-1 (Lube Specification Chart) for recommended lubricant.d. Call Landoll Customer Services for procedures to replace.

e. See Serial Number Plate on the front of the trailer for proper inflation requirements.

Table 4-2 Maintenance Schedule

TROUBLESHOOTING

Troubleshooting should be performed by a trained and competent technician. Landoll Corporation is not responsible for equipment that is improperly maintained. Contact an authorized Landoll dealer or the Landoll Service department for service questions.

5-1 ELECTRICAL

Most electrical system problems show up as a burned out light or fuse, or inoperative electrical component. Wiring, grounds or components may be at fault. Locate the symptom in this section that best identifies your electrical problem. Check out each possible problem under that symptom. If the problem cannot be located, see an automotive electrical specialist. For maintenance procedure, see **Section 4-5**.

Fuse blown on tractor: Replace fuse. Loose connection at plug-in: Tighten connection. Broken or corroded wires: Replace wire. Ground wire loose: Clean and tighten ground.
Wires shorted or loose: Locate, insulate, replace, or tighten.
Voltage difference between trailer & tractor: Trac- tor supply wire or circuit components too low capacity - enlarge wire or component, match bulbs with tractor voltage.
Ground wire disconnected: Self-explanatory. Voltage difference between trailer & tractor: Trac- tor supply wire or circuit components too low capacity - enlarge wire or component, match bulbs with tractor voltage.
Vibration: Locate source of vibration and repair. Short circuit: Replace fuse and try all accessories. If fuse blows right away, locate short and repair.
Vibration: Locate source of vibration and repair. Short circuit: Replace fuse and try all accessories. If fuse blows right away, locate short and repair. Loose connection: Check lamp sockets and ground connections. Intermittent short: Locate short and repair. Improper voltage: Check voltage regulator output.

5-2 TIRES - WHEELS - SUSPENSION

Most tire, wheel, and suspension related problems are due to excessive loads, extreme conditions, and improper maintenance. Tire, wheel, and suspension problems can be easily detected and solved by checking the following guide. For maintenance procedures, see **Sections 4-10 thru 4-17**.

SYMPIOM	PROBLEM: REMEDY
VIBRATIONS WHILE DRIVING	Improper tire inflation: Inflate to proper pressure. Tires cupped or have flat spots: Replace tires. Wheels bent or loose: Replace or tighten. Tires incorrectly mounted: Remount. Mud in wheels: Clean wheels. Tire(s) out of balance: Balance tires. Brakes dragging: Locate cause and repair. Object(s) stuck between duals: Remove object(s).

SYMPTOM

PROBLEM: REMEDY

RAPID TIRE WEAR/DETERIORATION:	
CENTER TREAD WEAR	Over inflation: Deflate to correct inflation.
SHOULDER TREAD WEAR - BOTH SHOULDERS	Under inflation: Increase inflation to correct psi. Check axle alignment. Overload: Loads are above rated tire capacity. Do not load above rated tire capacity.
SHOULDER TREAD WEAR - ONE SHOULDER	Axle damage: Straighten or replace axle. Axles not parallel: Check axle alignment.
OVERALL TREAD WEAR	Overloading: Check tire load rating. High speeds: Adjust speed according to road and load conditions. Incorrect dual matching: Properly match dual tires
TIRE FLAT SPOTS	Quick stops: Adjust braking practices. Grabbing brakes: Adjust brakes properly. Worn or loose wheel bearings: Adjust or replace as needed. Out of balance wheels and tire: Balance wheels and tires.
UNEVEN WEAR	Suspension bushings worn: Replace bushings. Worn or loose wheel bearings: Adjust or replace as needed. Out of balance wheels and tires: Balance wheels and tires.
RIM FAILURE*:	
CRACKING	Overinflated tires: Deflate tire to proper psi. High speeds: Adjust speed according to road and load conditions. High speed cornering: Adjust cornering practices. Over loading: Check rim load rating.
*In all instances of rim failure, replace the rim imm	ediately!
BENDING OR WARPING	Curb-hopping or potholes: Adjust turning practices and adjust speed accordingly with road conditions. Improper tightening sequence: Follow proper tightening sequence.
BROKEN STUDS*	Over-tightening: Use correct torque and tightening sequence when mounting.
*Replace broken studs before using the semitrailer	r!,
TRAILER TRACKING PROBLEMS:	
TRACKS TO ONE SIDE	Axle alignment: Re-align axle.
TRACKS TO EITHER SIDE	Broken or bent springs or equalizer bushings: Replace worn parts. Axles not parallel: Adjust axle spacing to be parallel.

5-3 BRAKES (FOR TRAILERS WITH AIR BRAKES)

For maintenance procedures, see Section 4-6.

SYMPTOM PROBLEM: REMEDY SINGLE BRAKE DRAGGING OR LOCKED Broken internal brake component: Locate and replace broken part. Flat spot on cam roller or cam shaft: Replace and lubricate. Improper adjustment: Adjust slack adjusters. Spider bushing or cam bracket bushing binding: Lubricate or replace bushing. Improper Iubrication: Lubricate per Figure 4-. Worn brake shoe bushing: Replace bushing. Brake drum distortion: Replace drum. Brake chamber pushrod binding: Realign brake chamber bracket. Air brake line loose or broken: Tighten or repair. BRAKES APPLY TOO SLOWLY Brakes need adjusting or lubrication: Adjust or lubricate as needed. Low air pressure in brake system (below 90 psi): Check tractor air system. Restricted tubing or hose: Locate restriction and remove. Worn or broken relay valve: Replace. Call Factory or see gualified Trailer/Brake Technician. Air system improperly connected to tractor: ALL BRAKES DO NOT RELEASE Tighten or adjust connections. Brake valve on tractor is applied: Release brake. Relay emergency valve in emergency position: Check line pressure and check valve. Restricted tubing or line: Locate restriction and remove. Tractor protection valve failure: Troubleshoot tractor air system. Parking brakes locked: Troubleshoot air system. Moisture in air system: Check air system. **BRAKES GRABBING** Grease on brake linings: Reline brakes. Brake rigging binds: Align brakes or replace bent parts. Brake valve on tractor failed or worn: Replace valve. Relay emergency valve failed or worn: Replace valve EXCESSIVE LEAKAGE WITH BRAKES APPLIED Relay emergency valve leaking: Replace valve. Leaking brake chamber diaphragm: Replace brake chamber. Call Factory or see qualified Trailer/Brake Technician Leaking tubing or hose: Replace part(s). EXCESSIVE WATER PRESENT IN BRAKE SYSTEM Reservoir not drained often enough: Drain reservoir daily. BRAKE WILL NOT APPLY PROPERLY Flat spot on cam roller or camshaft: Replace and lubricate.

5-4 BRAKES (FOR TRAILERS WITH ELECTRIC BRAKES)

For maintenance procedures, see Section 4-7.

SYMPTOM	PROBLEM: REMEDY
NO BRAKES	Open circuits: Find and correct. Severe Underadjustment: Adjust brakes. Faulty Controller: Test and correct. Short Circuits: Find and correct.
WEAK BRAKES	Grease or Oil on Magnets or Linings: Clean or re- place . Corroded Connections: Clean and correct cause of corrosion Worn Linings or Magnets: Replace. Scored or Grooved Brake Drums: Machine or re- place. Improper Synchronization: Correct. Underadjustment: Adjust brakes. Glazed Linings: Reburnish or replace. Overloaded Trailer: Reduce to within load restric- tions.
LOCKING BRAKES	Underadjustment: Adjust brakes. Improper Synchronization: Correct. Faulty Controller: Test and correct. Loose, Bent, or Broken Brake Components: Re- place components. Out-of-Round Brake Drums: Machine or replace. Insufficient Wheel Load: Adjust system resistor and synchronize.
INTERMITTENT BRAKES	Faulty Controller: Test and correct. Broken Wires: Repair or replace. Loose Connections: Find and repair. Faulty Ground: Find and repair.
BRAKES PULL TO ONE SIDE	Wrong Magnet Lead Wire Color: Correct. Incorrect Adjustment: Adjust. Grease or Oil on Magnets or Linings: Clean or re- place . Broken Wires: Repair or replace. Bad Connections: Find and repair.
HARSH BRAKES	Underadjustment: Adjust brakes. Improper Synchronization: Correct. Improper Controller: Change. Faulty Controller: Test and correct
NOISY BRAKE	Underadjustment: Adjust brakes. Lack of Lubrication: Replace and lubricate. Broken Brake Components: Replace components. Incorrect Brake Components: Correct.
SURGING BRAKES	Grease or Oil on Magnets or Linings: Clean or re- place . Out-of-Round Brake Drums: Machine or replace. Faulty Controller: Test and correct.
DRAGGING BRAKES	Overadjustment: Readjust Out-of-Round Brake Drums: Machine or replace. Incorrect Brake Components: Replace. Loose, Bent, or Broken Brake Components: Re- place components. Faulty Breakaway Switch: Repair or replace. Broken Wires: Repair or replace. Loose Wheel Bearing Adjustment: Adjust. Bent Spindle: Replace axle.

5-5 BRAKE DRUMS

For maintenance procedures, see See Section 4-8.

SYMPTOM	PROBLEM: REMEDY
EXCESSIVE LOSS OF BRAKES OR FADING	Overheated brake drums: Check for defective or misadjusted brake linings, distorted or over-machined drums. Also check for operating conditions or loads that create severe or excessive brake applications.
BRAKES PULL TO EITHER SIDE	Drums of different diameters: Replace with drums of same diameter. Foreign matter in drums: Clean drums out.
ROUGH OR NOISY BRAKING ACTION	Worn drums: Pull drums and inspect for any of the following; Heat spotted drums, grease spotting, blue drums, scored drums, excessive wear at rivet holes or edges, polished drums, out of round drums, unbal- anced drums, worn/damaged brake components, for- eign matter in drums. Correct situation or replace worn part(s).
VIBRATION IN RIDE	Worn or out-of-round drums: Replace drums. Out-of-balance drums: Balance drums.



Intertek

Equipment from Landoll Corporation is built to exacting standards ensured by ISO 9001 registration at all Landoll manufacturing facilities.

Model L20, L24, L40 & L50 Series Operator's Manual

Re-Order Part Number F-203-0503

LANDOLL CORPORATION

1900 North Street Marysville, Kansas 66508 (785) 562-5381 800-428-5655 ~<u>WWW.LANDOLL.COM</u>



Copyright 2014. Landoll Corporation "All rights reserved, including the right to reproduce this material or portions thereof in any form"