



Operation, Service and Maintenance Manual



Sierra H8 Hydraulic Winch

Ramsey Winch Company

P.O. Box 58151 - Tulsa, OK, 74158-1510 USA

Phone 1-800-777-2760 - Fax (918) 438-6688

<http://www.ramsey.com>

- This page intentionally left blank -

Table of Contents

Introduction	4
Pictogram Definitions	5
Sierra H8 Specifications	8
Winch Mounting	10
Cable Installation - Set Screw	11
Sierra Hydraulic Winch Operation	12
Sierra Troubleshooting Guide	13
Overhaul Section - Disassembly	14
Overhaul Section - Assembly	25
Assemblies and BOMs	36
Dimensional Drawing - Manual Shift	48
Dimensional Drawing - Air Shift	49
Limited Warranty	51












Introduction

Please read this manual carefully. This manual contains information to obtain the most efficient operation from your Ramsey Winch and safety procedures you need to know before operating a Ramsey Winch. Do not operate this winch until you have carefully read and understand the entire manual.

Ramsey Winches are designed and built to exacting specifications. Great care and skill go into every winch we make. Refer to the last page for information on the Ramsey Winch limited warranty.

At the time of publishing, this manual is accurate to the best of our knowledge. Ramsey Winch reserves the right to change any or all items, components and parts, necessary for any reason. This right does not obligate Ramsey Winch to immediately update the manual. If in doubt, please call your local Ramsey Winch distributor for the most up-to-date information.


Warnings

-  **WARNING** *Ensure the clutch is fully engaged before starting the winching operation.*
-  **WARNING** *Do not start the winch motor before engaging the clutch.*
-  **WARNING** *Do not disengage the clutch under load.*
-  **WARNING** *Do not allow personnel under or near the raised load.*
-  **WARNING** *Do not try to guide the cable during a pull. Stand clear of the cable.*
-  **WARNING** *Do not exceed the maximum line pull ratings shown in specifications.*
-  **WARNING** *Do not use the winch to lift, support, or otherwise transport people.*
-  **WARNING** *Always maintain a minimum of five wraps of cable around the drum. This is necessary to hold the load. The cable anchor is not designed to hold the load.*
-  **WARNING** *In car carrier applications, after pulling the vehicle onto the carrier, secure the vehicle to the carrier bed. Do not maintain load on winch cable while transporting the vehicle. Do not use the winch as a tie down.*
-  **WARNING** *When pulling a heavy load, place a blanket, jacket, or tarpaulin over the cable five or six feet from the hook.*
-  **WARNING** *Do not allow the load to shift or jerk.*

Pictogram Definitions



Read and understand this entire manual before using the winch.



Clutch must be fully engaged during winching operations.



Do not disengage clutch under load.



Keep all personnel out from under and away from raised loads.



Do not use the winch to lift, support, or otherwise transport people.



Do not exceed maximum line pull ratings shown in specifications. Shock loads must not exceed these ratings.



Keep yourself and others at a safe distance to the side of the cable when pulling under load. Do not step over a cable, or near a cable under load.



Do not use the winch in hoisting applications due to the required hoist safety factors and features.




Do not try to guide the rope during winching operations.




Always wear the appropriate personal protection equipment during winching operations.

MANUAL




Illustrates the engaged and disengaged positions for the clutch handle on winches with a manual clutch.

SEMI-AUTOMATIC




Illustrates the engaged and disengaged positions for the clutch handle on winches with a semi-automatic clutch.

BATTERY POWERED



Illustrates the engaged and disengaged positions on winches with electric shift.

AIR POWERED




Illustrates the engaged and disengaged positions on winches with air shift.



The winch is intended to be used for vehicle recovery and pulling loads.



This image illustrates the minimum number of wraps of rope for the particular winch.





The blanks on these images will have printed data specific to the particular winch.

Sierra H8 Specifications


Performance Table

SIERRA H8						
RATED LINE PULL	lbs.					8000
	kg.					3620
GEAR REDUCTION						17
WEIGHT (WITHOUT CABLE)						90 lbs.
LAYER OF CABLE		1	2	3	4	5
*RATED LINE PULL PER LAYER	lbs.	8000	6700	5700	5000	4500
	kg.	3620	3040	2585	2270	2040
CABLE CAPACITY	ft.	25	55	90	130	175
	m	7.6	16.7	27.4	39.6	53
LINE SPEED (AT 17 GPM)	fpm	48	56	64	73	81
	mpm	14.5	17.0	19.4	22.1	24.6
*These specifications are based on recommended 3/8" EIPS wire rope and a 4.8 Cu. In./Rev motor.						

Performance Charts



Hydraulic System Layout



Winch Mounting

It is important to mount the winch securely so the three major sections (the motor end, the cable drum, and the gear housing end) are properly aligned. Excessive bushing wear and difficulty freespooling are usually symptoms of misalignment.

If the winch is mid-mounted, attach at least one tie-plate to the mounting feet at the bottom of the winch to maintain alignment. If the winch is foot mounted, attach at least one tie-plate at the midpoint to maintain alignment. It is always preferred to use both tie-plates in the final installed configuration.

Contact your local RAMSEY WINCH distributor or RAMSEY WINCH customer service for the recommended mounting kit. The mounting kit will allow the winch to be mounted in upright or midmount applications and meets the criteria of serving as a solid and true mounting surface.

If not using the RAMSEY WINCH mounting kit, or a RAMSEY WINCH mounting kit is not available, use the mounting hole patterns described in the Dimensional drawings. The mounting surface must be flat within 0.015 in. and sufficiently stiff to resist flexing.


NOTICE

If angles or a steel plate are used in mounting the winch, attach the provided tie-plates to the remaining mounting pads to the either the side or foot.

Cable Installation - Set Screw

An "A" or "B" decal on the motor end bearing indicates the spooling direction of the cable. If the decal is damaged or unreadable, contact Customer Service for addition information.

1. Unwind the cable by rolling it out along the ground to prevent kinking. Securely wrap the end of the cable opposite of the hook with plastic or similar tape to prevent fraying.
2. Place the taped end of the cable into the hole in cable drum. Use the 3/8-16NC x 1/2" long hex socket drive setscrew to secure the cable to the drum. The setscrew is included with the drum assembly.
3. Carefully run the winch in the "reel-in" direction. Keeping tension on the end of the cable, spool all the cable onto the cable drum, taking care to form neatly wrapped layers.
4. With the cable installed, check the freespool operation. Disengage the clutch and pull on the cable at a walking speed. If the cable "birdnests," loosen the jam nut and turn the capscrew clockwise to increase drag on the drum. If the cable pull is excessive, loosen the capscrew by turning counterclockwise. Tighten the jam nut when the proper setting is obtained.



Sierra Hydraulic Winch Operation

Familiarize yourself with winch by making test runs before the first pull. Plan your test in advance. You hear your winch as see it operate; learn to recognize the sounds of a light steady pull, a heavy pull, and sounds caused by load jerking or shifting. Gain confidence in operating your winch and its use will become second nature with you.

The uneven spooling of cable while pulling a load is not a problem unless there is a cable pileup on one end of the drum. If this happens, reverse the winch to relieve the load and move your anchor point closer to the center of the vehicle. After the job is done you can unspool and rewind to neatly lay the cable.

Manual Clutch Operation

To disengage the clutch:

1. Run the winch in the "cable out" direction until the load is off the cable.
2. Pull the handle out and rotate 90°.
3. With the handle in the "DISENGAGED" position the cable can now be free-spooled from the drum.

To engage the clutch:

1. Pull the handle out and rotate 90° and release the handle.
2. Run the winch in reverse until the clutch handle snaps fully into the "ENGAGED" position.
3. Do not attempt to pull a load unless the handle is fully at the "ENGAGED" position.
4. Do not force the handle or hammer the handle to engage.

Air Clutch Operation

To disengage the clutch:

1. Run the winch in the reverse (reel out) direction until the load is off the cable.
2. Apply air pressure to the 0.125-27 NPT port. 80 PSI (min.) 150 PSI (max.). Pressure must not exceed 150 PSI.

To engage the clutch:

1. Remove air pressure from the cylinder (a return spring engages the plunger).
2. Run the winch in reverse until the clutch engages. Do not attempt to pull a load with the clutch not engaged.


Sierra Troubleshooting Guide

CONDITIONS	POSSIBLE CAUSE	CORRECTION
DRUM WILL NOT ROTATE WITH NO LOAD	1. Winch not mounted squarely causing end bearings to bind the drum. 2. Brake damaged. 3. Gears damaged.	1. Check the mounting. Verify it's square. 2. Inspect and replace brake. 3. Inspect and replace damaged gears.
DRUM WILL NOT ROTATE UNDER LOAD	1. Load greater than rated capacity of the winch. 2. Low hydraulic system pressure. 3. Winch not mounted squarely causing end bearings to bind the drum.	1. Reduce load to less than the rated capacity of the winch. 2. Check pressure. 3. Check the mounting. Verify it's square.
WINCH RUNS TOO SLOW	1. Low flow rate. 2. Hydraulic motor worn out.	1. Check flow rate. 2. Replace motor.
DRUM WILL NOT FREESPOOL	1. Clutch not disengaged. 2. Winch not mounted squarely causing end bearings to bind the drum.	1. Disengage clutch. 2. Check the mounting. Verify it's square.
BRAKE WILL NOT HOLD	1. Brake damaged.	1. Inspect and replace brake.
LOAD DRIFTS	1. Worn brake.	1. Overhaul the brake assembly.
CABLE BIRDNESTS WHEN THE CLUTCH IS DISENGAGE	1. Drag screw improperly adjusted.	1. Adjust drag screw.
EXCESSIVE NOISE	1. Hydraulic system flow too high. 2. Drum in bind, winch not mounted squarely.	1. Check flow rate. 2. Check the mounting. Verify it's square.
DRUM CHATTERS in "REEL IN" DIRECTION	1. Low hydraulic system flow. 2. Low hydraulic system relief pressure setting.	1. Check flow rate. 2. Check relief valve setting.
CLUTCH DIFFICULT TO ENGAGE	1. Detent screw damaged or improperly adjusted.	1. Replace or readjust detent screw.

Overhaul Section - Disassembly


Tie Bar Removal

1. Remove the capscrews (#9) to remove the tie plates (#7).




Motor Assembly Removal

1. Carefully remove the spring retention plate (#8) by removing the capscrews (#11). Remove the washers (#12). Remove the spacers (#6) from the spring tensioner assembly (#3) and remove the spring tensioner assembly. Remove the motor assembly (#2) from the winch.
2. Remove the thrust disc (#19), spring (#18), and drag brake (#4) from the motor assembly. Remove the capscrew (#20) and jam nut (#13) from the motor assembly.




Drum Removal

1. Pull the input coupling (#14) out of the drum (#15). Drive the roll pin (#16) out of the coupling (#14).
2. Pull the shaft (#5) out of the drum. Remove the O-ring (#20) from the shaft (#5).
3. Lift the drum (#15) off of the gear housing assembly and remove the dowel pins (#17).




Removing the Brake Cover

1. Set the gearbox assembly with the output side down.
2. Remove the brake housing (#103) by removing the capscrews (#111) and sealing washers (#119). The dowel pins (#124) will be loose when the brake housing is removed.
3. Remove the brake cover (#102) by removing capscrews (#110). Remove the O-ring (#116) from the brake housing (#103).




Removing the Brakes

1. Remove the wave washers (#121), stator plate (#104), the brake disc (#114), two separator plates (#105), the brake disc, the stator plate, the brake disc, and the cam (#107).




Removing the Brake Hub

1. Remove the O-ring (#117) from the brake spacer (#108). Remove the brake spacer and cam pilot (#109).
2. Carefully press the cam pilot (#109) from the brake spacer (#108).
3. Remove the brake actuator (#115) and thrust washer (#123) from the brake hub (#112).
4. Remove the brake hub (#112), preload spring (#120), cam plate (#107), brake disc (#113) and springs (#122).




Removing the End Bearing

1. Remove the end bearing (#203) by removing the capscrews (#208, #207). Remove the O-ring (#216).




Removing the Output Carrier Assembly

1. Remove the output carrier assembly (#201), output ring gear (#212), output sun gear (#214), and carrier spacer (#206).
2. Remove the input carrier assembly (#202), input ring gear (#213), and input sun gear (#215). Remove the O-ring (#217) and carrier spacer (#206) from the input sun gear.




Removing the O-ring Adapter

1. Press the O-ring adapter (#204) from the gear housing. Remove the O-ring (#218) from the O-ring adapter.




Manual Shift

1. Remove the jam nut (#227) and the detent screw (#226).
2. Remove the handle (#106) by driving out the roll pin (#118). Slide the shifter shaft assembly (#225) from the housing (#224).



Air Shift

1. Remove the plunger (#210) by removing the shoulder bolt (#209). Remove the roll pins (#219) from the plunger. Slide the clutch springs (#224) out of the gear housing (#205).
2. Remove the plug (#221) from the gear housing. Remove the air cylinder (#211) from the gear housing. Remove the shims (#222), if present, and the shifter shaft (#223) from the air cylinder (#211) by driving out the roll pin (#220).




Overhaul Section - Assembly

Pre-assembly Preparation

1. Spray the inside of the gear housing, outside of the output ring gear, ring gear pilot in the end bearing, shifter shaft and plunger with water resistant WD40. Let dry completely before assembling the winch.


Air Shift

1. Place the shifter shaft (#223) on the air cylinder (#211) using the roll pin (#220) to secure the shifter shaft on the air cylinder. Lightly coat the shifter shaft assembly with 75w90 synthetic gear oil. Insert the assembly into the gear housing. Use the shims (#222) to properly locate the port.
2. Place the clutch springs (#224) into the gear housing (#205). Press the roll pins (#219) into the plunger (#210) and place over the shift shaft in the gear housing. Secure the plunger onto the shifter shaft with the shoulder bolt (#209), use Red 263 Loctite on the threads. Install the plug (#221) in the gear housing.




Manual Shift

1. Slide the clutch springs (#224) into the gear housing. Lightly coat the shifter shaft assembly with 75w90 synthetic gear oil. Slide the shifter shaft assembly (#225) into the gear housing. Slide the clutch handle (#106) on the shifter shaft assembly and lock in place with the roll pin (#118).
2. Install the setscrew (#226) to hand tight then back off 1/4 turn. Use the jam nut (#227) to secure the setscrew.




Gear Housing

1. Lightly lubricate the O-ring (#218) with MOBILITH SHC 007 grease and place on the O-ring adapter (#204). Press the O-ring adapter into the gear housing.




Installing the Gear Sets

1. Place the O-ring (#217) and carrier spacer (#206) onto the input sun gear (#215). Slide the input sun gear into the gear housing. Generously apply MOBILITH SHC 007 grease to the sun gear teeth.
2. Install the input ring gear (#213) into the gear housing. Generously apply MOBILITH SHC 007 grease to the input ring gear's teeth. Wipe off any excess from the side of the ring gear. Slide the input carrier assembly (#202) into the input ring gear.
3. Place the carrier spacer (#206) onto the input carrier assembly. Insert the output sun gear (#214) into the input carrier assembly. Lightly apply MOBILITH SHC 007 to the sun gear teeth.
4. Lightly coat the outside of the output ring gear with 75w90 synthetic oil. Insert the output ring gear (#212) into the gear housing. Lightly apply MOBILITH SHC 007 grease to the output ring gear's teeth. Wipe off any excess from the side of the ring gear. Insert the output carrier assembly (#201) into the output ring gear. Ensure it properly aligns with the output sun gear.




End Bearing Assembly

1. Lubricate the O-ring (#216) with grease and place in the channel in the gear housing.
2. Align the end bearing (#203) on the output carrier assembly. Orient the end bearing as necessary. Use the capscrews (#207, #208) to attach the end bearing to the gear housing.




Assembling the Brake


1. Install the springs (#122) in the gear housing. Place the brake disc (#113) and cam plate (#107) on the springs. Place the long leg of the preload spring (#120) into the hole in the input sun gear. Install the brake hub (#112) where the short leg of the spring is in the hole of the brake hub and the brake hub is piloted on the input sun gear.
2. Insert the brake actuator (#115) into the brake hub until it rests on the internal lugs of the brake hub. Rotate the brake actuator and press fully into the brake hub. Insert the thrust washer (#123) into the brake actuator.
3. Press the cam pilot (#109) into the brake spacer (#108). Lubricate the O-ring (#117) with grease and place into the groove. Place the brake spacer on the gear housing. Ensure the O-ring sits in the groove of the brake spacer. Lubricate the O-ring (#117) and place in top groove of the brake spacers.



4. Place the cam (#107) on the brake hub. Align the cam to hit the corner of the cam surface in the relaxed position per cam alignment picture. Ensure the cams can rotate so they are fully collapsed. Install the brake discs (#114), the stator plates (#104), separator plates (#105) and wave washers (#121) in the order shown.




5. Place the dowel pins (#124) in the slots of the stator plates. Wrap a string around the outside of the dowel pins to prevent them from falling over. Lower the brake housing (#103) and align with all the dowel pins. Once the brake housing is on the dowel pins, remove the string and use a 5/8" hex shaft to rotate the brake actuator to close the brake.
6. While holding down the brake housing, install the sealing washers (#119) and capscrews (#111). Lightly lubricate the O-ring (#116) with grease and install the brake housing.
7. Install the brake cover (#102) with capscrews (#110).




Drum Assembly

1. Place a little MOBILITH SHC 007 grease on each of the dowel pins (#17) to hold them in place in the output carrier. Lower the drum (#15) onto the dowel pins ensuring they are properly lined up. Lightly grease the O-ring (#20) and slide onto the shaft (#5). Insert the roll pin (#16) into the coupling (#14) and slide onto the shaft. Slide the shaft through the drum and into the gear box.




Motor Installation

1. Install the thrust disc (#19), spring (#18), and the drag brake (#4) into the motor assembly (#2). Start sliding the motor assembly into the coupler.
2. Slide a spring tensioner spacer (#6) onto each end of the shaft of the spring tensioner. Place the spring tensioner assembly (#3) into the detent in the gear housing assembly. Align the spring tensioner with the detent in the motor assembly and slide the motor assembly fully into coupler. Use the capscrow (#11) to loosely install one side of the spring retention plate (#8) and the end bearing with the washers (#12) sandwiched between the two. Hold the spring retention plate vertical. Pull the legs of the springs back and rotate the spring retention plate and start the capscrows (#11).
3. Install jam nut (#13) onto the adjustment screw and hand-tighten the adjustment capscrow (#20) into the motor end bearing. Tighten the jam nut to specification.




Tie Bar Installation

1. Install the tie bars (#7) with the capscrews (#9).



Assemblies and BOMs


Main Winch



Main Winch BOM

ITEM #	QTY.	PART NUMBER	DESCRIPTION
1	1	297084	GEAR SIDE ASSEMBLY- B Rotation, Manual Shift
		297093	GEAR SIDE ASSEMBLY- B Rotation, Air Shift
		297095	GEAR SIDE ASSEMBLY- A Rotation, Manual Shift
		297094	GEAR SIDE ASSEMBLY- A Rotation, Air Shift
2	1	297086	MOTOR ASSEMBLY
3	1	297088	ROLLER TENSIONER ASSEMBLY- Long Drum
		297096	ROLLER TENSIONER ASSEMBLY- Short Drum
4	1	330010	DRAG BRAKE
5	1	357565	INPUT SHAFT - Long Drum
		357566	INPUT SHAFT - Short Drum
6	2	362350	SPACER
7	2	395458	TIE PLATE - Long Drum
		395476	TIE PLATE - Short Drum
8	1	395461	SPRING RETENTION PLATE - Long Drum
		395477	SPRING RETENTION PLATE - Short Drum
9	8	415409	CAPSCREW - M12X1.75X25mm SOCKET HEAD
10	1	415410	CAPSCREW - M12X1.75X35mm SOCKET HEAD
11	2	415415	CAPSCREW - M8 X 1.25 X 20mm LONG, FLAT SOCKET HEAD
12	2	418167	WASHER-5/16 SAE FLAT Z/P
13	1	418546	JAM NUT
14	1	431058	COUPLING
15	1	436075	DRUM-Long Drum
		436076	DRUM-Short Drum
16	1	470018	ROLL PIN
17	6	470155	DOWEL PIN
18	1	494154	SPRING
19	1	518099	THRUST DISC
20	1	462078	O-RING-.549 ID X .103 THK, 2-113, SHIFTER SHAFT


Brake Assembly Manual Shift



Brake Assembly Manual Shift BOM

ITEM #	QTY.	PART NUMBER	DESCRIPTION
101	1	297085	GEAR BOX ASSEMBLY
102	1	297104	BRAKE COVER
103	1	328196	BRAKE HOUSING
104	2	330024	BRAKE STATOR
105	2	330025	SEPARATOR PLATE
106	1	336010	HANDLE
107	2	340083	CAM PLATE-DRIVEN
108	1	362348	BRAKE SPACER
109	1	412177	CAM PILOT
110	4	415402	SCREW - M5X0.8X10mm FLAT HEAD
111	6	415412	CAPSCREW - M6 X 1.0 X 30mm LONG
112	1	431057	BRAKE HUB
113	1	438048	BRAKE DISC
114	3	438049	BRAKE DISC
115	1	438050	BRAKE ACTUATOR
116	1	462119	O-Ring
117	2	462123	O-RING -160
118	1	470033	SPIROL PIN
119	6	486107	WASHER SEALING
120	1	494147	SPRING - B ROTATION
		494144	SPRING - A ROTATION
121	6	494150	WAVE WASHER
122	4	494151	SPRING
123	1	518091	THRUST DISC
124	3	470162	DOWEL PIN


Gear Box Assembly Manual Shift



Gear Box Assembly Manual Shift BOM

ITEM #	QTY.	PART NUMBER	DESCRIPTION
201	1	247045	OUTPUT CARRIER ASSEMBLY
202	1	247049	INPUT CARRIER ASSEMBLY
203	1	297102	END BEARING ASSEMBLY
204	1	300077	ORING ADAPTER
205	1	328188	GEAR COVER
206	2	362347	SPACER
207	8	415405	CAPSCREW - M8X1.25X35mm BUTTON HEAD SOCKET
208	4	415413	M8 X 1.25 X 40mm FLAT HEAD SOCKET CAPSCREW
212	1	444120	OUTPUT RING GEAR
213	1	444126	INPUT RING GEAR
214	1	444144	OUTPUT SUN GEAR
215	1	444145	INPUT SUN GEAR
216	1	462114	O-RING -168
217	1	462124	ORING
218	1	462125	ORING
224	2	494143	SPRING
225	1	276065	SHIFTER ASSEMBLY
226	1	416288	SETSCREW - M5 X0.8X8mm EXTENDED POINT
227	1	418545	JAM NUT


Brake Assembly Air Shift



Brake Assembly Air Shift BOM

ITEM #	QTY.	PART NUMBER	DESCRIPTION
101	1	297092	GEAR BOX ASSEMBLY
102	1	297104	BRAKE COVER
103	1	328196	BRAKE HOUSING
104	2	330024	BRAKE STATOR
105	2	330025	SEPARATOR PLATE
107	2	340083	CAM PLATE-DRIVEN
108	1	362348	BRAKE SPACER
109	1	412177	CAM PILOT
110	4	415402	SCREW - M5X0.8X10mm FLAT HEAD
111	6	415412	CAPSCREW - M6 X 1.0 X 30mm LONG
112	1	431057	BRAKE HUB
113	1	438048	BRAKE DISC
114	3	438049	BRAKE DISC
115	1	438050	BRAKE ACTUATOR
116	1	462119	O-Ring
117	2	462123	O-RING -160
119	6	486107	WASHER SEALING
120	1	494147	SPRING - B ROTATION
		494144	SPRING - A ROTATION
121	6	494150	WAVE WASHER
122	4	494151	SPRING
123	1	518091	THRUST DISC
124	3	470162	DOWEL PIN


Gear Box Assembly Air Shift



Gear Box Assembly Air Shift BOM

ITEM #	QTY.	PART NUMBER	DESCRIPTION
201	1	247045	OUTPUT CARRIER ASSEMBLY
202	1	247049	INPUT CARRIER ASSEMBLY
203	1	297102	END BEARING ASSEMBLY
204	1	300077	ORING ADAPTER
205	1	328197	GEAR COVER
206	2	362347	SPACER
207	8	415405	CAPSCREW - M8X1.25X35mm BUTTON HEAD SOCKET
208	4	415413	M8 X 1.25 X 40mm FLAT HEAD SOCKET CAPSCREW
209	1	418549	SHOULDER BOLT
210	1	426070	PLUNGER
211	1	433027	AIR CYLINDER
212	1	444120	OUTPUT RING GEAR
213	1	444126	RING GEAR
214	1	444144	OUTPUT SUN GEAR
215	1	444145	ADAPTER-SUN GEAR
216	1	462114	O-RING -168
217	1	462124	ORING
218	1	462125	ORING
219	2	470018	ROLL PIN
220	1	470159	PIN-SPRING, n.125 X .5 LG
221	1	472052	PLUG-#6 SAE O-RING PORT
222	2	488007	SHIM
223	1	489039	SHIFTER SHAFT
224	2	494143	SPRING


Roller Tensioner Assembly



Roller Tensioner Assembly BOM

ITEM #	QTY.	PART NUMBER	DESCRIPTION
401	2	346071	ROLLER SHAFT
402	1	346072	TENSIONER BAR
403	1	350775	ARM
404	1	350776	LEVER ARM
405	1	354065	ROLLER
406	4	412108	BUSHING
407	4	414819	CAPSCREW-.250-20UNC X .50 LG.
408	2	418223	WASHER-1/2 FLAT
409	2	490079	RETAINING RING
410	1	494145	SPRING-TORSION
411	1	494146	SPRING-TORSION


Motor Assembly



Motor Assembly BOM


ITEM #	QTY.	PART NUMBER	DESCRIPTION
301	1	297103	END BEARING ASSEMBLY
302	1	458050	MOTOR
303	2	415409	CAPSCREW - M12X1.75X25mm SOCKET HEAD

Dimensional Drawing - Manual Shift



- NOTES:
1. DIMENSIONS SHOWN ARE INCHES OVER MILLIMETERS.
 2. WINCH MOUNTING CAPSCREWS MUST MEET OR EXCEED SAE GRADE 5 SPECIFICATION.
 - *3. THESE HOLE LOCATIONS MUST BE HELD WITHIN ± 0.03 (0.8mm) OF TRUE POSITION. RECOMMENDED MOUNTING HOLE DIAMETER IS .50 (12.7mm)
 4. "B" ROTATION SHOWN

Dimensional Drawing - Air Shift



- This page intentionally left blank -

Limited Warranty

RAMSEY WINCH warrants each new RAMSEY WINCH to be free from defects in material and workmanship for a period of two (2) years from date of purchase.

The obligation under this warranty, statutory or otherwise, is limited to the replacement or repair at the Manufacturer's factory, or at a point designated by the Manufacturer, of such part that shall appear to the Manufacturer, upon inspection of such part, to have been defective in material or workmanship.

This warranty does not obligate RAMSEY WINCH to bear the cost of labor or transportation charges in connection with the replacement or repair of defective parts, nor shall it apply to a product upon which repair or alterations have been made, unless authorized by Manufacturer, or for equipment misused, neglected or which has not been installed correctly.

RAMSEY WINCH shall in no event be liable for special or consequential damages. RAMSEY WINCH makes no warranty in respect to accessories such as being subject to the warranties of their respective manufacturers.

RAMSEY WINCH, whose policy is one of continuous improvement, reserves the right to improve its products through changes in design or materials as it may deem desirable without being obligated to incorporate such changes in products of prior manufacture.

If field service at the request of the Buyer is rendered and the fault is found not to be with RAMSEY WINCH's product, the Buyer shall pay the time and expense to the field representative. Bills for service, labor or other expenses that have been incurred by the Buyer without approval or authorization by RAMSEY WINCH will not be accepted.

For more information or to make a warranty claim, contact your local distributor or RAMSEY WINCH customer service.



Ramsey Winch Company

P.O. Box 58151 - Tulsa, OK, 74158-1510 USA

Phone 1-800-777-2760 - Fax (918) 438-6688

<http://www.ramsey.com>