



BEFORE YOU START

1

- The Receiver is designed to carry a maximum of 5 Amps, with an individual output maximum of 3 Amps. If you need to switch higher currents, then you should consider other series which can switch up to 15 Amps.
- Master Output. Continuous or Parallel operation,
- Receiver outputs, when connected in parallel with an external switching device (wired remote), will instantly switch off if the wired remote is operated. This is a feature of the safety circuits.
- Lodar Receivers **MUST** have an **isolation switch** to allow for registering a replacement Transmitter and a **FUSE** for safety.
- Safety Feature. Both the Transmitter and the Receiver will switch off after 30 minutes of inactivity. Other Timeouts are available, ask your dealer.

2

IDENTIFY POWER CONNECTION POINT AND ISOLATE SUPPLY

Remove fuse




or Disconnect Battery



3

MOUNT RECEIVER


CAUTION

 POSITIVE
NEGATIVE


TAKE TIME TO LOCATE THE BEST POSITION

If necessary, power the Receiver and move it around the vehicle until the required performance is achieved. Operate the Transmitter and observe the Receiver internal LED's.

 Mount as **HIGH** as possible

AVOID surfaces with **HEAVY VIBRATION**
AVOID DIRECT SPRAY from wheels

 In a **HOT CLIMATE** fit in a **SHADED** position

 Cable gland should face **DOWN** or **BACK**


Receiver P11RX04 Series

Waterproof to IP67 complete with 1.5 metres (5ft) cable

Secure using 5mm (3/16") bolts (not supplied) through the 2 mounting feet

ALL TRANSMITTERS FOLLOW THIS NUMBERING CONVENTION

4



CONNECT WIRES

When F1 is pressed the GREEN wire gives an output etc.

Make notes here.



Wire Colour	Wire used for	11RX00	11RX02	11RX04
RED	12/24 VDC Nominal Positive Supply			
BLACK	0 Volts (Ground)			
GREEN	Output Function 1 (F1 Button)			
YELLOW	Output Function 2 (F2 Button)			
BROWN	Output Function 3 (F3 Button)	Not Present	Not Available	
BLUE	Output Function 4 (F4 Button)	Not Present	Not Available	
WHITE	Master - pre configured to your requirement	Not Present		

What is the MASTER Output for ?

It is used to operate the pump of an electro-hydraulic power pack or maybe a clutch pump. It can also be used for powering a dump valve, master valve etc. It can be configured to work **continuously**, that is ON when SET is pressed and OFF when STOP is pressed; or in **parallel** with any output, that is, it is active only a function is operated. If it is needed with certain functions only, this can easily be configured.

5

Replace fuse



ACTIVATE THE RECEIVER SUPPLY

or re-connect Battery

6


CONNECT TRANSMITTER BATTERY

Batteries generally have to be disconnected when shipping.

7

TEST

 Press the Transmitter **RESET** button to activate the system, and carefully test each function for correct operation.



Fault Codes - Number of flashes indicate Fault Code.
"1 = Flash Pause, 2 = Flash, Flash, Pause, etc"

- 1 = OUTPUT FAULT - F1 to F4
- 2 = SAFETY VOLTAGE FAULT (LOW VOLTAGE)
- 3 = MASTER VOLTAGE FAULT (LOW VOLTAGE)
- 6 = OVER TEMPERATURE FAULT
- 7 = SYSTEM FAILURE - COMMS FAULT

LOW VOLTAGE = LESS THAN 6 VOLTS
OVER TEMPERATURE = GREATER THAN 100°C