



316 W. Milwaukee St., PO Box 511
New Hampton, Iowa 50659

Call: **800-222-6047**

Web: **Zips.com**

21-5 CYCLE DOLLY INSTRUCTIONS

WEIGHT CAPACITY 900 LBS. DO NOT EXCEED CAPACITY!

Before loading the Cycle Dolly, inspect the motorcycle to be towed to ensure suitable tie-down points exist. Some motorcycles such as the BMW K1200LT and BMW police models lack suitable tie-down points and the 21-5 Cycle Dolly may not be suitable to tow these motorcycles.

Prepare Cycle Dolly for use by flipping wheel stop into raised position, then insert outriggers into outrigger receiver (tie down ring near wheel should face up) and secure outriggers with hitch pins provided.

Roll motorcycle to be towed onto Cycle Dolly until front wheel of motorcycle contacts wheel stop of Cycle Dolly. It may be necessary to chock wheels of Cycle Dolly or have helper hold Dolly so it won't roll. Roll bike onto Cycle Dolly. At this point most motorcycles will stand on their kickstand. Leave motorcycle on its kickstand or have helper hold motorcycle upright and proceed to next step. Helpful hint: To make loading easier place motorcycle in gear and hold clutch in. When front wheel contacts wheel stop, let go of clutch and bike won't roll.

Pass the ratchet strap on wheel stop through the front wheel of the motorcycle and back through the ratchet and tighten.

Secure motorcycle to Cycle Dolly with the two 1" x 6' straps and ratchets by hooking one end of the strap to the tie-down ring on the outrigger and the other end to a secure point on the motorcycle's handle bars. For ease of use, the ratchet end of the strap until motorcycle's fork is slightly compressed and the motorcycle is secure on the Cycle Dolly. (When unloading, make sure the motorcycle is held securely when the straps are released. If not held securely, the motorcycle could fall over.)

Run a second pair of straps, one on either side of the motorcycle, from the rings on the outriggers to the foot pegs or other secure points on the rear of the motorcycle. This will keep the handlebars from twisting and prevent the Cycle Dolly from rolling with the motorcycle's front wheel (since the Cycle Dolly is made short enough to fit in a 24" tool box, and it is secured to the motorcycle's front wheel, it is possible for the Cycle Dolly to roll with the front wheel).

FAILURE TO SECURE MOTORCYCLE TO CYCLE DOLLY WITH 5 STRAPS PER INSTRUCTIONS COULD RESULT IN DAMAGE TO MOTORCYCLE AND/OR INJURY TO OPERATOR.

Attach hooks of your V-Chain or V-Strap to the tie-down rings on the outriggers and use the rollback's winch to pull the Cycle Dolly and motorcycle onto the rollback.

Using the 16' straps, secure the motorcycle to the rollback.