

51 Winthrop Road

Chester, Connecticut 06412-0684

Phone: (860) 526-9504 Internet: www.whelen.com

Sales e-mail: autosale@whelen.com

Customer Service e-mail: custserv@whelen.com

Installation Guide: Pedestal Mount Kit M2 series Lighthead

Mounting

1. Position the Pedestal Mount Base (Item 7 or 8) onto the proposed mounting surface.


NOTE! Mounting this product requires drilling through the mounting surface. It is absolutely necessary to make sure that no other vehicle components could be damaged by this process.

- 2. Using the base as a template, mark the location of the two mounting holes using a scribe or similar tool.
- Remove the base and drill the two mounting holes using a .281 drill bit. Deburr these holes before continuing.
- 4. Return the base to its mounting position and secure it using the hardware provided (Items 9, 10 & 11).
- Locate the housing included with this kit (Item 3 or 4).
 Route the wires from your M2 lighthead (sold separately) through the housing as shown.

- Secure the lighthead to the housing using the bushings included with your lighthead and the screws included with the pedestal mount kit (item 12). Do <u>not</u> use the screws included with your lighthead.
- Insert the hexagonal standoff (item 6) into the base as shown. Position the lighthead/housing assembly onto the base and install hardware items 1, 2 & 5.
- Adjust the lighthead/housing assembly to the desired angle and tighten the appropriate hardware.

Wiring

Refer to the manual included with your lighthead for important wiring and fusing information.



DESCRIPTION

M2 PEDESTAL MOUNT KIT (BLACK)

M2 PEDESTAL MOUNT KIT (CHROME)