

FF750

FORD

INSTALLATION INSTRUCTIONS

- a) Raise vehicle allowing the axle to hang freely.
- b) Remove existing bump stop assembly.
- c) Assemble Aeon rubber spring and bracket as shown in the adjacent diagram.
- d) Mount Timbren assembly using existing holes & Timbren supplied fasteners.
- e) Lower vehicle.

INSTRUCTIONS DE MONTAGE

- a) Soulever le véhicule de sorte que l'essieu soit dégagé.
- b) Retirer l'assemblage de la butée de suspension existante.
- c) Assembler le ressort en caoutchouc Aeon et le support comme il est indiqué dans le schéma adjacent.
- d) Monter l'assemblage Timbren en utilisant les trous existants et la boulonnnerie fournie avec l'assemblage Timbren.
- e) Redescendre le véhicule.

Front suspension package  
Ensemble pour suspension avant  
Ensemble para suspensión de delantero

INSTRUCCIONES DE INSTALACIÓN

- a) Levante el vehículo dejando que los ejes cuelguen libremente.
- b) Retire la unidad del tope de suspensión existente.
- c) Ensamble el resorte de caucho Aeon y la abrazadera como se muestra en el diagrama adyacente.
- d) Monte la unidad Timbren utilizando los orificios existentes y los elementos de sujeción Timbren provistos.
- e) Baje el vehículo.



Do not exceed vehicle manufacturer's recommended axle weight rating. Check for AEON® interference with vehicle components - Under load AEON® will "expand" in diameter.

Ne pas dépasser le poids nominal sur l'essieu recommandé par le fabricant du véhicule. Vérifier que le ressort AEON® n'a pas d'incidence sur d'autres pièces du véhicule - Le ressort AEON® augmentera son diamètre avec la charge.

No exceda la carga nominal en el eje recomendada por el fabricante del vehículo. Compruebe que no haya interferencia entre el resorte AEON® y los otros componentes del vehículo. Bajo carga, el resorte AEON® se amplía en diámetro.

Ref. = Reference = No. de référence = Núm. de referencia  
Part = Part #. = No. de pièce = Núm. de pieza  
Qty. = Quantity = Quantité = Cantidad

Ref	Part	Qty
1	F31007-150	8
2	F11142-150	8
3	K10326-003	2
4	A00540-65E60	2
5	F11103-150	2



FF750

TIMBREN

# FF750

TIMBREN INDUSTRIES INC.

[www.timbren.com](http://www.timbren.com)

PART NUMBER	DESCRIPTION	QTY	LOCATION
<b>F31007-150</b>	NYLOCK LOCKNUT 5/8 UNF GR 5 Z	<b>8</b>	<b>H2E</b>
<b>F11142-150</b>	HCS 5/8 x 1-1/2 UNF GR 5 Z	<b>8</b>	<b>H2E</b>
<b>F11103-150</b>	HCS 1/2 x 1-3/4 UNF GR 5 Z	<b>2</b>	<b>G1D</b>
<b>A00540-65E60</b>	Hollow Rubber Spring	<b>2</b>	<b>C8B</b>
<b>K10326-003</b>	FF750 WELDMENT PAINTED	<b>2</b>	<b>D13E</b>
<b>B90201-CF</b>	LARGE FRONT BOX - 10.5 x 8.5 x 6	<b>1</b>	<b>A--D</b>
<b>B10000</b>	8" x 12" BUBBLE FOR KITS	<b>1</b>	
<b>B00029-010</b>	BARCODE LABEL FOR KIT	<b>1</b>	

Issued: 4/11/2003

## Clearance Instructions:

Rear SES Kits for Pick-Ups and Vans should have a 1/2" to 1-1/2" gap between the rubber spring and contact point when empty.

A partial load, or vehicle accessories will reduce or eliminate the gap.

Front SES kits are usually in full contact.

Medium and Heavy-Duty Trucks, Trailers and Motorhomes will be in constant contact, and have no gap.

## Lifetime Warranty:

Timbren SES Kits are warranted against defects in material and workmanship, under normal use and service, for the life of the vehicle on which the kit was originally installed. The warranty is not transferable and proof of purchase is required. The warranty is limited to the replacement of the failed part.

TIMBREN will not be responsible for any labour or freight charges involved in the replacement of any product. TIMBREN shall be entitled to make its own inspection to determine the validity of the claim. TIMBREN shall not be liable nor warranty the product in the event of alteration, misuse, overload, negligence or damage caused by others.

If ride or performance of our product is unsatisfactory in any way, please call: 1-800-263-3113 or email [sales@timbren.com](mailto:sales@timbren.com)