

# DIVERSIFIED PRODUCTS MFG.



8330 Atlantic Blvd., Jacksonville, FL 32211  
Sales@Pushbumper.com (904)724-0310

SHEET #  
1 OF 1

## PB-9510 - I SERIES PUSHBUMPER


PART #	SUGGESTED APPLICATION	WEIGHT	BUMPER SIZE
PB-9510-1	2023+ FORD F450/550/600 2x4 & 4x4	281	83 1/2 x 17
PB-9510-1C	2023+ FORD F450/550/600 2x4 & 4x4 w/GRILLE GUARD	326	83 1/2 x 17
PB-9510-1D	2023+ FORD F450/550/600 2x4 & 4x4 w/HD GRILLE GUARD	346	83 1/2 x 17

C = 20 1/2  
D = 20 1/2



### INSTALLATION PROCEDURE:

1. Remove factory side braces from the frame horns to the outside of bumper.
2. Unbolt the factory bumper and remove it. Do not remove tow hooks.
3. Bolt new bumper brackets to truck frame horn using bolts on sides of frame horns by tow hooks. Position brackets with bolts in the middle of the slots to start. Snug but do not tighten bolts now. Loosely bolt 4 bracket supports to 4 bumper brackets.
4. Position the bumper top 1/2" below the bottom of the trucks head light assembly.
5. Loosely bolt bumper brackets to bumper.
6. Loosely bolt on side frame braces to hole in the bottom lip of the pushbumper. Attach other end to slot in bottom of the frame horn or provided hole in weight plate when it is used.
7. Align bumper for proper fit and securely tighten frame to bumper bracket bolts before tightening the remaining bolts.
8. Shimming may be required to align bumper due to truck body and frame tolerances.
9. Drill 2 holes in frame thru provided holes in each bumper bracket & add bolts.



**OPTIONAL WEIGHT PLATE KIT**  
155 LBS w/ 50 lb. ADD ON WEIGHT  
PLATES AVAILABLE.

### IMPORTANT NOTE:

Use CAUTION on Air Bag equipped vehicles. Avoid impact which could activate the air bag sensor while pushing.

DJR  
8/12/23