


DIVERSIFIED PRODUCTS MFG.

8330 Atlantic Blvd., Jacksonville, Fl. 32211
Sales@Pushbumper.com (904)724-0310

SHEET #
1 OF 1


PB-9500 - I SERIES PUSHBUMPER

PART #	SUGGESTED APPLICATION	WEIGHT	BUMPER SIZE
PB-9500-1	2023+ FORD F250/350 2x4	225	78 1/4 x 14
PB-9500-1C	2023+ FORD F250/350 2x4 w/GRILLE GUARD	267	78 1/4 x 14
PB-9500-1D	2023+ FORD F250/350 2x4 w/HD GRILLE GUARD	287	78 1/4 x 14




INSTALLATION PROCEDURE:

1. Remove factory side braces from the frame horns to the outside of bumper.
2. Unbolt the factory bumper and remove it. Do not remove tow hooks.
3. Bolt new bumper brackets to truck frame horn using bolts on sides of frame horns by tow hooks. Position brackets with bolts in the middle of the slots to start. Snug but do not tighten bolts now. Loosely bolt 4 bracket supports to 4 bumper brackets. Install optional weight plate as shown. (If being used)
4. Position the bumper top 1/2" below the bottom of the trucks head light assembly.
5. Loosely bolt bumper brackets to bumper.
6. Align bumper for proper fit and securely tighten frame to bumper bracket bolts before tightening the remaining bolts.
7. Shimming may be required to align bumper due to truck body and frame tolerances.
8. Drill 2 holes in frame thru provided holes in each bumper bracket & add bolts.



OPTIONAL WEIGHT PLATE KIT
15 LBS w/ 50 lb. ADD ON WEIGHT
PLATES AVAILABLE.



USE EXISTING BOLT LOCATION ON FRAME

SIDE FOR TOW HOOKS SUPPORT PLATE.

TYP. EACH SIDE OF FRAME HORN.

ALL 4 BRACKETS.

FACTORY

TOW HOOK

LAST PROCESS:
DRILL $\phi 1/2$ " HOLE's
2 LOCATIONS ON
ALL 4 BRACKETS.

BRACKET SUPPORTS 4 PCS

IMPORTANT NOTE:

Use CAUTION on Air Bag equipped vehicles. Avoid impact
which could activate the air bag sensor while pushing.