



Zip's Lift Assist Dolly Mount

Mounting Guidelines

Item #: ZP-DM-SL

For use with any brand of tow dolly with adjustable saddle and adjustable tire stands.



Measure spacing

Optimum mounting measurement is to be no less than 8" and no more than 10" from inside the body rail to the front of the mounting plate.



Check clearance

Make sure you check for clearance under the mounting surface so you do not drill directly into a toolbox wall. Depending on the type of material your body side is made from, you will need to determine if it needs additional support under the mount. Best practice is to support the bracket by tying to the toolbox wall.