Installation Guide for Dolly Bunk ITD1022 & ITD1023

Below is a list of parts you will need to install a set of Dolly Bunks.

Mounting hardware is **NOT** included with product.

Minimum Required Mounting Hardware List:



(14) 5/16" Bolts (Grade 5 or better)



(14) 5/16" Nuts (Grade 5 or better)



(28) 5/16" Washers




MOUNTING INSTRUCTIONS


READ ALL SAFETY WARNINGS & INSTRUCTIONS CAREFULLY BEFORE MOUNTING OR OPERATING YOUR DOLLY BUNKS.





Parts List:

| Item # | Qty | Description | Part # (ITD1023) | Part # (ITD1022) |
|--------|-----|-------------------------|---------------------|---------------------|
| 1 | (4) | Dolly Bunk Side | ITD6662 | ITD6997 |
| | | *Mirrored Parts | | |
| 2 | (2) | Dolly Bunk Center Latch | ITD6663 | ITD6998 |










For missing or damaged parts, please call 1-888-993-4824



Due to variances in tool box & dolly designs, ITD cannot provide explicit mounting requirements for every mounting option. These are only guidelines, final installation requirements are left to the discretion of a qualified installer. ITD will NOT warrantee any damage to tool boxes or dollies resulting from inadequate mounting. A qualified installer needs to make sure that there is no way a dolly can unexpectedly come loose from the dolly bunk! We recommend you use the Speed Dolly® with this bunk.

Figure A

Center Line





Step 1

Determine the width the bunk sides need to be spaced. Take overall width of dolly and add 1/2" for clearance.

Step 2 (Fig A)

Layout bottom of toolbox.

- -Create centerline for dolly placement.
 -Mark a line 1/2 the required distance for
- proper dolly spacing, either side of center-line.

Step 3

Hold each side of dolly bunk against marked line. Mark a minimum of 3 mounting holes per bunk side.

Step 4

Bolt each side to tool box using a minimum of (3) 5/16" bolts, (6) 5/16" washers, & (3) 5/16" nuts.

Note: It is recommended to use some nut locking device (nylok, loktite, etc)

Step 5 (Fig B)

Mark and bolt center locking section on centerline of toolbox. Mount locking section rearward so that it holds dolly to the back of mount, with minimum slack in chain.

Locking Note:

To lock dolly use supplied safety chain to wrap around dolly tube. Then feed free end of chain through round portion of key hole slot. Slide chain into slot between two links. Secure the free end of chain with a pad-lock or other device to ensure chain can not unexpectedly come loose!

IT IS IMPORTANT TO VERIFY ALL HARDWARE IS SECURE AND TIGHT. THIS INCLUDES BUT IS NOT LIMITED TO MOUNTING HARDWARE AND RETAINING CHAINS

Before First Use Checklist:

All nuts and bolts are tight, <u>pull on dolly</u>
<u>in all directions to validate the dolly can</u>
not fall out of dolly bunk.



Warning



☐ Inspect and retighten after first 10 uses

It is the drivers responsibility to make sure all items are secure on truck