

Installation Instructions

8891030 Wireless Mini Light Bar

Power on the wireless mini light bar by pressing the power button on top of the unit. Pressing the top button again will select the next flash pattern.

Power off the wireless mini light bar by pressing and holding the power button for three (3) seconds. When the unit is again powered on, it will resume the flash pattern that was selected when it was powered off.

When the light bar is powered on, the light near the power button indicates the battery level according to chart 1.

! IMPORTANT

Always make sure that the charging port plug is fully inserted during operation to prevent damage from dirt or moisture.

Charging the Wireless Light Bar

Before using the wireless light bar, it must be charged. To charge the unit, remove the plug from the connector on the bottom of the light bar and insert the power cord into the connector. Plug the power cord into an appropriate auxiliary power connection in your vehicle.

The unit will reach full charge in 4.5 hours. Charging status is indicated by the light near the power button according to chart 1. The light will turn green when charging is complete.

When charging is complete, remove the power cord and ensure that the plug is fully inserted into the charging connector. This will ensure that the light bar is protected from dirt and moisture.

WARRANTY

Buyers Products Co. warrants all truck/trailer hardware manufactured or distributed by it, to be free from defects in material and workmanship for a period of one year from date of shipment. Parts must be properly installed and used under normal conditions. Any product which has been altered, including modification, misuse, accident or lack of maintenance will not be considered under warranty. Normal wear is excluded. The sole responsibility of Buyers Products Co. under this warranty is limited to repairing or replacing any part or parts which are returned, prepaid, and are found to be defective by Buyers Products Co. Authorization from Buyers Products Co. must be obtained before returning any part. No charges for transportation or labor performed on Buyers' products will be allowed under this warranty.



CHART 1

status	level	Light Indication
Charging	0-30%	Red
	30%-90%	Yellow
	100%	Green
In Use	<10%	Red, Flashing
	10%-30%	Red
	30%-70% 70%-100%	Yellow Green

CHART 2

Number	Pattern
1	single flash
2	single flash rapid
3	double flash
4	triple flash
5	quad flash
6	clockwise chase (SAE)
7	counterclockwise chase (SAE)

! WARNING

Do not look directly into LED's while in operation; may cause momentary blindness and/or eye damage.

! WARNING

It is not recommended to use magnetically mounted warning devices on vehicles in motion. Usage is at the sole risk and responsibility of the user.