

## Zips Allegiant - Wire Guide

Red - Lightbar Current (wire to ignition w/ relay)

Brown- Mode 1 (Red)

Orange - Mode 2 (White)

Yellow - Mode 3 (Amber)

Blue - Worklight / Bedlight

Green - Signal Master Left

Grey - Signal Master Right

Green/Grey - Center Out

Brown/White - Dim/Pattern Change

- Tap dim 5 times to +12 to unlock pattern change

Black - Ground

- Mode 1 activates only red LED heads
- Mode 2 activates only white LED heads
- Mode 3 activates only amber LED heads
- If all modes are active, all color LED heads will be active