Hub Puller

10901



Have What It Takes

Safety Warning

Read all instructions and safety warnings prior to operation. Failure to do so could result in equipment damage, personal injury or even death.

- Stay Alert! Watch what you are doing and use common sense when operating this tool.
- Inspect product for damage prior to using; do not use if product is in unsafe condition.
- Do not operate tool while under the influence of drugs, alcohol or medication.
- Always use safety equipment to prevent injuries. Approved face and eye protection must always be worn by the operator, as well as others in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Dress properly. Do not wear loose clothing or jewelry.
 Keep your hair, clothing and gloves away from moving parts.
- · Keep your work area clean and well lit.

Operating Instructions

- 1 Remove the hub cap.
- 2 Ensure the hub threads are in good condition, clean and free of debris.
- 3 Back the forcing screw of the hub puller out.
- 4 Thread the tool into the hub by hand using the two tabs on the side of the tool. If the tool will not thread in by hand, check hub threads for damage.
- 5 Once the tool is tight on the hub, begin to turn the forcing screw with either a hand or impact wrench. (Up to ½" drive.)
- 6 Once the wheel assembly has been removed, unscrew the tool from the hub and repeat on the remaining hub(s).

Here at Tiger Tool, your satisfaction is our number one priority. Should you have any questions about this or any of our products, please call us at 1.800.661.4661.



Hub Puller

10901



Parts Breakdown



Item No.	Part Number	Description	Qty.
1	10901-1	Housing Fruehauf	1
2	10803-11	Forcing Screw	1
3	10901-4	Axle Plug	1
4	10901-5	O-Ring	1