

Hub Puller

10902

**TIGER
TOOL**

Have What It Takes

Safety Warning

Read all instructions and safety warnings prior to operation. Failure to do so could result in equipment damage, personal injury or even death.

- **Stay Alert!** Watch what you are doing and use common sense when operating this tool.
- Inspect product for damage prior to using; do not use if product is in unsafe condition.
- Do not operate tool while under the influence of drugs, alcohol or medication.
- Always use safety equipment to prevent injuries. Approved face and eye protection must always be worn by the operator, as well as others in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.
- Keep your work area clean and well lit.

Operating Instructions

- 1 Remove the hub cap.
- 2 Ensure the hub threads are in good condition, clean and free of debris.
- 3 Back the forcing screw of the hub puller out.
- 4 Using the bolt which fastens the cap onto the hub, secure the hub puller to the hub. **Do not over tighten.**
- 5 Begin to turn the forcing screw with either a hand or impact wrench. (Up to ½" drive.)
- 6 Once the wheel assembly has been removed, detach tool from the hub, and repeat on the remaining hub(s).

Here at Tiger Tool, your satisfaction is our number one priority. Should you have any questions about this or any of our products, please call us at 1.800.661.4661.



View demonstration videos and a complete product list at tigertool.com

Technical Support
1.800.661.4661

Hub Puller

10902

**TIGER
TOOL**

Have What It Takes

Parts Breakdown



Item No.	Part Number	Description	Qty.
1	10902-1	Housing Rockwell	1
2	10803-11	Forcing Screw	1
3	10901-4	Axle Plug	1
4	10901-5	O-Ring	1



View demonstration videos and a complete product list at [tigertool.com](https://www.tigertool.com)

Technical Support
1.800.661.4661