



SAFETY MINDED. FORWARD THINKING.

Ping

Advanced Warning System | [Startup Instructions](#)

Thank You for
Choosing SafeAll Ping!

To get started with your SafeAll Ping, **follow these simple steps:**

1 Activate Your Ping

- Locate the QR code under the lip of the box.
- Scan the QR code using your smartphone to activate your device.

2 Installing the SafeAll Ping

- Securely mount the SafeAll Ping inside the cab of your vehicle. Choose a spot that is easily accessible and does not obstruct your view or movement.

3 Connecting the Wiring

- Locate the three wires at the end of the Ping's main cable.
 - **Black wire:** Connect to a ground point.
 - **Red wire:** Connect to the key ignition power source.
 - **White wire:** Connect to a switch inside the cab.
 - This switch will activate the Ping and begin alerting nearby motorists via Waze that you are present and on the side of the road.

4 Using Your Ping

- Once installed, the SafeAll Ping operates seamlessly. Simply flip the designated switch when you need to alert others of your presence.
- After setup, you can forget about it—the system will handle everything automatically when activated.

Enjoy Safer Roads with SafeAll Ping!

