

Installation Instructions LED Grommet Mount Directional 3965 Series



WARNING!

Failure to install or use this product according to manufacturer's recommendations may result in property damage, serious bodily/personal injury, and/or death to you and those you are seeking to protect!



Do not install and/or operate this safety product unless you have read and understand the safety information contained in this manual.

- 1. Proper installation combined with operator training in the use, care, and maintenance of emergecy warning devices are essential to ensure the safety of you and those you are trying to protect.
- 2. Exercise caution when working with live electrical connections.
- 3. This product must be properly grounded. Inadequate grounding and/or shorting of electrical connections can cause high current arcing, which can cause personal injury and/or severe vehicle damage, including fire.
- 4. Proper placement and installation are vital to the performance of this warning device. Install this product so that output performance of the system is maximized and the controls are placed within convenient reach of the operator so that s/he can operate the system without losing eye contact with the roadway.
- 5. It is the responsibility of the vehicle operator to ensure during use that all features of this product work correctly. In use, the vehicle operator should ensure the projection of the warning signal is not blocked by vehicle components (i.e., open trunks or compartment doors), people, vehicles, or other obstructions.
- 6. The use of this or any other warning device does not ensure all drivers can or will observe or react to a warning signal.

 Never take the right-of-way for granted. It is your responsibility to be sure you can proceed safely before entering an intersection, driving against traffic, responding at a high rate of speed, walking on or around traffic lanes.
- 7. This equipment is intended for use by authorized personnel only. The user is responsible for understanding and obeying all laws regarding warning signal devices. Therefore, the user should check all applicable city, state, and federal laws and regulations. The manufacturer assumes no liability for any loss resulting from the use of this warning device.

Specifications:

Size: 7.5" length, 3.3" height, 2.1" depth

Weight: 0.4 lb Input Voltage: 12-24 VDC

Current Draw: 1.0 A (@ 12 VDC NOMINAL)

Installation & Mounting:


Cut a hole in the vehicle using the product as a template. Push the rubber grommet into the hole until it seats. Route wires from the light through the hole and connect to the vehicle wiring harnesses. Push the light into the grommet until it seats.

Wiring:

Important! This unit is a safety device, and it must be connected to its own seperate, fused power point to assure its continued operation should any other electrical accessory fail.

The 3965 Series of directional LED lights are self flashing when not in pattern 9. All wiring should be a minimum of 20 AWG. The positive line must have an in-line 2 amp slow-blow fuse for each directional as shown in Figure 1.

Directionals must be set to steady burn before a separate in-line flasher (accessory option listed below) is installed as shown in Figure 2.



DIRECTIONAL

REMOTE
PLASHER*

RED - POWER

BLACK - GROUND

+ -

FIGURE 1

FIGURE 2

Flash Pattern Selection:

The 3965 series directionals can be configured to flash the following patterns (in the order shown) by momentarily applying ground to the white wire. The directional must be powered through the ground and power wires to allow pattern selection.

Accessory and Replacement Parts:

Description	Part No.	
Remote Solid State Flasher	LEDFLASHER1	
3965X, 3965XX Oval Grommet	R2160G0	
3965X, 3965XX Oval Grommet Box	A9895	

3965X & 3965XX FLASH PATTERN CHART			
Pattern	Flash Pattern	FPM	SAE J595
1	Single	185	CLASS 2
2	Single	115	CLASS 2
3	Single	230	
4	Double	155	CLASS 2
5	Quint	70	CLASS 2
6	Single	360	
7	Double	75	CLASS 2
8	Quad	70	CLASS 2
9	Steady Burn	N/A	

^{**}Dual color units flash in split alternating patterns

Electronics Controls Company "ECCO" (Manufacturer)

ECCO warrants that on the date of purchase, this product will conform to ECCO's specifications for this product (which are available from ECCO upon request). This Limited Warranty extends for twelve (12) months from the date of purchase.

DAMAGE TO PARTS OR PRODUCTS RESULTING FROM TAMPERING, ACCIDENT, ABUSE, MISUSE, NEGLIGENCE, UNAPPROVED MODIFICATIONS, FIRE OR OTHER HAZARD; IMPROPER INSTALLATION OR OPERATION; OR NOT BEING MAINTAINED IN ACCORDANCE WITH THE MAINTENANCE PROCEDURES SET FORTH IN ECCO'S INSTALLATION AND OPERATING INSTRUCTIONS VOIDS THIS LIMITED WARRANTY.

Exclusion of Other Warranties:

ECCO MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED. THE IMPLIED WARRANTIES FOR MERCHANTABILITY, QUALITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE ARE HEREBY EXCLUDED AND SHALL NOT APPLY TO THE PRODUCT AND ARE HEREBY DISCLAIMED, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ORAL STATEMENTS OR REPRESENTATIONS ABOUT THE PRODUCT DO NOT CONSTITUTE WARRANTIES.

Remedies and Limitation of Liability:

ECCO'S SOLE LIABILITY AND BUYER'S EXCLUSIVE REMEDY IN CONTRACT, TORT (INCLUDING NEGLIGENCE), OR UNDER ANY OTHER THEORY AGAINST ECCO REGARDING THE PRODUCT AND ITS USE SHALL BE, AT ECCO'S DISCRETION, THE REPLACEMENT OR REPAIR OF THE PRODUCT, OR THE REFUND OF THE PURCHASE PRICE PAID BY BUYER FOR NON-CONFORMING PRODUCT. IN NO EVENT SHALL ECCO'S LIABILITY ARISING OUT OF THIS LIMITED WARRANTY OR ANY OTHER CLAIM RELATED TO THE ECCO'S PRODUCTS EXCEED THE AMOUNT PAID FOR THE PRODUCT BY BUYER AT THE TIME OF THE ORIGINAL PURCHASE. IN NO EVENT SHALL ECCO BE LIABLE FOR LOST PROFITS, THE COST OF SUBSTITUTE EQUIPMENT OR LABOR, PROPERTY DAMAGE, OR OTHER SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES BASED UPON ANY CLAIM FOR BREACH OF CONTRACT, IMPROPER INSTALLATION, NEGLIGENCE, OR OTHER CLAIM, EVEN IF ECCO OR A REPRESENTATIVE OF ECCO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. ECCO SHALL HAVE NO FURTHER OBLIGATION OR LIABILITY WITH RESPECT TO THE PRODUCT OR ITS SALE, OPERATION AND USE, AND ECCO NEITHER ASSUMES NOR AUTHORIZES THE ASSUMPTION OF ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH SUCH PRODUCT.

This Limited Warranty defines specific legal rights. You may have other legal rights which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages.



833 West Diamond St Boise, Idaho 83705 **Customer Service** USA 800-635-5900 UK +44 (0)113 237 5340 AUS +61 (0)3 63322444 www.**eccoesg.**com

An **ECCO SAFETY GROUP™** Brand WWW.**eccosafetygroup**.com

920-0477-00 Rev. E Page 3 of 3