


INSTALLATION SHEET

ON/OFF AND PATTERN SELECT SWITCH PANEL


THIS SWITCH PANEL WILL PROVIDE ON/OFF CONTROL OF A DEVICE AND FLASH PATTERN SELECTION ON THOSE PRODUCTS WHICH HAVE A SINGLE WIRE FLASH PATTERN SELECTION SYSTEM.

CONNECTION DIAGRAM:



THE PATTERN SELECTION SWITCH IS A MOMENTARY PUSH-BUTTON WHICH SUPPLIES +12V TO BLUE WIRE WHEN PRESSED.

SEE THE INSTRUCTION MANUAL OF THE DEVICE BEING CONNECTED TO THIS SWITCH PANEL FOR DETAILS OF HOW THE FLASH PATTERN IS CHANGED.



SPLICES INCLUDED

SWITCH WIRING REFERENCE:

